




Installation manual

R32 split series



RXA20A2V1B
RXA25A2V1B
RXA35A2V1B

Installation manual
R32 split series

English

CE - DECLARACIONE-DE-CONFORMIDAD
 CE - KONFORMITÄTSEKLERÄRING
 CE - DICHIARAZIONE-DE-CONFORMITA
 CE - ДИКЛAРАЦИЯ-О-СОБЛЕТВЕТВИИ
 CE - CONFORMITÄTSEKLERÄRING

Daikin Industries Czech Republic s.r.o.

- 01 (en) declares under its sole responsibility that the air conditioning models to which this declaration relates.
- 02 (en) erklärt auf seine alleinige Verantwortung, dass die Modelle der Klimaanlage für die diese Erklärung bestimmt ist.
- 03 (en) déclare sous sa seule responsabilité que les appareils d'air conditionné visés par la présente déclaration.
- 04 (en) verklaart hierbij te eigen oorspronkelijke verantwoordelijkheid dat de airconditioning units waaraan deze verklaring betrekking heeft.
- 05 (en) deklaara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración.
- 06 (en) δηλώνει στα αποκλειστικά του condonatoria μετρία και η ίδια η ίδια αυτής δηλώνεται.
- 07 (en) объявляет от своего имени и своей ответственности, что модели климатизации, к которым относится настоящая декларация.
- 08 (en) deklaara sub sua exclusiva responsabilità que os modelos de ar condicionado a que esta declaração se refere.

CE - DECLARACIÓN-DE-CONFORMIDAD
 CE - ЗАЯВЛЕНИЕ-О-СОБЛЕТВЕТВИИ
 CE - DICHIARAZIONE-DE-CONFORMITA
 CE - ДИКЛAРАЦИЯ-О-СОБЛЕТВЕТВИИ
 CE - FORSKÄRAN-OM-ÖVERENSSTÄMMELSE

- 09 (en) заявляет, исключительную под свою ответственность, что модели кондиционеров воздуха, к которым относится настоящая декларация.
- 10 (en) erklærer under eget ansvar at klimaatlægningerne, som denne deklaration vedrører.
- 11 (en) deklarerar seg ansvar for at luftkondisjoneringssystemene som berøres av denne erklæringen innehar alt.
- 12 (en) erklærer et tilsvarende ansvar for de luftkonditioneringsmodeller som berøres av denne erklæringen. Inneharer alt.
- 13 (en) innotiba yksuotamain omalla vastuullisuuten, että tähän ilmoituksen tarkoitettuihin ilmastointilaitteisiin liittyy.
- 14 (en) pronisuje te své plné odpovědnosti, že modely klimatizací, k nimž se tato prohlášení vztahuje.
- 15 (en) zpraviuje pod svojimiú vlastním odgovorností za su modely klimatizácie, na ktoré sa vzťahuje táto vyhlásenie.
- 16 (en) teigs teileisšige luidatiba ņiešit, togi a klimaatleidzības modeļi, piekure ir turpatkazi norakstoti.

CE - ZJAVLVA O SKLADENOSTI
 CE - MEGFELARASÉGI NYILATKOZÁS
 CE - DECLARAZIONE-DE-CONFORMITÀ
 CE - ДЕКЛАРАЦІЯ-О-СОБЛЕТВЕТВИИ
 CE - DECLARAȚIE-DE-CONFORMITATE

- 17 (en) deklaruje na vlastni odgovornost, da modely klimatizacijskih, ki jih vključuje ta izjava, izpolnjuje zahtevane pogoje.
- 18 (en) deklaarar på eget ansvar at klimaatlægningerne, som denne erklæring vedrører.
- 19 (en) deklarerar seg ansvar for de luftkonditioneringsmodeller som berøres av denne erklæringen. Inneharer alt.
- 20 (en) erklærer et tilsvarende ansvar for de luftkonditioneringsmodeller som berøres av denne erklæringen. Inneharer alt.
- 21 (en) innotiba yksuotamain omalla vastuullisuuten, että tähän ilmoituksen tarkoitettuihin ilmastointilaitteisiin liittyy.
- 22 (en) pronisuje te své plné odpovědnosti, že modely klimatizací, k nimž se tato prohlášení vztahuje.
- 23 (en) zpraviuje pod svojimiú vlastním odgovorností za su modely klimatizácie, na ktoré sa vzťahuje táto vyhlásenie.
- 24 (en) teigs teileisšige luidatiba ņiešit, togi a klimaatleidzības modeļi, piekure ir turpatkazi norakstoti.

CE - ATTIKTIKTES-DEKLARACJA
 CE - ATILI STIŠTAS-DEKLARACIJA
 CE - VYHLÁŠENIE-ZHODY
 CE - UYGUNLUK-BEYANI

- 25 (en) deklaruje na vlastni odgovornost, da modely klimatizacijskih, ki jih vključuje ta izjava, izpolnjuje zahtevane pogoje.
- 26 (en) deklaarar på eget ansvar at klimaatlægningerne, som denne erklæring vedrører.
- 27 (en) deklarerar seg ansvar for de luftkonditioneringsmodeller som berøres av denne erklæringen. Inneharer alt.
- 28 (en) erklærer et tilsvarende ansvar for de luftkonditioneringsmodeller som berøres av denne erklæringen. Inneharer alt.
- 29 (en) innotiba yksuotamain omalla vastuullisuuten, että tähän ilmoituksen tarkoitettuihin ilmastointilaitteisiin liittyy.
- 30 (en) pronisuje te své plné odpovědnosti, že modely klimatizací, k nimž se tato prohlášení vztahuje.
- 31 (en) zpraviuje pod svojimiú vlastním odgovorností za su modely klimatizácie, na ktoré sa vzťahuje táto vyhlásenie.
- 32 (en) teigs teileisšige luidatiba ņiešit, togi a klimaatleidzības modeļi, piekure ir turpatkazi norakstoti.

RXA20A2V1B, RXA25A2V1B, RXA35A2V1B,

- 01 are in conformity with the following standard(s) or other normative document(s), provided that these are used in accordance with our instructions:
- 02 (en) derien (følgende) Norm(en) eller et/n andre Norm(dokument) (er) dokument(er) (normativ(e)), som er anvendt i overensstemmelse med vores instruktioner.
- 03 sont conformes à l(s) ou autre(s) norme(s) ou autre(s) document(s) normatifs, pour autant qu'ils soient utilisés conformément à nos instructions.
- 04 conform de volgende norm(en) of één of meer andere bindende document(en) of document(en) normatief, op voorwaarde dat ze worden gebruikt overeenkomstig onze instructies.
- 05 están en conformidad con la(s) siguiente(s) norma(s) u otro(s) documento(s) normativo(s), siempre que sean utilizados de acuerdo con nuestras instrucciones.
- 06 sono conformi all(i) seguente(i) standard(i) o altro(i) documento(i) a carattere normativo, a patto che vengano usati in conformità alle nostre istruzioni.
- 07 είναι σύμφωνα με το(α) ακόλουθο(α) πρότυπο(α) ή άλλο(α) έγγραφο(α) κανονιστικό, υπό την προϋπόθεση ότι χρησιμοποιούνται σύμφωνα με τις οδηγίες μας.
- 08 (en) underlagades af bestemmelserne i:
- 09 (en) enligt villkoren i:
- 10 (en) gemäß den Vorschriften für:
- 11 (en) enligt villkoren i:
- 12 (en) enligt villkoren i:
- 13 (en) enligt villkoren i:
- 14 (en) enligt villkoren i:
- 15 (en) enligt villkoren i:
- 16 (en) enligt villkoren i:
- 17 (en) enligt villkoren i:
- 18 (en) enligt villkoren i:
- 19 (en) enligt villkoren i:
- 20 (en) enligt villkoren i:
- 21 (en) enligt villkoren i:
- 22 (en) enligt villkoren i:
- 23 (en) enligt villkoren i:
- 24 (en) enligt villkoren i:
- 25 (en) enligt villkoren i:

EN60335-2-40,

- 01 (en) underlagades af bestemmelserne i:
- 02 (en) enligt villkoren i:
- 03 (en) gemäß den Vorschriften für:
- 04 (en) enligt villkoren i:
- 05 (en) enligt villkoren i:
- 06 (en) enligt villkoren i:
- 07 (en) enligt villkoren i:
- 08 (en) enligt villkoren i:
- 09 (en) enligt villkoren i:
- 10 (en) enligt villkoren i:
- 11 (en) enligt villkoren i:
- 12 (en) enligt villkoren i:
- 13 (en) enligt villkoren i:
- 14 (en) enligt villkoren i:
- 15 (en) enligt villkoren i:
- 16 (en) enligt villkoren i:
- 17 (en) enligt villkoren i:
- 18 (en) enligt villkoren i:
- 19 (en) enligt villkoren i:
- 20 (en) enligt villkoren i:
- 21 (en) enligt villkoren i:
- 22 (en) enligt villkoren i:
- 23 (en) enligt villkoren i:
- 24 (en) enligt villkoren i:
- 25 (en) enligt villkoren i:

**Low Voltage 2014/35/EU
 Electromagnetic Compatibility 2014/30/EU
 Machinery 2006/42/EC**

- 01 Informator*
- 02 Merk*
- 03 Huon*
- 04 Pöytä*
- 05 Nappi*
- 06 Nappi*
- 07 Nappi*
- 08 Nappi*
- 09 Nappi*
- 10 Nappi*
- 11 Informator*
- 12 Merk*
- 13 Huon*
- 14 Pöytä*
- 15 Nappi*
- 16 Megajärjest*
- 17 Uvega*
- 18 Nola*
- 19 Opomba*
- 20 Märkus*
- 21 Sertifikat*
- 22 Sertifikat*
- 23 Sertifikat*
- 24 Sertifikat*
- 25 Nola*

- 01 Directives as amended
- 02 Direktiven med forändring
- 03 Direktives, telles que modifiées
- 04 Richtlijnen zoals gewijzigd
- 05 Directives, zoals gewijzigd
- 06 Direktive, como se modificó
- 07 Ohjelmot, muutokset mukautettuina
- 08 Direktiivien muokattuina versioina
- 09 Direktiivien muokattuina versioina
- 10 Direktives as amended
- 11 Direktiven med förändring
- 12 Direktives, telles que modifiées
- 13 Richtlijnen zoals gewijzigd
- 14 Directives, zoals gewijzigd
- 15 Direktive, como se modificó
- 16 Ohjelmot, muutokset mukautettuina
- 17 Direktiivien muokattuina versioina
- 18 Direktiivien, muokattuina versioina
- 19 Direktive, muokattuina versioina
- 20 Direktiivien, muokattuina versioina
- 21 Direktiivien, muokattuina versioina
- 22 Direktiivien, muokattuina versioina
- 23 Direktiivien, muokattuina versioina
- 24 Direktiivien, muokattuina versioina
- 25 Direktiivien, muokattuina versioina

- 07** H DICz***
- 08** A DICz***
- 09** K DICz***
- 10** DICz***
- 11** DICz***
- 12** DICz***
- 07** H DICz***
- 08** A DICz***
- 09** K DICz***
- 10** DICz***
- 11** DICz***
- 12** DICz***

- 13** DICz***
- 14** Společnost DICz***
- 15** DICz***
- 16** ADICz***
- 17** DICz***
- 18** DICz***
- 19** DICz***
- 20** DICz***
- 21** DICz***
- 22** DICz***
- 23** DICz***
- 24** DICz***
- 25** DICz***

***DICz = Daikin Industries Czech Republic s.r.o.



Tetsuya Baba
 Managing Director
 Pilsen, 1st of February 2018

(Signature)

DAIKIN INDUSTRIES CZECH REPUBLIC s.r.o.

U Nové Hospody 1/155, 301 00 Plzeň Skvrňany,
 Czech Republic

<A>	DAIKIN.TCF.032D3D01-2018
	DEKRA (NEB0344)
<C>	2159619.0551-EMC

Table of Contents

1	About the documentation	3
1.1	About this document.....	3
2	About the box	3
2.1	Outdoor unit.....	3
2.1.1	To remove the accessories from the outdoor unit.....	3
3	Preparation	4
3.1	Preparing the installation site.....	4
3.1.1	Installation site requirements of the outdoor unit.....	4
3.1.2	Additional installation site requirements of the outdoor unit in cold climates.....	4
3.2	Preparing refrigerant piping.....	5
3.2.1	Refrigerant piping requirements.....	5
3.2.2	Refrigerant piping length and height difference.....	5
3.2.3	Refrigerant piping insulation.....	5
4	Installation	5
4.1	Mounting the outdoor unit.....	5
4.1.1	To provide the installation structure.....	5
4.1.2	To install the outdoor unit.....	6
4.1.3	To provide drainage.....	6
4.1.4	To prevent the outdoor unit from falling over.....	6
4.2	Connecting the refrigerant piping.....	6
4.2.1	Guidelines when connecting the refrigerant piping.....	6
4.2.2	Using the stop valve and service port.....	6
4.2.3	To connect the refrigerant piping to the outdoor unit.....	7
4.3	Checking the refrigerant piping.....	7
4.3.1	To check for leaks.....	7
4.3.2	To perform vacuum drying.....	7
4.4	Charging refrigerant.....	7
4.4.1	About charging refrigerant.....	7
4.4.2	About the refrigerant.....	8
4.4.3	To determine the additional refrigerant amount.....	8
4.4.4	To determine the complete recharge amount.....	8
4.4.5	To charge additional refrigerant.....	8
4.4.6	To fix the fluorinated greenhouse gases label.....	8
4.5	Connecting the electrical wiring.....	9
4.5.1	Guidelines when connecting the electrical wiring.....	9
4.5.2	Specifications of standard wiring components.....	9
4.5.3	To connect the electrical wiring on the outdoor unit.....	9
4.6	Finishing the outdoor unit installation.....	9
4.6.1	To finish the outdoor unit installation.....	9
4.7	About the compressor.....	10
5	Commissioning	10
5.1	Checklist before commissioning.....	10
5.2	Checklist during commissioning.....	10
5.3	To perform a test run.....	10
6	Configuration	10
6.1	To set the facility mode.....	10
7	Troubleshooting	11
7.1	Fault diagnosis using LED on outdoor unit PCB.....	11
8	Disposal	11
8.1	To pump down.....	11
8.2	To start and stop forced cooling.....	11
8.2.1	To start/stop forced cooling using the indoor unit ON/OFF switch.....	11
8.2.2	To start/stop forced cooling using the indoor unit user interface.....	11
9	Technical data	12
9.1	Wiring diagram.....	12

1 About the documentation

1.1 About this document



INFORMATION

Make sure that the user has the printed documentation and ask him/her to keep it for future reference.

Target audience

Authorised installers

Documentation set

This document is part of a documentation set. The complete set consists of:

General safety precautions:

- Safety instructions that you **MUST** read before installing
- Format: Paper (in the box of the outdoor unit)

Outdoor unit installation manual:

- Installation instructions
- Format: Paper (in the box of the outdoor unit)

Installer reference guide:

- Preparation of the installation, reference data,...
- Format: Digital files on <http://www.daikineurope.com/support-and-manuals/product-information/>

Latest revisions of the supplied documentation may be available on the regional Daikin website or via your dealer.

The original documentation is written in English. All other languages are translations.

Technical engineering data


- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin extranet (authentication required).

2 About the box

2.1 Outdoor unit

2.1.1 To remove the accessories from the outdoor unit

- 1 Lift the outdoor unit.
- 2 Remove the accessories at the bottom of the package.



- a General safety precautions
- b Outdoor unit installation manual
- c Fluorinated greenhouse gases label
- d Multilingual fluorinated greenhouse gases label
- e Drain plug (located on the bottom of the packing case)

3 Preparation

3 Preparation

3.1 Preparing the installation site

CAUTION


- Check if the installation location can support the unit's weight. Poor installation is hazardous. It can also cause vibrations or unusual operating noise.
 - Provide sufficient service space.
 - Do NOT install the unit so that it is in contact with a ceiling or a wall, as this may cause vibrations.
- Choose the installation location with sufficient space for carrying the unit in and out of the site.

WARNING

The appliance shall be stored in a room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).

3.1.1 Installation site requirements of the outdoor unit

Mind the following spacing guidelines:




NOTICE

The height of the wall on the outlet side of the outdoor unit MUST be ≤ 1200 mm.

It is recommended to install a baffle plate when the air outlet is exposed to wind.

It is recommended to install the outdoor unit with the air inlet facing the wall and NOT directly exposed to the wind.



- a Baffle plate
- b Prevailing wind direction
- c Air outlet

Do NOT install the unit in sound sensitive areas (e.g. near a bedroom), so that the operation noise will cause no trouble.


Note: If the sound is measured under actual installation conditions, the measured value might be higher than the sound pressure level mentioned in "Sound spectrum" in the data book due to environmental noise and sound reflections.

INFORMATION

The sound pressure level is less than 70 dBA.

3.1.2 Additional installation site requirements of the outdoor unit in cold climates

Protect the outdoor unit against direct snowfall and take care that the outdoor unit is NEVER snowed up.



- a Snow cover or shed
- b Pedestal
- c Prevailing wind direction
- d Air outlet

In any case, provide at least 300 mm of free space below the unit. Additionally, make sure the unit is positioned at least 100 mm above the maximum expected level of snow. See "4.1 Mounting the outdoor unit" on page 5 for more details.

In heavy snowfall areas it is very important to select an installation site where the snow will NOT affect the unit. If lateral snowfall is possible, make sure that the heat exchanger coil is NOT affected by the snow. If necessary, install a snow cover or shed and a pedestal.


3.2 Preparing refrigerant piping

3.2.1 Refrigerant piping requirements

- **Piping material:** Phosphoric acid deoxidised seamless copper.
- **Piping diameter:**

Liquid piping	Ø6.4 mm (1/4")
Gas piping	Ø9.5 mm (3/8")

- **Piping temper grade and thickness:**

Outer diameter (Ø)	Temper grade	Thickness (t) ^(a)	
6.4 mm (1/4")	Annealed (O)	≥0.8 mm	
9.5 mm (3/8")	Annealed (O)		

(a) Depending on the applicable legislation and the unit's maximum working pressure (see "PS High" on the unit name plate), larger piping thickness might be required.

3.2.2 Refrigerant piping length and height difference

What?	Distance
Maximum allowable pipe length	20 m
Minimum allowable pipe length	1.5 m
Maximum allowable height difference	15 m

3.2.3 Refrigerant piping insulation

Pipe outer diameter (Ø _p)	Insulation inner diameter (Ø _i)	Insulation thickness (t)
6.4 mm (1/4")	8~10 mm	≥10 mm
9.5 mm (3/8")	12~15 mm	





If the temperature is higher than 30°C and the humidity is higher than RH 80%, the thickness of the insulation materials should be at least 20 mm to prevent condensation on the surface of the insulation.

4 Installation


4.1 Mounting the outdoor unit

4.1.1 To provide the installation structure

Prepare 4 sets of M8 or M10 anchor bolts, nuts and washers (field supply).




In any case, provide at least 300 mm of free space below the unit. Additionally, make sure the unit is positioned at least 100 mm above the maximum expected level of snow. In this case, it is recommended to construct a pedestal.




a Maximum snowfall height

If the unit is installed on brackets to the wall, install the unit as follows:

4 Installation



4.1.2 To install the outdoor unit



4.1.3 To provide drainage



NOTICE

If the unit is installed in a cold climate, take adequate measures so that the evacuated condensate CANNOT freeze.



INFORMATION


For information on the available options, contact your dealer.



NOTICE

Provide at least 300 mm of free space below the unit. Additionally, make sure the unit is positioned at least 100 mm above the expected level of snow.

- 1 Use a drain plug for drainage.
- 2 Use a $\varnothing 16$ mm hose (field supply).




- a Drain port
- b Bottom frame
- c Drain plug
- d Hose (field supply)

4.1.4 To prevent the outdoor unit from falling over

In case the unit is installed in places where strong wind can tilt the unit, take following measure:

- 1 Prepare 2 cables as indicated in the following illustration (field supply).
- 2 Place the 2 cables over the outdoor unit.
- 3 Insert a rubber sheet between the cables and the outdoor unit to prevent the cable from scratching the paint (field supply).
- 4 Attach the cable's ends. Tighten those ends.



4.2 Connecting the refrigerant piping



DANGER: RISK OF BURNING

4.2.1 Guidelines when connecting the refrigerant piping


Piping size (mm)	Tightening torque (N·m)	Flare dimensions (A) (mm)	Flare shape (mm)
$\varnothing 6.4$	15~17	8.7~9.1	
$\varnothing 9.5$	33~39	12.8~13.2	

4.2.2 Using the stop valve and service port



CAUTION

Do NOT open the valves before flaring is complete. This would cause refrigerant gas leakage.



- a Service port and service port cap
- b Valve stem
- c Field piping connection
- d Stem cap

Item	Tightening torque (N·m)
Stem cap, liquid side	21.6~28.4
Stem cap, gas side	21.6~28.4

Item	Tightening torque (N·m)
Service port cap	10.8~14.7

4.2.3 To connect the refrigerant piping to the outdoor unit

- **Piping length.** Keep field piping as short as possible.
- **Piping protection.** Protect the field piping against physical damage.



WARNING


Connect the refrigerant piping securely before running the compressor. If the refrigerant piping is NOT connected and the stop valve is open when the compressor is run, air will be sucked in. This will cause abnormal pressure in the refrigeration cycle, which may result in equipment damage and even injury.



CAUTION

- Use the flare nut fixed to the unit.
- To prevent gas leakage, apply refrigeration oil only to the inside of the flare. Use refrigeration oil for R32.
- Do NOT reuse joints.

- 1 Connect the liquid refrigerant connection from the indoor unit to the liquid stop valve of the outdoor unit.



- a Liquid stop valve
- b Gas stop valve
- c Service port

- 2 Connect the gas refrigerant connection from the indoor unit to the gas stop valve of the outdoor unit.



NOTICE

It is recommended that the refrigerant piping between indoor and outdoor unit is installed in a ducting or the refrigerant piping is wrapped with finishing tape.

4.3 Checking the refrigerant piping

4.3.1 To check for leaks



NOTICE

Do NOT exceed the unit's maximum working pressure (see "PS High" on the unit name plate).



NOTICE

Make sure to use a recommended bubble test solution from your wholesaler. Do not use soap water, which may cause cracking of flare nuts (soap water may contain salt, which absorbs moisture that will freeze when the piping gets cold), and/or lead to corrosion of flared joints (soap water may contain ammonia which causes a corrosive effect between the brass flare nut and the copper flare).

- 1 Charge the system with nitrogen gas up to a gauge pressure of at least 200 kPa (2 bar). It is recommended to pressurize to 3000 kPa (30 bar) in order to detect small leaks.

- 2 Check for leaks by applying the bubble test solution to all connections.
- 3 Discharge all nitrogen gas.

4.3.2 To perform vacuum drying



DANGER: RISK OF EXPLOSION

Do NOT start the unit if it is vacuumed.

- 1 Vacuum the system until the pressure on the manifold indicates -0.1 MPa (-1 bar).
- 2 Leave as is for 4-5 minutes and check the pressure:

If the pressure...	Then...
Does not change	There is no moisture in the system. This procedure is finished.
Increases	There is moisture in the system. Go to the next step.

- 3 Vacuum the system for at least 2 hours to a manifold pressure of -0.1 MPa (-1 bar).
- 4 After turning the pump OFF, check the pressure for at least 1 hour.
- 5 If you do NOT reach the target vacuum or CANNOT maintain the vacuum for 1 hour, do the following:
 - Check for leaks again.
 - Perform vacuum drying again.



NOTICE

Make sure to open the stop valves after installing the refrigerant piping and performing vacuum drying. Running the system with the stop valves closed may break the compressor.

4.4 Charging refrigerant

4.4.1 About charging refrigerant

The outdoor unit is factory charged with refrigerant, but in some cases the following might be necessary:

What	When
Charging additional refrigerant	When the total liquid piping length is more than specified (see later).
Completely recharging refrigerant	Example: <ul style="list-style-type: none"> • When relocating the system. • After a leak.

Charging additional refrigerant

Before charging additional refrigerant, make sure the outdoor unit's external refrigerant piping is checked (leak test, vacuum drying).



INFORMATION

Depending on the units and/or the installation conditions, it might be necessary to connect electrical wiring before you can charge refrigerant.

Typical workflow – Charging additional refrigerant typically consists of the following stages:

- 1 Determining if and how much you have to charge additionally.
- 2 If necessary, charging additional refrigerant.
- 3 Filling in the fluorinated greenhouse gases label, and fixing it to the inside of the outdoor unit.

4 Installation

Completely recharging refrigerant

Before completely recharging refrigerant, make sure the following is done:

- 1 All refrigerant is recovered from the system.
- 2 The outdoor unit's **external** refrigerant piping is checked (leak test, vacuum drying).
- 3 Vacuum drying on the outdoor unit's **internal** refrigerant piping is performed.

NOTICE

Before completely recharging, perform vacuum drying on the outdoor unit's **internal** refrigerant piping as well.

Typical workflow – Completely recharging refrigerant typically consists of the following stages:

- 1 Determining how much refrigerant to charge.
- 2 Charging refrigerant.
- 3 Filling in the fluorinated greenhouse gases label, and fixing it to the inside of the outdoor unit.

4.4.2 About the refrigerant

This product contains fluorinated greenhouse gases. Do NOT vent gases into the atmosphere.

Refrigerant type: R32

Global warming potential (GWP) value: 675

WARNING: FLAMMABLE MATERIAL

The refrigerant inside this unit is mildly flammable.

WARNING

The appliance shall be stored in a room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).

WARNING

- Do NOT pierce or burn refrigerant cycle parts.
- Do NOT use cleaning materials or means to accelerate the defrosting process other than those recommended by the manufacturer.
- Be aware that the refrigerant inside the system is odourless.

WARNING

The refrigerant inside the unit is mildly flammable, but normally does NOT leak. If the refrigerant leaks in the room and comes in contact with fire from a burner, a heater, or a cooker, this may result in fire, or the formation of a harmful gas.

Turn off any combustible heating devices, ventilate the room, and contact the dealer where you purchased the unit.

Do NOT use the unit until a service person confirms that the part from which the refrigerant leaked has been repaired.

4.4.3 To determine the additional refrigerant amount

If the total liquid piping length is...	Then...
≤10 m	Do NOT add additional refrigerant.

If the total liquid piping length is...	Then...
>10 m	$R = (\text{total length (m) of liquid piping} - 10 \text{ m}) \times 0.020$ $R = \text{Additional charge (kg)} (\text{rounded in units of } 0.1 \text{ kg})$

INFORMATION

Piping length is the one way length of liquid piping.

4.4.4 To determine the complete recharge amount

INFORMATION

If a complete recharge is necessary, the total refrigerant charge is: the factory refrigerant charge (see unit name plate) + the determined additional amount.

4.4.5 To charge additional refrigerant

WARNING


- Only use R32 as refrigerant. Other substances may cause explosions and accidents.
- R32 contains fluorinated greenhouse gases. Its global warming potential (GWP) value is 675. Do NOT vent these gases into the atmosphere.
- When charging refrigerant, ALWAYS use protective gloves and safety glasses.

Prerequisite: Before charging refrigerant, make sure the refrigerant piping is connected and checked (leak test and vacuum drying).

- 1 Connect the refrigerant cylinder to the service port.
- 2 Charge the additional refrigerant amount.
- 3 Open the gas stop valve.

4.4.6 To fix the fluorinated greenhouse gases label

- 1 Fill in the label as follows:



- If a multilingual fluorinated greenhouse gases label is delivered with the unit (see accessories), peel off the applicable language and stick it on top of a.
- Factory refrigerant charge: see unit name plate
- Additional refrigerant amount charged
- Total refrigerant charge
- Greenhouse gas emissions** of the total refrigerant charge expressed as tonnes CO₂-equivalent
- GWP = Global warming potential

NOTICE

In Europe, the **greenhouse gas emissions** of the total refrigerant charge in the system (expressed as tonnes CO₂-equivalent) is used to determine the maintenance intervals. Follow the applicable legislation.

Formula to calculate the greenhouse gas emissions:
 $\text{GWP value of the refrigerant} \times \text{Total refrigerant charge [in kg]} / 1000$

- 2 Fix the label on the inside of the outdoor unit near the gas and liquid stop valves.

4.5 Connecting the electrical wiring

DANGER: RISK OF ELECTROCUTION

WARNING

- All wiring **MUST** be performed by an authorised electrician and **MUST** comply with the applicable legislation.
- Make electrical connections to the fixed wiring.
- All components procured on the site and all electrical construction **MUST** comply with the applicable legislation.

WARNING

ALWAYS use multicore cable for power supply cables.

WARNING

If the supply cord is damaged, it **MUST** be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

WARNING

Do **NOT** connect the power supply to the indoor unit. This could result in electrical shock or fire.

WARNING

- Do **NOT** use locally purchased electrical parts inside the product.
- Do **NOT** branch the power supply for the drain pump, etc. from the terminal block. This could result in electrical shock or fire.

WARNING


Keep the interconnection wiring away from copper pipes without thermal insulation as such pipes will be very hot.

DANGER: RISK OF ELECTROCUTION

Disconnect the power supply for more than 10 minutes, and measure the voltage at the terminals of main circuit capacitors or electrical components before servicing. The voltage **MUST** be less than 50 V DC before you can touch electrical components. For the location of the terminals, see the wiring diagram.

DANGER: RISK OF ELECTROCUTION

All electrical parts (including thermistors) are powered by the power supply. Do not touch them with bare hands.



- a Multimeter (DC voltage range)
- b S70 – fan motor lead wire
- c LED
- d S90 – thermistor lead wire
- e S20 – electronic expansion valve lead wire
- f S80 – reversing solenoid valve lead wire
- g S40 – thermal overload relay lead wire
- h DB1 - diode bridge

4.5.1 Guidelines when connecting the electrical wiring

Tightening torques


Item	Tightening torque (N·m)
M4 (X1M)	1.5~1.6
M4 (earth)	1.4~1.5

4.5.2 Specifications of standard wiring components

Component	RXA	
	20	25+35
Power supply cable	Voltage	220~240 V
	Phase	1~
	Frequency	50 Hz
	Wire sizes	MUST comply with applicable legislation
Interconnection cable (indoor↔outdoor)	4-core cable ≥1.5 mm ² and applicable for 220~240 V	
Recommended field fuse	10 A	13A
Earth leakage circuit breaker	MUST comply with applicable legislation	

4.5.3 To connect the electrical wiring on the outdoor unit

- Open the wire clamp.
- Connect the interconnection cable and power supply as follows:



- a Interconnection cable
- b Power supply cable
- c Field fuse
- d Earth leakage circuit breaker
- e Power supply
- f Earth

- Tighten the terminal screws securely. We recommend using a Phillips screwdriver.


4.6 Finishing the outdoor unit installation

4.6.1 To finish the outdoor unit installation

DANGER: RISK OF ELECTROCUTION

- Make sure that the system is earthed properly.
- Turn off the power supply before servicing.
- Install the service cover before turning on the power supply.

- Insulate and fix the refrigerant piping and interconnection cable as follows:



5 Commissioning

- a Gas pipe
- b Gas pipe insulation
- c Interconnection cable
- d Liquid pipe
- e Liquid pipe insulation
- f Finishing tape

2 Install the service cover.

4.7 About the compressor



DANGER: RISK OF EXPLOSION

- Use a pipe cutter to remove the compressor.
- Do NOT use the brazing torch.
- Use approved refrigerants and lubricants only.



DANGER: RISK OF BURNING

Do NOT touch the compressor with bare hands.

5 Commissioning



NOTICE

NEVER operate the unit without thermistors and/or pressure sensors/switches. Burning of the compressor might result.

5.1 Checklist before commissioning

Do NOT operate the system before the following checks are OK:

<input type="checkbox"/>	The indoor unit is properly mounted.
<input type="checkbox"/>	The outdoor unit is properly mounted.
<input type="checkbox"/>	The system is properly earthed and the earth terminals are tightened.
<input type="checkbox"/>	The fuses or locally installed protection devices are installed according to this document, and have NOT been bypassed.
<input type="checkbox"/>	The power supply voltage matches the voltage on the identification label of the unit.
<input type="checkbox"/>	There are NO loose connections or damaged electrical components in the switch box.
<input type="checkbox"/>	There are NO damaged components or squeezed pipes on the inside of the indoor and outdoor units.
<input type="checkbox"/>	There are NO refrigerant leaks .
<input type="checkbox"/>	The refrigerant pipes (gas and liquid) are thermally insulated.
<input type="checkbox"/>	The correct pipe size is installed and the pipes are properly insulated.
<input type="checkbox"/>	The stop valves (gas and liquid) on the outdoor unit are fully open.
<input type="checkbox"/>	The following field wiring has been carried out according to this document and the applicable legislation between the outdoor unit and the indoor unit.
<input type="checkbox"/>	Drainage Make sure drainage flows smoothly. Possible consequence: Condensate water might drip.
<input type="checkbox"/>	The indoor unit receives the signals of the user interface .
<input type="checkbox"/>	The specified wires are used for the interconnection cable .

5.2 Checklist during commissioning

<input type="checkbox"/>	To perform an air purge .
<input type="checkbox"/>	To perform a test run .

5.3 To perform a test run

Prerequisite: Power supply **MUST** be in the specified range.

Prerequisite: Test run may be performed done in cooling or heating mode.

Prerequisite: Test run should be performed in accordance with the operation manual of the indoor unit to make sure that all functions and parts are working properly.

- 1 In cooling mode, select the lowest programmable temperature. In heating mode, select the highest programmable temperature. Test run can be disabled if necessary.
- 2 When the test run is finished, set the temperature to a normal level. In cooling mode: 26~28°C, in heating mode: 20~24°C.
- 3 The system stops operating 3 minutes after turning the unit OFF.




INFORMATION

- Even if the unit is turned OFF, it consumes electricity.
- When the power turns back on after a power break, the previously selected mode will be resumed.

6 Configuration

6.1 To set the facility mode

When cutting jumper J6 on the PCB, the operation range will expand to -15°C. The facility mode will stop if the outdoor temperature drops below -20°C and resume when the temperature rises again.






INFORMATION

- The indoor unit may produce Intermittent noise due to the outdoor unit fan turning ON and/or OFF.
- Do NOT place humidifiers or other items which might raise humidity in rooms when you use the facility mode.
- Cutting jumper J6 sets the indoor unit fan to the highest speed.
- Do NOT use this setting in residences or offices with people.

7 Troubleshooting

7.1 Fault diagnosis using LED on outdoor unit PCB

LED is...	Diagnosis
 flashing	Normal. <ul style="list-style-type: none"> Check the indoor unit.
 ON	<ul style="list-style-type: none"> Turn the power OFF and back ON, and check the LED within approximately 3 minutes. If the LED is ON again, the outdoor unit PCB is faulty.
 OFF	<ol style="list-style-type: none"> Supply voltage (for power saving). Power supply fault. Turn the power OFF and back ON, and check the LED within approximately 3 minutes. If the LED is ON again, the outdoor unit PCB is faulty.



DANGER: RISK OF ELECTROCUTION

- When the unit is not operating, the LEDs on the PCB are turned off in order to save power.
- Even when the LEDs are off, the terminal block and the PCB may be powered.

8 Disposal



NOTICE

Do NOT try to dismantle the system yourself: the dismantling of the system, treatment of the refrigerant, oil and other parts MUST comply with applicable legislation. Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery.

8.1 To pump down

Example: To protect the environment, pump down when relocating the unit or when disposing of the unit.



DANGER: RISK OF EXPLOSION

Pump down – Refrigerant leakage. If you want to pump down the system, and there is a leakage in the refrigerant circuit:

- Do NOT use the unit's automatic pump down function, with which you can collect all refrigerant from the system into the outdoor unit. **Possible consequence:** Self-combustion and explosion of the compressor because of air going into the operating compressor.
- Use a separate recovery system so that the unit's compressor does NOT have to operate.




NOTICE

During pump down operation, stop the compressor before removing the refrigerant piping. If the compressor is still running and the stop valve is open during pump down, air will be sucked into the system. Compressor breakdown or damage to the system can result due to abnormal pressure in the refrigerant cycle.

Pump down operation will extract all refrigerant from the system into the outdoor unit.

- Remove the valve cap from the liquid stop valve and the gas stop valve.
- Carry out forced cooling. See "8.2 To start and stop forced cooling" on page 11.
- After 5 to 10 minutes (after only 1 or 2 minutes in case of very low ambient temperatures ($<-10^{\circ}\text{C}$)), close the liquid stop valve with a hexagonal wrench.
- Check on the manifold if the vacuum is reached.
- After 2-3 minutes, close the gas stop valve and stop forced cooling.



- a Gas stop valve
- b Closing direction
- c Hexagonal wrench
- d Valve cap
- e Liquid stop valve

8.2 To start and stop forced cooling

There are 2 methods to perform forced cooling.

- Method 1.** Using the indoor unit ON/OFF switch (if present on the indoor unit).
- Method 2.** Using the indoor unit user interface.

8.2.1 To start/stop forced cooling using the indoor unit ON/OFF switch

- Press the ON/OFF switch for at least 5 seconds.

Result: Operation will start.

Note: Forced cooling stops automatically after 15 minutes.

- To stop operation sooner, press the ON/OFF switch.

8.2.2 To start/stop forced cooling using the indoor unit user interface

- Set the operation mode to **cooling**.

For the procedure, refer to "To perform a test run" in the installation manual of the indoor unit.

Note: Forced cooling will stop automatically after around 30 minutes.

- To stop operation sooner, press the ON/OFF switch.



INFORMATION

If forced cooling is used and the outside temperature is $<-10^{\circ}\text{C}$, the safety device may prevent operation.

















- Warm the outside temperature thermistor on the outdoor unit to $\geq-10^{\circ}\text{C}$. **Result:** Operation will start.



9 Technical data



9 Technical data



A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible). The **full set** of latest technical data is available on the Daikin extranet (authentication required).

9.1 Wiring diagram

Unified Wiring Diagram Legend			
For applied parts and numbering refer to the wiring diagram sticker supplied on the unit. Part numbering is realized by Arabic numbers in ascending order for each part and is represented in the overview below by symbol ^{198T} in the part code.			
	: CIRCUIT BREAKER		: PROTECTIVE EARTH
	: CONNECTION		: PROTECTIVE EARTH (SCREW)
	: CONNECTOR		: RECTIFIER
	: EARTH		: RELAY CONNECTOR
	: FIELD WIRING		: SHORT CIRCUIT CONNECTOR
	: FUSE		: TERMINAL
	: INDOOR UNIT		: TERMINAL STRIP
	: OUTDOOR UNIT		: WIRE CLAMP
BLK : BLACK	GRN : GREEN	PNK : PINK	WHT : WHITE
BLU : BLUE	GRY : GREY	PRP, PPL : PURPLE	YLW : YELLOW
BRN : BROWN	ORG : ORANGE	RED : RED	
A*P	: PRINTED CIRCUIT BOARD	PS	: SWITCHING POWER SUPPLY
BS*	: PUSH BUTTON ON / OFF, OPERATION SWITCH	PTC*	: THERMISTOR PTC
BZ, H*O	: BUZZER	Q*	: INSULATED GATE BIPOLAR TRANSISTOR (IGBT)
C*	: CAPACITOR	Q*DI	: EARTH LEAK CIRCUIT BREAKER
AC*, CN*, E*, HA*, HE, HL*, HN*, HR*, MR*_A, MR*_B, S*, U, V, W, X*A, K*R_*	: CONNECTION, CONNECTOR	Q*L	: OVERLOAD PROTECTOR
D*, V*D	: DIODE	Q*M	: THERMO SWITCH
DB*	: DIODE BRIDGE	R*	: RESISTOR
DS*	: DIP SWITCH	R*T	: THERMISTOR
E*H	: HEATER	RC	: RECEIVER
F*U, FU* (FOR CHARACTERISTICS REFER TO PCB INSIDE YOUR UNIT)	: FUSE	S*C	: LIMIT SWITCH
FG*	: CONNECTOR (FRAME GROUND)	S*L	: FLOAT SWITCH
H*	: HARNESS	S*NPH	: PRESSURE SENSOR (HIGH)
H*P, LED*, V*L	: PILOT LAMP, LIGHT EMITTING DIODE	S*NPL	: PRESSURE SENSOR (LOW)
HAP	: LIGHT EMITTING DIODE (SERVICE MONITOR GREEN)	S*PH, HPS*	: PRESSURE SWITCH (HIGH)
HIGH VOLTAGE	: HIGH VOLTAGE	S*PL	: PRESSURE SWITCH (LOW)
IES	: INTELLIGENT EYE SENSOR	S*T	: THERMOSTAT
IPM*	: INTELLIGENT POWER MODULE	S*RH	: HUMIDITY SENSOR
K*R, KCR, KFR, KHuR, K*M	: MAGNETIC RELAY	S*W, SW*	: OPERATION SWITCH
L	: LIVE	SA*, F1S	: SURGE ARRESTOR
L*	: COIL	SR*, WLU	: SIGNAL RECEIVER
L*R	: REACTOR	SS*	: SELECTOR SWITCH
M*	: STEPPER MOTOR	SHEET METAL	: TERMINAL STRIP FIXED PLATE
M*C	: COMPRESSOR MOTOR	T*R	: TRANSFORMER
M*F	: FAN MOTOR	TC, TRC	: TRANSMITTER
M*P	: DRAIN PUMP MOTOR	V*, R*V	: VARISTOR
M*S	: SWING MOTOR	V*R	: DIODE BRIDGE
MR*, MRCW*, MRM*, MRN*	: MAGNETIC RELAY	WRC	: WIRELESS REMOTE CONTROLLER
N	: NEUTRAL	X*	: TERMINAL
n = *, N = *	: NUMBER OF PASSES THROUGH FERRITE CORE	X*M	: TERMINAL STRIP (BLOCK)
PAM	: PULSE-AMPLITUDE MODULATION	Y*E	: ELECTRONIC EXPANSION VALVE COIL
PCB*	: PRINTED CIRCUIT BOARD	Y*R, Y*S	: REVERSING SOLENOID VALVE COIL
PM*	: POWER MODULE	Z*C	: FERRITE CORE
		ZF, Z*F	: NOISE FILTER









Copyright 2017 Daikin

DAIKIN INDUSTRIES CZECH REPUBLIC s.r.o.
U Nové Hospody 1/1155, 301 00 Plzeň Skvrňany, Czech Republic

DAIKIN EUROPE N.V.
Zandvoordestraat 300, B-8400 Oostende, Belgium

3P517827-1 2017.12