

Service Manual

Inverter Pair Floor Standing Type B Series



- [Applied Models]**
- Inverter Pair : Cooling Only
 - Inverter Pair : Heat Pump

Inverter Pair Floor Standing Type B Series

● **Cooling Only**
Indoor Unit

FVKS25BVMB
FVKS35BVMB

Outdoor Unit

RKS25BVMB
RKS35BVMB

● **Heat Pump**
Indoor Unit

FVXS25BVMB
FVXS35BVMB

Outdoor Unit

RXS25BVMB
RXS35BVMB



1. Introduction	V
1.1 Safety Cautions	V
Part 1 List of Functions	1
1. Functions	2
Part 2 Specifications	3
1. Specifications	4
1.1 Cooling Only	4
1.2 Heat Pump	5
Part 3 Printed Circuit Board Connector Wiring Diagram	7
1. Printed Circuit Board Connector Wiring Diagram	8
1.1 FVKS 25/35 B, FVXS 25/35 B Series	8
1.2 RKS 25/35 BVMB, RXS 25/35 BVMB	10
Part 4 Function and Control	13
1. Main Functions	14
1.1 Frequency Principle	14
1.2 Flap Control	16
1.3 Air Flow Selection	17
1.4 Fan Speed Control for Indoor Units	18
1.5 Programme Dry Function	19
1.6 Automatic Operation	20
1.7 Night Set Mode	21
1.8 Home Leave Operation	22
1.9 Inverter Powerful Operation	23
1.10 Other Functions	24
2. Function of Main Structural Parts	26
2.1 Main Structural Parts	26
2.2 Function of Thermistor	27
3. Control Specification	29
3.1 Mode Hierarchy	29
3.2 Frequency Control	30
3.3 Controls at Mode Changing / Start-up	32
3.4 Discharge Pipe Control	33
3.5 Input Current Control	33
3.6 Freeze-up Protection Control	34
3.7 Heating Peak-cut Control	34
3.8 Fan Control	35
3.9 Moisture Protection Function 1 (Securing of Differential Pressure and Blown Air Temperature)	35
3.10 Moisture Protection Function 2	36
3.11 Defrost Control	37
3.12 Electronic Expansion Valve Control	38
3.13 Malfunctions	41
3.14 Forced Operation Mode	42
3.15 Additional Function	42

Part 5 System Configuration.....	43
1. System Configuration.....	44
1.1 Operation Instructions	44
2. Instruction.....	45
2.1 Safety Precautions	45
2.2 Names of Parts.....	47
2.3 Preparation before Operation.....	50
2.4 AUTO·DRY·COOL·HEAT·FAN Operation	53
2.5 Adjusting the Air Flow Direction	55
2.6 POWERFUL Operation	57
2.7 Outdoor Unit Silent Operation	58
2.8 HOME LEAVE Operation	59
2.9 TIMER Operation	61
2.10 Care and Cleaning	63
2.11 Trouble Shooting	66
Part 6 Service Diagnosis.....	69
1. Caution for Diagnosis.....	70
2. Problem Symptoms and Measures	71
3. Service Check Function	72
3.1 ARC433 Series.....	72
4. Troubleshooting	73
4.1 Error Codes and Description	73
4.2 Indoor Unit PCB Abnormality	74
4.3 Freeze-up Protection Control or High Pressure Control.....	75
4.4 Fan Motor (DC Motor) or Related Abnormality.....	77
4.5 Thermistor or Related Abnormality (Indoor Unit).....	79
4.6 Shutter Drive Motor / Shutter Limit Switch Abnormality	80
4.7 Signal Transmission Error (between Indoor and Outdoor Units).....	81
4.8 OL Activation (Compressor Overload)	82
4.9 Compressor Lock	83
4.10 Input Over Current Detection	84
4.11 Four Way Valve Abnormality	85
4.12 Discharge Pipe Temperature Control.....	87
4.13 Position Sensor Abnormality	88
4.14 CT or Related Abnormality	89
4.15 Thermistor or Related Abnormality (Outdoor Unit).....	91
4.16 Electrical Box Temperature Rise	93
4.17 Radiation Fin Temperature Rise	95
4.18 Output Over Current Detection.....	97
4.19 Insufficient Gas.....	99
4.20 Over-voltage Detection.....	101
4.21 High Pressure Control in Cooling	102
5. Checks	104
5.1 How to Check.....	104

Part 7 Removal Procedure	113
1. Indoor Unit.....	114
1.1 Removal of the Air Filter / Front Panel	114
1.2 Removal of the Horizontal Blade	117
1.3 Removal of the Electrical Box	118
1.4 Removal of the PCB.....	121
1.5 Removal of the Heat Exchanger	123
1.6 Removal of the Fan Rotor / Fan Motor.....	125
2. Outdoor Unit.....	127
2.1 Removal of External Casing.....	127
2.2 Removal of Bellmouth and Left Side Plate.....	129
2.3 Removal of PCB and Electrical Box	130
2.4 Removal of Propeller Fan and Fan Motor	136
2.5 Removal of Compressor Noise Absorption Pad.....	138
2.6 Removal of Partition Plate and Reactor	140
2.7 Removal of Four Way Valve and Motor Valve	143
2.8 Removal of Compressor.....	146
Part 8 Appendix.....	149
1. Piping Diagrams.....	150
1.1 Indoor Units	150
1.2 Outdoor Units	151
2. Wiring Diagrams.....	153
2.1 Indoor Units	153
2.2 Outdoor Units	154
Index	i
Drawings & Flow Charts	v

1. Introduction

1.1 Safety Cautions

Cautions and Warnings

- Be sure to read the following safety cautions before conducting repair work.
- The caution items are classified into “ **Warning**” and “ **Caution**”. The “ **Warning**” items are especially important since they can lead to death or serious injury if they are not followed closely. The “ **Caution**” items can also lead to serious accidents under some conditions if they are not followed. Therefore, be sure to observe all the safety caution items described below.
- About the pictograms
 - △ This symbol indicates an item for which caution must be exercised.
The pictogram shows the item to which attention must be paid.
 - This symbol indicates a prohibited action.
The prohibited item or action is shown inside or near the symbol.
 - This symbol indicates an action that must be taken, or an instruction.
The instruction is shown inside or near the symbol.
- After the repair work is complete, be sure to conduct a test operation to ensure that the equipment operates normally, and explain the cautions for operating the product to the customer.

1.1.1 Caution in Repair

 Warning	
Be sure to disconnect the power cable plug from the plug socket before disassembling the equipment for a repair. Working on the equipment that is connected to a power supply can cause an electrical shock. If it is necessary to supply power to the equipment to conduct the repair or inspecting the circuits, do not touch any electrically charged sections of the equipment.	
If the refrigerant gas discharges during the repair work, do not touch the discharging refrigerant gas. The refrigerant gas can cause frostbite.	
When disconnecting the suction or discharge pipe of the compressor at the welded section, release the refrigerant gas completely at a well-ventilated place first. If there is a gas remaining inside the compressor, the refrigerant gas or refrigerating machine oil discharges when the pipe is disconnected, and it can cause injury.	
If the refrigerant gas leaks during the repair work, ventilate the area. The refrigerant gas can generate toxic gases when it contacts flames.	
The step-up capacitor supplies high-voltage electricity to the electrical components of the outdoor unit. Be sure to discharge the capacitor completely before conducting repair work. A charged capacitor can cause an electrical shock.	
Do not start or stop the air conditioner operation by plugging or unplugging the power cable plug. Plugging or unplugging the power cable plug to operate the equipment can cause an electrical shock or fire.	

 Caution	
Do not repair the electrical components with wet hands. Working on the equipment with wet hands can cause an electrical shock.	
Do not clean the air conditioner by splashing water. Washing the unit with water can cause an electrical shock.	
Be sure to provide the grounding when repairing the equipment in a humid or wet place, to avoid electrical shocks.	
Be sure to turn off the power switch and unplug the power cable when cleaning the equipment. The internal fan rotates at a high speed, and cause injury.	
Do not tilt the unit when removing it. The water inside the unit can spill and wet the furniture and floor.	
Be sure to check that the refrigerating cycle section has cooled down sufficiently before conducting repair work. Working on the unit when the refrigerating cycle section is hot can cause burns.	
Use the welder in a well-ventilated place. Using the welder in an enclosed room can cause oxygen deficiency.	

1.1.2 Cautions Regarding Products after Repair

 Warning	
Be sure to use parts listed in the service parts list of the applicable model and appropriate tools to conduct repair work. Never attempt to modify the equipment. The use of inappropriate parts or tools can cause an electrical shock, excessive heat generation or fire.	
When relocating the equipment, make sure that the new installation site has sufficient strength to withstand the weight of the equipment. If the installation site does not have sufficient strength and if the installation work is not conducted securely, the equipment can fall and cause injury.	
Be sure to install the product correctly by using the provided standard installation frame. Incorrect use of the installation frame and improper installation can cause the equipment to fall, resulting in injury.	For integral units only
Be sure to install the product securely in the installation frame mounted on a window frame. If the unit is not securely mounted, it can fall and cause injury.	For integral units only

 Warning	
Be sure to use an exclusive power circuit for the equipment, and follow the technical standards related to the electrical equipment, the internal wiring regulations and the instruction manual for installation when conducting electrical work. Insufficient power circuit capacity and improper electrical work can cause an electrical shock or fire.	
Be sure to use the specified cable to connect between the indoor and outdoor units. Make the connections securely and route the cable properly so that there is no force pulling the cable at the connection terminals. Improper connections can cause excessive heat generation or fire.	
When connecting the cable between the indoor and outdoor units, make sure that the terminal cover does not lift off or dismount because of the cable. If the cover is not mounted properly, the terminal connection section can cause an electrical shock, excessive heat generation or fire.	
Do not damage or modify the power cable. Damaged or modified power cable can cause an electrical shock or fire. Placing heavy items on the power cable, and heating or pulling the power cable can damage the cable.	
Do not mix air or gas other than the specified refrigerant (R410A) in the refrigerant system. If air enters the refrigerating system, an excessively high pressure results, causing equipment damage and injury.	
If the refrigerant gas leaks, be sure to locate the leak and repair it before charging the refrigerant. After charging refrigerant, make sure that there is no refrigerant leak. If the leak cannot be located and the repair work must be stopped, be sure to perform pump-down and close the service valve, to prevent the refrigerant gas from leaking into the room. The refrigerant gas itself is harmless, but it can generate toxic gases when it contacts flames, such as fan and other heaters, stoves and ranges.	
When replacing the coin battery in the remote controller, be sure to disposed of the old battery to prevent children from swallowing it. If a child swallows the coin battery, see a doctor immediately.	

 Caution	
Installation of a leakage breaker is necessary in some cases depending on the conditions of the installation site, to prevent electrical shocks.	
Do not install the equipment in a place where there is a possibility of combustible gas leaks. If a combustible gas leaks and remains around the unit, it can cause a fire.	
Be sure to install the packing and seal on the installation frame properly. If the packing and seal are not installed properly, water can enter the room and wet the furniture and floor.	For integral units only

1.1.3 Inspection after Repair

 Warning	
Check to make sure that the power cable plug is not dirty or loose, then insert the plug into a power outlet all the way. If the plug has dust or loose connection, it can cause an electrical shock or fire.	
If the power cable and lead wires have scratches or deteriorated, be sure to replace them. Damaged cable and wires can cause an electrical shock, excessive heat generation or fire.	

 Warning	
Do not use a joined power cable or extension cable, or share the same power outlet with other electrical appliances, since it can cause an electrical shock, excessive heat generation or fire.	

 Caution	
Check to see if the parts and wires are mounted and connected properly, and if the connections at the soldered or crimped terminals are secure. Improper installation and connections can cause excessive heat generation, fire or an electrical shock.	
If the installation platform or frame has corroded, replace it. Corroded installation platform or frame can cause the unit to fall, resulting in injury.	
Check the grounding, and repair it if the equipment is not properly grounded. Improper grounding can cause an electrical shock.	
Be sure to measure the insulation resistance after the repair, and make sure that the resistance is 1 Mohm or higher. Faulty insulation can cause an electrical shock.	
Be sure to check the drainage of the indoor unit after the repair. Faulty drainage can cause the water to enter the room and wet the furniture and floor.	

1.1.4 Using Icons

Icons are used to attract the attention of the reader to specific information. The meaning of each icon is described in the table below:

1.1.5 Using Icons List

Icon	Type of Information	Description
 Note:	Note	A “note” provides information that is not indispensable, but may nevertheless be valuable to the reader, such as tips and tricks.
 Caution	Caution	A “caution” is used when there is danger that the reader, through incorrect manipulation, may damage equipment, lose data, get an unexpected result or has to restart (part of) a procedure.
 Warning	Warning	A “warning” is used when there is danger of personal injury.
	Reference	A “reference” guides the reader to other places in this binder or in this manual, where he/she will find additional information on a specific topic.

Part 1

List of Functions

1. Functions.....2

1. Functions

Category	Functions	FVKS25-35B RKS25-35B	FVXS25-35B RXS25-35B	Category	Functions	FVKS25-35B RKS25-35B	FVXS25-35B RXS25-35B	
Basic Function	Inverter (with Inverter Power Control)	○	○	Health & Clean	Air Purifying Filter with Bacteriostatic, Virustatic Functions	○	○	
	Operation Limit for Cooling (°C)	-10 ~46	-10 ~46		Photocatalytic Deodorizing Filter	○	○	
	Operation Limit for Heating (°C)	—	-15 ~20		Air Purifying Filter with Photocatalytic Deodorizing Function	—	—	
	PAM Control	○	○		Longlife Filter	—	—	
Compressor	Oval Scroll Compressor	—	—		Ultra-Longlife Filter (Option)	—	—	
	Swing Compressor	○	○		Mold Proof Air Filter	○	○	
	Rotary Compressor	—	—		Wipe-clean Flat Panel	—	—	
	Reluctance DC Motor	○	○		Washable Grille	○	○	
Comfortable Airflow	Power-Airflow Flap	—	—		Filter Cleaning Indicator	—	—	
	Power-Airflow Dual Flaps	—	—		Good-Sleep Cooling Operation	—	—	
	Power-Airflow Diffuser	—	—		Timer	24-Hour On/Off Timer	○	○
	Wide-Angle Louvers	○	○			Night Set Mode	○	○
	Vertical Auto-Swing (Up and Down)	○	○	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○	
	Horizontal Auto-Swing (Right and Left)	—	—		Self-Diagnosis (Digital, LED) Display	○ ★	○ ★	
	3-D Airflow	—	—		Wiring Error Check	—	—	
3-Step Airflow (H/P Only)	—	—	Anticorrosion Treatment of Outdoor Heat Exchanger		○	○		
Comfort Control	Auto Fan Speed	○	○	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○	
	Indoor Unit Silent Operation	○	○		Flexible Voltage Correspondence	○	○	
	Night Quiet Mode (Automatic)	—	—		High Ceiling Application	—	—	
	Outdoor Unit Silent Operation (Manual)	○	○		Chargeless	10m	10m	
	Intelligent Eye	—	—		Power Selection	—	—	
	Quick Warming Function	—	○		Remote Control	5-Rooms Centralized Controller (Option)	○	○
	Hot-Start Function	—	○			Remote Control Adaptor (Normal Open-Pulse Contact)(Option)	○	○
Automatic Defrosting	—	○	Remote Control Adaptor (Normal Open Contact)(Option)	○		○		
Lifestyle Convenience	Automatic Operation	—	○	Remote Controller		DIII-NET Compatible (Adaptor)(Option)	○	○
	Programme Dry Function	○	○		Wireless	○	○	
	Fan Only	○	○	Wired	—	—		
	New Powerful Operation (Non-Inverter)	—	—					
	Inverter Powerful Operation	○	○					
	Priority-Room Setting	—	—					
	Cooling / Heating Mode Lock	—	—					
	Home Leave Operation	○	○					
Indoor Unit On/Off Switch	○	○						
Signal Reception Indicator	○	○						
Temperature Display	—	—						
Another Room Operation	—	—						

Note: ○ : Holding Functions
— : No Functions

★ : Digital Only

Part 2 Specifications

1. Specifications	4
1.1 Cooling Only	4
1.2 Heat Pump	5

1. Specifications

1.1 Cooling Only

230V, 50Hz

Model	Indoor Units		FVKS25BVMB		FVKS35BVMB	
	Outdoor Units		RKS25BVMB		RKS35BVMB	
Capacity Rated (Min.-Max.)		kW	2.5 (1.0~3.0)		3.5 (1.0~3.7)	
		Btu/h	8,550 (3,400~10,250)		11,950 (3,400~12,600)	
		kcal/h	2,150 (860~2,580)		3,010 (860~3,180)	
Moisture Removal		L/h	1.2		1.9	
Running Current (Rated)		A	3.7		5.5	
Power Consumption Rated (Min.-Max.)		W	700 (240~925)		1,160 (240~1,300)	
Power Factor (Min.-Max.)		%	82.3		91.7	
COP		W/W	3.57		3.02	
Piping Connections	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	φ 20.0		φ 20.0	
Heat Insulation	Both Liquid and Gas Pipes				Both Liquid and Gas Pipes	
Indoor Unit			FVKS25BVMB		FVKS35BVMB	
Front Panel Color			Almond White		Almond White	
Air Flow Rate	m³/min (cfm)	H	8.1 (286)		8.3 (293)	
		M	6.2 (219)		6.3 (222)	
		L	4.3 (152)		4.3 (152)	
		SL	3.4 (120)		3.4 (120)	
Fan	Type		Cross Flow Fan		Cross Flow Fan	
	Motor Output Upper/Lower	W	14/14		14/14	
	Speed	Steps	5 Steps, Silent and Auto		5 Steps, Silent and Auto	
Air Direction Control			Right, Left, Horizontal and Upward		Right, Left, Horizontal and Upward	
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Current (Rated)		A	0.14		0.14	
Power Consumption (Rated)		W	32		32	
Power Factor		%	99.4		99.4	
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)		mm	600x650x195		600x650x195	
Packaged Dimensions (WxDxH)		mm	770x294x714		770x294x714	
Weight		kg	13		13	
Gross Weight		kg	19		19	
Operation Sound	H/M/L/SL	dBA	38 / 32 / 26 / 23		39 / 33 / 27 / 24	
Sound Power	H	dBA	54		55	
Outdoor Unit			RKS25BVMB		RKS35BVMB	
Casing Color			Ivory White		Ivory White	
Compressor	Type		Hermetically Sealed Swing Type		Hermetically Sealed Swing Type	
	Model		1YC23GXD#A		1YC23GXD#A	
Refrigerant Oil	Motor Output	W	600		600	
	Model		FVC50K		FVC50K	
Refrigerant	Charge	L	0.4		0.4	
	Model		R410A		R410A	
Refrigerant	Charge	kg	0.96		1.06	
	Model		R410A		R410A	
Air Flow Rate	m³/min (H/L)		25.3/17.0		25.3/17.0	
	cfm (H/L)		893/600		893/600	
Fan	Type		Propeller		Propeller	
	Motor Output	W	19		19	
Running Current (Rated)		A	3.56		5.36	
Power Consumption (Rated)		W	668		1,128	
Power Factor		%	81.6		94.0	
Starting Current		A	3.7		5.5	
Dimensions (HxWxD)		mm	560x695x265		560x695x265	
Packaged Dimensions (WxDxH)		mm	797x310x599		797x310x599	
Weight		kg	37		37	
Gross Weight		kg	40		40	
Operation Sound	H/L	dBA	46 / 43		47 / 44	
Sound Power	H	dBA	59		60	
Drawing No.			3D040164A		3D040165A	

Notes:

- MAX. interunit piping length: 25m
- MAX. interunit height difference: 15m
- Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
- The data are based on the conditions shown in the table below.

Cooling	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	7.5m

Conversion Formulae
kcal/h=kWx860 Btu/h=kWx3414 cfm=m³/minx35.3

1.2 Heat Pump

230V, 50Hz

Model	Indoor Units		FVXS25BVMB		FVXS35BVMB	
	Outdoor Units		RXS25BVMB		RXS35BVMB	
			Cooling	Heating	Cooling	Heating
Capacity Rated (Min.-Max.)	kW		2.5 (1.0-3.0)	3.4 (1.0-5.0)	3.5 (1.0-3.7)	4.5 (1.0-5.0)
	Btu/h		8,550 (3,400-10,250)	11,600 (3,400-17,050)	11,950 (3,400-12,600)	15,350 (3,400-17,050)
	kcal/h		2,150 (860-2,580)	2,920 (860-4,300)	3,010 (860-3,180)	3,870 (860-4,300)
Moisture Removal	L/h		1.2	—	1.9	—
Running Current (Rated)	A		3.7	4.3	5.5	6.0
Power Consumption Rated (Min.-Max.)	W		700 (240-925)	840 (240-1,430)	1,160 (240-1,300)	1,285 (240-1,830)
Power Factor (Min.-Max.)	%		82.3	84.9	91.7	93.1
COP	W/W		3.57	4.05	3.02	3.50
Piping Connections	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	φ 20.0		φ 20.0	
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Indoor Unit		FVXS25BVMB		FVXS35BVMB		
Front Panel Color		Almond White		Almond White		
Air Flow Rate	m³/min (cfm)	H	8.1 (286)	9.2 (325)	8.3 (293)	9.2 (325)
		M	6.2 (219)	7.0 (247)	6.3 (222)	7.1 (251)
		L	4.3 (152)	4.8 (169)	4.3 (152)	5.0 (177)
		SL	3.4 (120)	3.5 (124)	3.4 (120)	3.6 (127)
Fan	Type	Cross Flow Fan		Cross Flow Fan		
	Motor Output Upper/Lower	W	14/14		14/14	
	Speed	Steps	5 Steps, Silent and Auto		5 Steps, Silent and Auto	
Air Direction Control		Right, Left, Horizontal and Upward		Right, Left, Horizontal and Upward		
Air Filter		Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof		
Running Current (Rated)	A	0.14	0.14	0.14	0.14	
Power Consumption (Rated)	W	32	32	32	32	
Power Factor	%	99.4	99.4	99.4	99.4	
Temperature Control		Microcomputer Control		Microcomputer Control		
Dimensions (HxWxD)	mm	600x650x195		600x650x195		
Packaged Dimensions (WxDxH)	mm	770x294x714		770x294x714		
Weight	kg	13		13		
Gross Weight	kg	19		19		
Operation Sound	H/M/L/SL	dBA	38 / 32 / 26 / 23	38 / 32 / 26 / 23	39 / 33 / 27 / 24	39 / 34 / 29 / 26
Sound Power	H	dBA	54	—	55	—
Outdoor Unit		RXS25BVMB		RXS35BVMB		
Casing Color		Ivory White		Ivory White		
Compressor	Type	Hermetically Sealed Swing Type		Hermetically Sealed Swing Type		
	Model	1YC23GXD#A		1YC23GXD#A		
	Motor Output	W	600	600	600	
Refrigerant Oil	Model	FVC50K		FVC50K		
	Charge	L	0.4	0.4	0.4	
Refrigerant	Model	R410A		R410A		
	Charge	kg	0.96	1.06	1.06	
Air Flow Rate	m³/min (H/L)	25.3/17.0	22.8/15.3	25.3/17.0	22.8/15.3	
	cfm (H/L)	893/600	805/540	893/600	805/540	
Fan	Type	Propeller		Propeller		
	Motor Output	W	19	19	19	
Running Current (Rated)	A	3.56	4.16	5.36	5.86	
Power Consumption (Rated)	W	668	808	1,128	1,253	
Power Factor	%	81.6	84.4	91.5	93.0	
Starting Current	A	4.3		6.0		
Dimensions (HxWxD)	mm	560x695x265		560x695x265		
Packaged Dimensions (WxDxH)	mm	797x310x599		797x310x599		
Weight	kg	37		37		
Gross Weight	kg	40		40		
Operation Sound	H/L	dBA	46 / 43	47 / 44	47 / 44	48 / 45
Sound Power	H	dBA	59	—	60	—
Drawing No.			3D040172A		3D040173A	

Notes:

- MAX. interunit piping length: 20m
- MAX. interunit height difference: 15m
- Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
- The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae
kcal/h=kWx860 Btu/h=kWx3414 cfm=m³/minx35.3

Part 3

Printed Circuit Board

Connector Wiring Diagram

1. Printed Circuit Board Connector Wiring Diagram.....	8
1.1 FVKS 25/35 B, FVXS 25/35 B Series.....	8
1.2 RKS 25/35 BVMB, RXS 25/35 BVMB	10

1. Printed Circuit Board Connector Wiring Diagram

1.1 FVKS 25/35 B, FVXS 25/35 B Series

Name of Connector


- 1) **S6** Connector for swing motor and lower air outlet motor
- 2) **S23** Connector for signal receiver
- 3) **S31, S32** Connector for room temp / heat exchanger thermistor
- 4) **S201, S203, S7, S24, S26** Connector for control PCB (1)
- 5) **S202, S204, S8** Connector for control PCB (2)
- 6) **S25** Connector for display PCB (3)
- 7) **S301, S302** Connector for fan motors



Note: Other Designations


- 1) **V1** Varistor
- 2) **FU** FUSE
- 3) **LED11** LED for operation
- 4) **LED12** LED for timer
- 5) **LED14** LED for Home Leave Operation

Printed Circuit Board (1) (Power Supply PCB)



2P044051E

Printed Circuit Board (2) (Control PCB)
(3) (Display PCB)
(4) (Signal Receiver PCB)



2P088265C

1.2 RKS 25/35 BVMB, RXS 25/35 BVMB


Printed circuit board (1)

Printed circuit board (2)

Name of Connector

- 1) **S10** Connector for PCB (2)
- 2) **S11** Connector for PCB (1)
- 3) **S30** Connector for compressor motor
- 4) **S70** Connector for fan motor
- 5) **S80** Connector for four way valve coil (Heat pump only)
- 6) **S90** Connector for thermistor

Outline of PCB



Part 4

Function and Control

1. Main Functions.....	14
1.1 Frequency Principle.....	14
1.2 Flap Control.....	16
1.3 Air Flow Selection.....	17
1.4 Fan Speed Control for Indoor Units.....	18
1.5 Programme Dry Function	19
1.6 Automatic Operation.....	20
1.7 Night Set Mode.....	21
1.8 Home Leave Operation	22
1.9 Inverter Powerful Operation	23
1.10 Other Functions.....	24
2. Function of Main Structural Parts.....	26
2.1 Main Structural Parts.....	26
2.2 Function of Thermistor	27
3. Control Specification	29
3.1 Mode Hierarchy	29
3.2 Frequency Control.....	30
3.3 Controls at Mode Changing / Start-up.....	32
3.4 Discharge Pipe Control	33
3.5 Input Current Control.....	33
3.6 Freeze-up Protection Control	34
3.7 Heating Peak-cut Control	34
3.8 Fan Control.....	35
3.9 Moisture Protection Function 1 (Securing of Differential Pressure and Blown Air Temperature)	35
3.10 Moisture Protection Function 2.....	36
3.11 Defrost Control	37
3.12 Electronic Expansion Valve Control	38
3.13 Malfunctions	41
3.14 Forced Operation Mode	42
3.15 Additional Function.....	42

1. Main Functions

1.1 Frequency Principle

Main Control Parameters

The compressor is frequency-controlled during normal operation. The target frequency is set by the following 2 parameters coming from the operating indoor unit:

- The load condition of the operating indoor unit
- The difference between the room temperature and the set temperature

Additional Control Parameters

The target frequency is adapted by additional parameters in the following cases:

- Frequency restrictions
- Initial settings
- Forced cooling operation


Inverter Principle

To regulate the capacity, a frequency control is needed. The inverter makes it possible to vary the rotation speed of the compressor. The following table explains the conversion principle:

Phase	Description
1	The supplied AC power source is converted into the DC power source for the present.
2	The DC power source is reconverted into the three phase AC power source with variable frequency. <ul style="list-style-type: none"> ■ When the frequency increases, the rotation speed of the compressor increases resulting in an increased refrigerant circulation. This leads to a higher amount of the heat exchange per unit. ■ When the frequency decreases, the rotation speed of the compressor decreases resulting in a decreased refrigerant circulation. This leads to a lower amount of the heat exchange per unit.

Drawing of Inverter


The following drawing shows a schematic view of the inverter principle:



Inverter Features

The inverter provides the following features:

- The regulating capacity can be changed according to the changes in the outdoor air temperature and cooling / heating load.
- Quick heating and quick cooling
The compressor rotational speed is increased when starting the heating (or cooling). This enables a quick set temperature.



- Even during extreme cold weather, the high capacity is achieved. It is maintained even when the outdoor air temperature is 0°C.
- Comfortable air conditioning
A detailed adjustment is integrated to ensure a fixed room temperature. It is possible to air condition with a small room temperature variation.
- Energy saving heating and cooling
Once the set temperature is reached, the energy saving operation enables to maintain the room temperature at low power.

Frequency Limits

The following table shows the functions that define the minimum and maximum frequency:

Frequency limits	Limited during the activation of following functions
Low	<ul style="list-style-type: none"> ■ Four way valve operation compensation. Refer to page 32.
High	<ul style="list-style-type: none"> ■ Input current control. Refer to page 33. ■ Compressor protection function. Refer to page 32. ■ Heating peak-cut control. Refer to page 34. ■ Freeze-up protection. Refer to page 34. ■ Defrost control. Refer to page 37.

Forced Cooling Operation

For more information, refer to "Forced operation mode" on page 42.

1.2 Flap Control

Wide-angle Flap



The large flaps send a large volume of air all over the room. The flap provides an optimum control in cooling, heating and dry mode.

Louvres

The louvres, made of elastic synthetic resin, provide a wide range of airflow that guarantees a comfortable air distribution.

Auto-swing


The following table explains the auto-swing process for heating and cooling:

Item	Description	Drawing
heating	The flap swings up and down as shown in the drawing alongside.	 <p>(R1194)</p>
cooling / dry	The flap swings up and down as shown in the drawing alongside.	 <p>(R1195)</p>

1.3 Air Flow Selection

When setting the air flow selection switch to  .

- Air conditioner automatically decides the appropriate blowing pattern depending on the operating mode / situation.

Operating mode	Situation	Blowing pattern
Cool mode	<ul style="list-style-type: none"> ■ When the room has become fully cool, or when one hour has passed since turning on the air conditioner. 	<ul style="list-style-type: none"> ■ So that air does not come into direct contact with people, air is blown upper air outlet, room temperature is equalised.
	<ul style="list-style-type: none"> ■ At start of operation or other times when the room is not fully cooled. 	 <ul style="list-style-type: none"> ■ Air is blown from the upper and lower air outlets for high speed cooling during Cool mode, and for filling the room with warm air during Heat mode.
Heat mode	<ul style="list-style-type: none"> ■ At times other than below. (Normal time.) 	
	<ul style="list-style-type: none"> ■ At start or when air temperature is low. 	<ul style="list-style-type: none"> ■ So that air does not come into direct contact with people. Air is blown upper air outlet.

- During Dry mode, so that cold air does not come into direct contact with people, air is blown upper air outlet.

When setting the air outlet selection switch to  .

- Regardless of the operating mode or situation, air blows from the upper air outlet.
- Use this switch when you do not want air coming out of the lower air outlet. (While sleeping etc..)

1.4 Fan Speed Control for Indoor Units

Control Mode

The airflow rate can be automatically controlled depending on the difference between the set temperature and the room temperature. This is done through phase control and Hall IC control.



For more information about Hall IC, refer to trouble shooting for fan motor on page 77.

Phase Steps

Phase control and fan speed control contains 9 steps: LLL, LL, SL, L, ML, M, MH, H and HH.

Step	Cooling	Heating	Dry mode
LLL (Heating thermostat OFF)			FVK(X)S : 740 - 760 rpm (During powerful operation : 970 rpm)
LL (Cooling thermostat OFF)			
SL (Silent)			
L			
ML			
M			
MH			
H			
HH (Powerful)			

= Within this range the airflow rate is automatically controlled when the AIRFLOW ADJUSTING button is set to AUTOMATIC




Note:

1. During powerful operation, fan operate H tap + 50 - 90 rpm.
2. Fan stops during defrost operation.


Automatic Air Flow Control for Heating

The following drawing explains the principle for fan speed control for heating:



Automatic Air Flow Control for Cooling

The following drawing explains the principle of fan speed control for cooling:



1.5 Programme Dry Function


Programme dry function removes humidity while preventing the room temperature from lowering.

Since the microcomputer controls both the temperature and air flow volume, the temperature adjustment and fan adjustment buttons are inoperable in this mode.

In Case of Inverter Units

The microcomputer automatically sets the temperature and fan settings. The difference between the room temperature at startup and the temperature set by the microcomputer is divided into two zones. Then, the unit operates in the dry mode with an appropriate capacity for each zone to maintain the temperature and humidity at a comfortable level.

Room temperature at startup	Temperature (ON point) at which operation starts	Frequency switching point	Temperature difference for operation stop
24°C	Room temperature at startup	0.5°C	1.5°C
18°C	18°C		1.0°C
17°C		—	



LHz indicates low frequency. Item marked with varies depending on models.

(R1359)

1.6 Automatic Operation


Automatic Cooling / Heating Function (Heat Pump Only)

When the AUTO mode is selected with the remote controller, the microcomputer automatically determines the operation mode from cooling and heating according to the room temperature and setting temperature at the time of the operation startup, and automatically operates in that mode.

The unit automatically switches the operation mode to cooling or heating to maintain the room temperature at the main unit setting temperature.

Detailed Explanation of the Function

1. Remote controller setting temperature is set as automatic cooling / heating setting temperature (18 to 30°C).
2. Main unit setting temperature equals remote controller setting temperature plus correction value (correction value / cooling: 0 deg, heating: 2 deg.).
3. Operation ON / OFF point and mode switching point are as follows.
 - ① Heating → Cooling switching point:
Room temperature \geq Main unit setting temperature +2.5 deg.
 - ② Cooling → Heating switching point:
Room temperature $<$ Main unit setting temperature -2.5 deg.
 - ③ Thermostat ON / OFF point is the same as the ON / OFF point of cooling or heating operation.
4. During initial operation
 Room temperature \geq Remote controller setting temperature: Cooling operation
 Room temperature $<$ Remote controller setting temperature: Heating operation



(R1360)


1.7 Night Set Mode

When the OFF timer is set, the Night Set circuit automatically activates. The Night Set circuit maintains the airflow setting made by users.

The Night Set Circuit

The Night Set circuit continues heating or cooling the room at the set temperature for the first one hour, then automatically lowers the temperature setting slightly in the case of cooling, or raises it slightly in the case of heating, for economical operations. This prevents excessive heating in winter and excessive cooling in summer to ensure comfortable sleeping conditions, and also conserves electricity.


Cooling Operation



- Ⓐ : ● When outside temperature is normal and room temperature is at set temperature.
- Ⓑ : ● When outside temperature is high (27°C or higher).

(R1361)

Heating Operation



(R1362)

1.8 Home Leave Operation

Outline

In order to respond to the customer's need for immediate heating and cooling of the room after returning home or for house care, a measure to switch the temperature and air volume from that for normal time over to outing time by one touch is provided. (This function responds also to the need for keeping up with weak cooling or heating.)

This time, we seek for simplicity of operation by providing the special temperature and air volume control for outing to be set by the exclusive button.

Detail of the Control

1. Start of Function

The function starts when the [HOME LEAVE] button is pressed in cooling mode or heating mode (including stopping and powerful operation). If this button is pressed while the operation is stopped, the function becomes effective when the operation is started. If this button is pressed in powerful operation, the powerful operation is reset and this function becomes effective.

- The [HOME LEAVE] button is ineffective in dry mode and fan mode.

2. Details of Function

A mark representing [HOME LEAVE] is indicated on the liquid crystal display of the remote controller. The indoor unit is operated according to the set temperature and air volume for HOME LEAVE which were pre-set in the memory of the remote controller.

The LED (Red) of indoor unit representing [HOME LEAVE] lights up. (It goes out when the operation is stopped.)


3. End of Function

The function ends when the [HOME LEAVE] button is pressed again during [HOME LEAVE] operation or when the powerful operation button is pressed.

Scene <cooling>



Scene <Heating>



Others

The set temperature and set air volume are memorized in the remote controller. When the remote controller is reset due to replacement of battery, it is necessary to set the temperature and air volume again for [HOME LEAVE].

1.9 Inverter Powerful Operation

Outline


In order to exploit the cooling and heating capacity to full extent, operate the air conditioner by increasing the indoor fan rotating speed and the compressor frequency.

Details of the Control

When Powerful button is pushed in each operation mode, the fan speed / setting temperature will be converted to the following states in a period of twenty minutes.

Operation mode	Fan speed	Target set temperature
Cooling	H tap + 70 rpm	18°C
Dry	Dry rotating speed + 50 rpm	Normally targeted temperature in dry operation; Approx. - 2°C
Heating	H tap + 80 rpm	30°C
Fan	H tap + 70 rpm	—
Automatic	Same as cooling / heating in Powerful operation	The target is kept unchanged

Ex.) : Powerful operation in cooling mode.



(R2823)

1.10 Other Functions

1.10.1 Hot Start Function

Heat Pump Only

In order to prevent the cold air blast that normally comes when heating is started, the temperature of the heat exchanger of the indoor unit is detected, and either the air flow is stopped or is made very weak thereby carrying out comfortable heating of the room.

*The cold air blast is also prevented using a similar control when the defrosting operation is started or when the thermostat gets turned ON.


1.10.2 Signal Receiving Sign

When the indoor unit receives a signal from the remote controller, the unit emits a signal receiving sound.

1.10.3 ON/OFF Button on Indoor Unit

An ON/OFF switch is provided on the front panel of the unit. Use this switch when the remote controller is missing or if its battery has run out.

Every press of the switch changes from Operation to Stop or from Stop to Operation



(R3052)

- Push this button once to start operation. Push once again to stop it.
- This button is useful when the remote controller is missing.
- The operation mode refers to the following table.

	Mode	Temperature setting	Air flow rate
Cooling Only	COOL	22°C	AUTO
Heat Pump	AUTO	25°C	AUTO

- In the case of multi system operation, there are times when the unit does not activate with this button.

1.10.4 Photocatalytic Deodorizing Filter

Photocatalytic Deodorizing Filter demonstrates powerful oxidation characteristics when subjected to harmless ultraviolet light. Photocatalytic deodorizing power is recovered simply by exposing the filter to the sun for 6 hours once every 6 months.

1.10.5 Air-Purifying Filter

A double structure made up of a bacteriostatic filter and an Air-Purifying Filter traps dust, mildew, mites, tobacco smoke, and allergy-causing pollen. Replace the Air-Purifying Filter once every 3 months.

1.10.6 Mold Proof Air Filter

The filter net is treated with mold resisting agent TBZ (harmless, colorless, and odorless). Due to this treatment, the amount of mold growth is much smaller than that of normal filters.

1.10.7 Self-Diagnosis Digital Display

The microcomputer continuously monitors main operating conditions of the indoor unit, outdoor unit and the entire system. When an abnormality occurs, the LCD remote controller displays error code. These indications allow prompt maintenance operations.


1.10.8 Auto-restart Function

Even if a power failure (including one for just a moment) occurs during the operation, the operation restarts in the condition before power failure automatically when power is restored. (Note) It takes 3 minutes to restart the operation because the 3-minute standby function is activated.


2. Function of Main Structural Parts

2.1 Main Structural Parts

Heat Pump Model




Cooling Only Model



2.2 Function of Thermistor

2.2.1 Heat Pump Model



A Outdoor Heat Exchanger Thermistor (DCB)

1. The outdoor heat exchanger thermistor is used for controlling target discharge temperature. Set a target discharge temperature depending on the outdoor and indoor heat exchanger temperature. Control the electronic expansion valve opening so that the target discharge temperature can be obtained.
2. The outdoor heat exchanger thermistor is used for detecting the discharge thermistor disconnected when cooling. When the temperature of the discharge piping is lower than the temperature of outdoor heat exchanger, a disconnected discharge thermistor can be detected.
3. The outdoor heat exchanger thermistor is used for high pressure protection during cooling operation.


B Discharge Pipe Thermistor (DOT)

1. The discharge pipe thermistor is used to control the discharge pipe. If the temperature of discharge pipe (used in place of the inner temperature of the compressor) rises abnormally, the operating frequency drops or the operation must be halted.
2. The discharge pipe thermistor is used for detecting the discharge thermistor disconnected.

C Indoor Heat Exchanger Thermistor (DCN)

1. The indoor heat exchanger thermistor is used for controlling target discharge pipe temperature. Set a target discharge pipe temperature according to the outdoor and indoor heat exchanger temperature. Control the electronic expansion valve so that the target discharge pipe temperature can be obtained.
2. The indoor heat exchanger thermistor is used to prevent freezing. During the cooling operation, if the temperature drops abnormally, the operating frequency becomes lower, then the operation must be halted.
3. The indoor heat exchanger thermistor is used for anti-icing control. During the cooling operation, if the heat exchanger temperature in the room where operation is halted becomes -1°C , it is assumed as icing.
4. During heating: the indoor heat exchanger thermistor is used for detecting the discharge pipe thermistor disconnected. When the discharge pipe temperature become lower than an indoor heat exchanger temperature, a disconnected discharge pipe thermistor can be detected.

2.2.2 Cooling Only Model



A Outdoor Heat Exchanger Thermistor (DCB)

1. The outdoor heat exchanger thermistor is used for controlling target discharge temperature. Set a target discharge temperature depending on the outdoor and indoor heat exchanger temperature. Control the electronic expansion valve opening so that the target discharge temperature can be obtained.
2. When cooling: an outdoor heat exchanger thermistor is used for detecting the discharge thermistor disconnected. When the temperature of the discharge piping is lower than the temperature of outdoor heat exchanger, a disconnected discharge thermistor can be detected.
3. The outdoor heat exchanger thermistor is used for high pressure protection during cooling operation.

B Discharge Pipe Thermistor (DOT)

1. The discharge pipe thermistor is used to control the discharge pipe. If the temperature of discharge pipe (used in place of the inner temperature of the compressor) rises abnormally, the operating frequency drops or the operation must be halted.
2. The discharge pipe thermistor is used for detecting the discharge thermistor disconnected.

C Indoor Heat Exchanger Thermistor (DCN)

1. The indoor heat exchanger thermistor is used for controlling target discharge pipe temperature. Set a target discharge pipe temperature according to the outdoor and indoor heat exchanger temperature. Control the electronic expansion valve opening so that the target discharge pipe temperature can be obtained.
2. The indoor heat exchanger thermistor is used to prevent freezing. During the cooling operation, if the temperature drops abnormally, the operating frequency becomes lower, then the operation must be halted.
3. The indoor heat exchanger thermistor is used for anti-icing control. During the cooling operation, if the heat exchanger temperature in the room where operation is halted becomes -1°C , it is assumed as icing.

3. Control Specification

3.1 Mode Hierarchy


Outline

There are two modes; the mode selected in user's place (normal air conditioning mode) and forced operation mode for installation and providing service.

Detail

1. For heat pump model


There are following modes; stop, cooling (includes drying), heating (include defrosting)



(R2829)

2. For cooling only model

There are following models; stop and cooling (including drying).



(R2830)




Note: Unless specified otherwise, an indoor dry operation command must be regarded as cooling operation.

3.2 Frequency Control

Outline

Frequency will be determined according to the difference between room and set temperature. The function is explained as follows.

1. How to determine frequency.
2. Frequency command from an indoor unit. (The difference between a room temperature and the temperature set by the remote controller.)
3. Frequency command from an indoor unit.
4. Frequency initial setting.
5. PI control.



(R2831)

Detail

How to Determine Frequency

The compressor's frequency will finally be determined by taking the following steps.

For Heat Pump Model

1. Determine command frequency
 - Command frequency will be determined in the following order of priority.
 - 1.1 Limiting frequency by drooping function
 - Input current, discharge pipes, low Hz high pressure limit, peak cutting, freeze prevention, dew prevention, fin thermistor temperature.
 - 1.2 Limiting defrost control time
 - 1.3 Forced cooling
 - 1.4 Indoor frequency command
2. Determine upper limit frequency
 - Set a minimum value as an upper limit frequency among the frequency upper limits of the following functions:
 - Compressor protection, input current, discharge pipes, Low Hz high pressure, peak cutting, freeze-up protection, defrost.
3. Determine lower limit frequency
 - Set a maximum value as an lower limit frequency among the frequency lower limits of the following functions:
 - Four way valve operating compensation, draft prevention, pressure difference upkeep.
4. Determine prohibited frequency
 - There is a certain prohibited frequency such as a power supply frequency.

For Cooling Only Model

1. Determine command frequency
 - Command frequency will be determined in the following order of priority.
 - 1.1 Limiting frequency by drooping function
 - Input current, discharge pipes, freeze-up protection, dew prevention, fin thermistor temperature.
 - 1.2 Indoor frequency command
2. Determine upper limit frequency
 - Set a minimum value as an upper limit frequency among the frequency upper limits of the following functions:
 - Compressor protection, input current, discharge pipes, freeze-up protection, dew prevention, fin thermistor temperature.

3. Determine lower limit frequency
 - Set a maximum value as an lower limit frequency among the frequency lower limits of the following functions:
Pressure difference upkeep.
4. Determine prohibited frequency
 - There is a certain prohibited frequency such as a power supply frequency.

Indoor Frequency Command (ΔD signal)

The difference between a room temperature and the temperature set by the remote controller will be taken as the " ΔD signal" and is used for frequency command.

Temperature difference	ΔD signal						
0	*Th OFF	2.0	4	4.0	8	6.0	C
0.5	1	2.5	5	4.5	9	6.5	D
1.0	2	3.0	6	5.0	A	7.0	E
1.5	3	3.5	7	5.5	B	7.5	F

*Th OFF = Thermostat OFF

Frequency Initial Setting

■ Outline

When starting the compressor, or when conditions are varied due to the change of the room, the frequency must be initialized according to the ΔD value of the indoor unit and the Q value of the indoor unit.

Q value: Indoor unit output determined from indoor unit volume, air flow rate and other factors.

PI Control (Determine Frequency Up / Down by ΔD Signal)

1. P control
Calculate ΔD value in each sampling time (20 seconds), and adjust the frequency according to its difference from the frequency previously calculated.
2. I control
If the operating frequency is not change more than a certain fixed time, adjust the frequency up and down according to the ΔD value, obtaining the fixed ΔD value.
When the ΔD value is small...lower the frequency.
When the ΔD value is large...increase the frequency.
3. Limit of frequency variation width
When the difference between input current and input current drooping value is less than 1.5 A, the frequency increase width must be limited.
4. Frequency management when other controls are functioning
 - When frequency is drooping;
Frequency management is carried out only when the frequency droops.
 - For limiting lower limit
Frequency management is carried out only when the frequency rises.
5. Upper and lower limit of frequency by PI control
The frequency upper and lower limits are set depending on indoor unit.
When low noise commands come from the indoor unit or when outdoor unit low noise or quiet commands come from indoor unit, the upper limit frequency must be lowered than the usual setting.

3.3 Controls at Mode Changing / Start-up

3.3.1 Preheating Operation

Outline Operate the inverter in the open phase operation with the conditions including the preheating command (only for heat pump model) from the indoor, the outdoor air temperature and discharge pipe temperature.

Detail

Preheating ON Condition

- When outdoor air temperature is below 10.5°C and discharge pipe temperature is below 10.5°C, inverter in open phase operation starts.

OFF Condition

- When outdoor air temperature is higher than 12°C or discharge pipe temperature is higher than 12°C, inverter in open phase operation stops.

3.3.2 Four Way Valve Switching

Outline of Heating Operation

Heat Pump Only

During the heating operation current must not be conducted and during cooling and defrosting current must be conducted. In order to eliminate the switching sound (as the four way valve coil switches from ON to OFF) when the cooling is stopped, the delay switch of the four way valve must be carried out after the operation stopped.

Detail

The OFF delay of four way valve
Energize the coil for 150 sec after unit operation is stopped.

3.3.3 Four Way Valve Operation Compensation

Outline

Heat Pump Only

At the beginning of the operation as the four way valve is switched, acquire the differential pressure required for activating the four way valve by having output the operating frequency, which is more than a certain fixed frequency, for a certain fixed time.

Detail

Starting Conditions

1. When starting compressor for cooling.
2. When the operating mode changes from the previous time.
3. When starting compressor for rushing defrosting or resetting.
4. When starting compressor for the first time after the reset with the power is ON.
Set the lower limit frequency to 66 (model by model) Hz for 45 seconds with the OR conditions with 1 through 4 above.


3.3.4 3 Minutes Stand-by

Prohibit to turn ON the compressor for 3 minutes after turning it off.
(Except when defrosting. (Only for Heat Pump Model).)

3.3.5 Compressor Protection Function

When turning the compressor from OFF to ON, the upper limit of frequency must be set as follows. (The function must not be used when defrosting (only for heat pump model).)

FCG 3	94
FCG 2	96
FCG 1	50
TCG 1	240
TCG 2	240
TCG 3	120




3.4 Discharge Pipe Control

Outline

The discharge pipe temperature is used as the compressor's internal temperature. If the discharge pipe temperature rises above a certain level, the operating frequency upper limit is set to keep this temperature from going up further.

Detail

Divide the Zone



Management within the Zones

Zone	Control contents
Stop zone	When the temperature reaches the stop zone, stop the compressor and correct abnormality.
Drooping zone	Start the timer, and the frequency will be drooping.
Unchanged zone	Keep the upper limit of frequency.
Return / Reset zone	Cancel the upper limit of frequency.


3.5 Input Current Control

Outline

Detect an input current by the CT during the compressor is running, and set the frequency upper limit from such input current. In case of heat pump model, this control is the upper limit control function of the frequency which takes priority of the lower limit of four way valve activating compensation.

Detail

The frequency control will be made within the following zones.



When a “stop current” continues for 2.5 seconds after rushing on the stop zone, the compressor operation stops.

If a “drooping current” is continues for 1.0 second after rushing on the drooping zone, the frequency will be 2 Hz drooping.

Repeating the above drooping continues until the current rushes on the drooping zone without change.

In the unchanged zone, the frequency limit will remain.

In the return / reset zone, the frequency limit will be cancelled.

Limitation of current drooping and stop value according to the outdoor air temperature


1. In case the operation mode is cooling
 - The current droops when outdoor air temperature becomes higher than a certain level (model by model).
2. In case the operation mode is heating (only for heat pump model)
 - The current droops when outdoor air temperature becomes higher than a certain level (model by model).

3.6 Freeze-up Protection Control

Outline During cooling operation, the signals being sent from the indoor unit allow the operating frequency limitation and then prevent freezing of the indoor heat exchanger. (The signal from the indoor unit must be divided into the zones as the followings.)

Detail **Conditions for Start Controlling**
Judge the controlling start with the indoor heat exchanger temperature after 2 sec from operation start.

Control in Each Zone




3.7 Heating Peak-cut Control

Outline **Heat Pump Only**
During heating operation, the signals being sent from the indoor unit allow the operating frequency limitation and prevent abnormal high pressure. (The signal from the indoor unit must be divided as follows.)

Detail **Conditions for Start Controlling**
Judge the controlling start with the indoor heat exchanger temperature after 2 min from operation start.

Control in Each Zone

The heat exchange intermediate temperature of indoor unit controls the following.



3.8 Fan Control

Outline	<p>Fan control is carried out according to the following priority.</p> <ol style="list-style-type: none"> 1. Fan ON control for electric component cooling fan 2. Fan control when defrosting 3. Fan OFF delay when stopped 4. ON/OFF control when cooling operation 5. Tap control when drooping function is working 6. Fan control when forced operation 7. Fan control in low noise mode 8. Fan control during heating operation 9. Fan control in the quiet mode 10. Fan control in the powerful mode 11. Fan control for pressure difference upkeep
----------------	---

Detail	<p>Fan OFF Control when Stopped</p> <ul style="list-style-type: none"> ■ Fan OFF delay for 60 seconds must be made when the compressor is stopped.
---------------	--


3.9 Moisture Protection Function 1 (Securing of Differential Pressure and Blown Air Temperature)

Outline	<p>To secure the reliability of the compressor (for dryness of suction refrigerant and differential pressure) which is the primary purpose of the compressor, the lower limit of the output frequency is limited to two stages under the condition of outside air temperature. This time, in addition to this purpose, this function is adopted also for prevention of cold draught by securing the blown air temperature at the time of heating operation by low-temperature outside air.</p>
----------------	--

Processing	<p>1. At the first step</p> <ol style="list-style-type: none"> ① During operation of compressors. ② Outdoor temperature \leq DOA1CG <ul style="list-style-type: none"> ■ If ① and ② are under the simultaneous condition with AND, the lower limit of frequency in this function is set at FCG7. ③ Compressors stop. ④ Outdoor temperature \geq DOA2CG <ul style="list-style-type: none"> ■ If ③ and ④ are under the simultaneous condition with OR, the lower limit of frequency at the first step control is cancelled. <p>2. At the second step</p> <ol style="list-style-type: none"> ① During operation of compressors ② Outdoor temperature \leq DOA3CG <ul style="list-style-type: none"> ■ If ① and ② are under the simultaneous condition with AND, the lower limit of frequency in this function is set at FCG8. ③ Compressors stop. ④ Outdoor temperature \geq DOA4CG <ul style="list-style-type: none"> ■ If ③ and ④ are under the coordinate condition with OR, the lower limit of frequency at the second step control is cancelled.
-------------------	--

3. The set of a constant

DOA1CG, DOA2CG, DOA3CG, FCG7 and FCG8 have constants for Cooling / Heating separately and these constants are distinguished with a suffix c/w.



4. Actual constant

Cooling	FVK(X)S series	Heating	FVXS series
DOA1CGC	18°C	DOA1CGW	0°C
DOA2CGC	19°C	DOA2CGW	2°C
DOA3CGC	0°C	DOA3CGW	-4°C
DOA4CGC	1°C	DOA4CGW	-2°C
FCG7C	44 Hz	FCG7W	37 Hz
FCG8C	54 Hz	FCG8W	52 Hz

- * DOA : Outdoor air temperature
- CGC : Compressor guard for cooling
- CGW : Compressor guard for heating
- FCG : Frequency guard for compressor protection
- * Common setting for 25/35 class

3.10 Moisture Protection Function 2

Outline

In order to obtain the dependability of the compressor, the compressor must be stopped according to the conditions of the temperature of the outdoor air and outdoor heat exchanger.

Detail

- Operation stop depending on the outdoor air temperature
Compressor operation turns OFF under the conditions that the system is in cooling operation and outdoor air temperature is below -10°C.

3.11 Defrost Control

Outline

Heat Pump Only

Defrosting is carried out by the cooling cycle (reverse cycle). The defrosting time or outdoor heat exchanger temperature must be more than its fixed value when finishing.


Detail

Conditions for Starting Defrost

The starting conditions must be made with the outdoor air temperature and heat exchanger temperature. Under the conditions that the system is in heating operation, 6 minutes after the compressor is started and more than 44 minutes of accumulated time pass since the start of the operation or ending the defrosting.

Conditions for Canceling Defrost

The judgment must be made with heat exchanger temperature. (4°C~22°C)



(R2945)

3.12 Electronic Expansion Valve Control

Outline

The following items are included in the electronic expansion valve control.

Electronic expansion valve is fully closed

1. Electronic expansion valve is fully closed when turning on the power.
2. Pressure equalizing control

Open Control

1. Electronic expansion valve control when starting operation
2. Control when frequency changed
3. Control for defrosting (only for heat pump model)
4. Control when a discharge pipe temperature is abnormally high
5. Control when the discharge pipe thermistor is disconnected

Feedback Control

1. Discharge pipe temperature control

Detail

The followings are the examples of control which function in each mode by the electronic expansion valve control.

Operation pattern		Control when frequency changed	Control for abnormally high discharge pipe temperature	
When power is turned ON	○ : function × : not function			
↓		Fully closed when power is turned ON	×	×
Cooling operation		Open control when starting	×	○
↓		(Control of target discharge pipe temperature)	○	○
Stop		Pressure equalizing control	×	×
Heating operation (only for heat pump model)		Open control when starting	×	○
↓		(Control of target discharge pipe temperature)	○	○
Stop		(Defrost control FD=1) (only for heat pump model)	×	×
Heating operation (only for heat pump model)		Pressure equalizing control	×	×
↓		Open control when starting	×	○
Control of discharge pipe thermistor disconnection		Continue	×	×
↓		Pressure equalizing control	×	×
Stop				

(R2833)

3.12.1 Fully Closing with Power ON

Initialize the electronic expansion valve when turning on the power, set the opening position and develop pressure equalizing.

3.12.2 Pressure Equalization Control

When the compressor is stopped, open and close the electronic expansion valve and develop pressure equalization.

3.12.3 Opening Limit

Outline

Limit a maximum and minimum opening of the electronic expansion valve.

Detail

- A maximum electronic expansion valve opening : 55 pulses
 - A minimum electronic expansion valve opening : 4 pulses
- The electronic expansion valve is fully closed in the room where cooling is stopped and is opened with fixed opening during defrosting.

3.12.4 Starting Operation Control

Control the electronic expansion valve opening when the system is starting, and prevent the system to be super heated or moistened.

3.12.5 High Temperature of the Discharge Pipe

When the compressor is operating, if the discharge pipe temperature exceeds a certain value, open the electronic expansion valve and remove the refrigerant to the low pressure side and lower discharge temperature.

3.12.6 Disconnection of the Discharge Pipe Thermistor

Outline

Detect a disconnected discharge pipe thermistor by comparing the discharge pipe temperature with the condensation temperature. If any is disconnected, open the electronic expansion valve according to the outdoor air temperature and the operating frequency and operate for a specified time, and then stop.

After 3 minutes of waiting, restart the unit and check if any is disconnected. If any is disconnected stop the system after operating for a specified time. If the disconnection is detected 4 times in succession, then the system will be down.

Detail

Detect Disconnection

If a 570-second timer for open control becomes over, and a 9-minute timer for the compressor operation continuation is not counting time, the following adjustment must be made.

1. When the operation mode is cooling
 - When the discharge pipe temperature is lower than the outdoor heat exchanger temperature, the discharge pipe thermistor disconnection must be ascertained.
2. When the operation mode is heating (only for heat pump model)
 - When the discharge pipe temperature is lower than the max temperature of indoor unit heat exchanger, the discharge pipe thermistor disconnection must be ascertained.

Adjustment when the thermistor is disconnected


When compressor stop repeats specified time, the system should be down.

3.12.7 Control when frequency is changed

When the target discharge pipe temperature control is active, if the target frequency is changed for a specified value in a certain time period, cancel the target discharge pipe temperature control and change the target opening of the electronic expansion valve according to the shift.

3.12.8 Target Discharge Pipe Temperature Control

Obtain the target discharge pipe temperature from the indoor and outdoor heat exchanger temperature, and adjust the electronic expansion valve opening so that the actual discharge pipe temperature become close to that temperature. (Indirect SH control using the discharge pipe temperature)



(R1389)

Determine a correction value of the electronic expansion valve compensation and drive it according to the deflection of the target discharge temperature and actual discharge temperature, and the discharge temperature variation by the 20 sec.

3.13 Malfunctions

3.13.1 Sensor Malfunction Detection

Sensor malfunction may occur either in the thermistor or current transformer (CT) system.

Relating to Thermistor Malfunction

1. Outdoor heat exchanger thermistor
2. Discharge pipe thermistor
3. Fin thermistor
4. Outdoor air thermistor

Relating to CT Malfunction

When the output frequency is more than 62 Hz and the input current is less than 0.5A, carry out abnormal adjustment.

3.13.2 Detection of Over Load and Over Current

Outline

In order to protect the inverter, detect an excessive output current, and for protecting compressor, monitor the OL operation.

Detail


- If the OL (compressor head) temperature exceeds 120~130°C (depending on the model), the compressor gets interrupted.
- If the inverter current exceeds 22 A, the compressor gets interrupted too.

3.13.3 Insufficient Gas Control


Outline

If a power consumption is below the specified value in which the frequency is higher than the specified frequency, it must be regarded as gas insufficient.

In addition to such conventional function, if the discharge temperature is higher than the target discharge pipe temperature, and the electronic expansion valve is fully open (55 pulses) more than the specified time, it is considered as an insufficient gas.



With the conventional function, a power consumption is weak comparing with that in the normal operation when gas is insufficient, and gas insufficiency is detected by checking a power consumption.



When operating with insufficient gas, although the rise of discharge pipe temperature is great and the electronic expansion valve is open, it is presumed as an insufficient gas if the discharge pipe temperature is higher than the target discharge pipe temperature.

Detail

Judgment by Input Current

When an output frequency is exceeds 65 Hz and the input current is less than specified value, the adjustment is made for insufficient gas.

Judgment by Discharge Pipe Temperature

When discharge pipe temperature is 30°C higher than target value and the electronic expansion valve opening is 55 plus (max.), the adjustment is made for insufficient gas.

3.14 Forced Operation Mode

Outline Forced operating mode includes only forced cooling.

Detail

Forced Cooling

Item	Forced Cooling
Forced operation allowing conditions	1) The outdoor unit is not abnormal and not in the 3-minute stand-by mode.
	2) The operating mode of the outdoor unit is the stop mode.
	3) The forced operation is ON. The forced operation is allowed when the above "and" conditions are met.
Starting/adjustment	If the forced operation switch is pressed as the above conditions are met.
1) Command frequency	■ 66 Hz
2) Electronic expansion valve opening	■ Depending on the capacity of the indoor unit.
3) Outdoor unit adjustment	■ Compressor is in operation
4) Indoor unit adjustment	■ Transmit the command of forced draft to the indoor unit.
End	1) When the forced operation switch is pressed again.
	2) The operation is to end automatically after 15 min.
Others	The protect functions are prior to all others in the forced operation.

3.15 Additional Function

3.15.1 Powerful Operation Mode

Compressor operating frequency is increased to P1 Max. (Max. Hz of operating room) and outdoor unit airflow rate is increased.

3.15.2 Voltage Detection Function

Power supply voltage is detected each time equipment operation starts.

Part 5

System Configuration

1. System Configuration.....	44
1.1 Operation Instructions	44
2. Instruction.....	45
2.1 Safety Precautions	45
2.2 Names of Parts.....	47
2.3 Preparation before Operation.....	50
2.4 AUTO-DRY·COOL-HEAT·FAN Operation	53
2.5 Adjusting the Air Flow Direction	55
2.6 POWERFUL Operation	57
2.7 Outdoor Unit Silent Operation	58
2.8 HOME LEAVE Operation	59
2.9 TIMER Operation	61
2.10 Care and Cleaning	63
2.11 Trouble shooting.....	66

1. System Configuration

1.1 Operation Instructions

After the installation and test operation of the room air conditioner have been completed, it should be operated and handled as described below. Every user would like to know the correct method of operation of the room air conditioner, to check if it is capable of cooling (or heating) well, and to know a clever method of using it.

In order to meet this expectation of the users, giving sufficient explanations taking enough time can be said to reduce about 80% of the requests for servicing. However good the installation work is and however good the functions are, the customer may blame either the room air conditioner or its installation work because of improper handling. The installation work and handing over of the unit can only be considered to have been completed when its handling has been explained to the user without using technical terms but giving full knowledge of the equipment.

2. Instruction

2.1 Safety Precautions

Safety precautions

- Keep this manual where the operator can easily find them.
- Read this manual attentively before starting up the unit.
- For safety reason the operator must read the following cautions carefully.
- This manual classifies precautions into WARNINGS and CAUTIONS. Be sure to follow all precautions below: they are all important for ensuring safety.

WARNING

If you do not follow these instructions exactly, the unit may cause property damage, personal injury or loss of life.

CAUTION

If you do not follow these instructions exactly, the unit may cause minor or moderate property damage or personal injury.



Never do.



Be sure to follow the instructions.



Be sure to earth the air conditioner.



Never cause the air conditioner (including the remote controller) to get wet.



Never touch the air conditioner (including the remote controller) with a wet hand.



WARNING

- In order to avoid fire, explosion or injury, do not operate the unit when harmful, among which flammable or corrosive gases, are detected near the unit. 
- It is not good for health to expose your body to the air flow for a long time.
- Do not put a finger, a rod or other objects into the air outlet or inlet. As the fan is rotating at a high speed, it will cause injury.
- Do not attempt to repair, relocate, modify or reinstall the air conditioner by yourself. Incorrect work will cause electric shocks, fire etc.
For repairs and reinstallation, consult your Daikin dealer for advice and information.

- The refrigerant used in the air conditioner is safe. Although leaks should not occur, if for some reason any refrigerant happens to leak into the room, make sure it does not come in contact with any flame as of gas heaters, kerosene heaters or gas range. 
- If the air conditioner is not cooling (heating) properly, the refrigerant may be leaking, so call your dealer. When carrying out repairs accompanying adding refrigerant, check the content of the repairs with our service staff.
- Do not attempt to install the air conditioner by your self. Incorrect work will result in water leakage, electric shocks or fire. For installation, consult the dealer or a qualified technician.
- In order to avoid electric shock, fire or injury, if you detect any abnormally such as smell of fire, stop the operation and turn off the breaker. And call your dealer for instructions.



CAUTION

- The air conditioner must be earthed. Incomplete earthing may result in electric shocks. Do not connect the earth line to a gas pipe, water pipe, lightning rod, or a telephone earth line. 
- In order to avoid any quality deterioration, do not use the unit for cooling precision instruments, food, plants, animals or works of art. 
- Never expose little children, plants or animals directly to the air flow.
- Do not place appliances which produce open fire in places exposed to the air flow from the unit or under the indoor unit. It may cause incomplete combustion or deformation of the unit due to the heat.
- Do not block air inlets nor outlets. Impaired air flow may result in insufficient performance or trouble.

- Do not stand or sit on the outdoor unit. Do not place any object on the unit to avoid injury, do not remove the fan guard.
- Do not place anything under the indoor or outdoor unit that must be kept away from moisture. In certain conditions, moisture in the air may condense and drip.
- After a long use, check the unit stand and fittings for damage.
- Do not touch the air inlet and aluminum fins of outdoor unit. It may cause injury.
- The appliance is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with the appliance.

- To avoid oxygen deficiency, ventilate the room sufficiently if equipment with burner is used together with the air conditioner.
- Before cleaning, be sure to stop the operation, turn the breaker off or pull out the supply cord.
- Do not connect the air conditioner to a power supply different from the one as specified. It may cause trouble or fire.
- Depending on the environment, an earth leakage breaker must be installed. Lack of an earth leakage breaker may result in electric shocks.
- Arrange the drain hose to ensure smooth drainage. Incomplete draining may cause wetting of the building, furniture etc.



- Do not operate the air conditioner with wet hands.



- Do not wash the indoor unit with excessive water, only use a slightly wet cloth.
- Do not place things such as vessels containing water or anything else on top of the unit. Water may penetrate into the unit and degrade electrical insulations, resulting in an electric shock.



Installation site

- To install the air conditioner in the following types of environments, consult the dealer.
 - Places with an oily ambient or where steam or soot occurs.
 - Salty environment such as coastal areas.
 - Places where sulfide gas occurs such as hot springs.
 - Places where snow may block the outdoor unit.

The drain from the outdoor unit must be discharged to a place of good drainage.

Consider nuisance to your neighbours from noises

- For installation, choose a place as described below.
 - A place solid enough to bear the weight of the unit which does not amplify the operation noise or vibration.
 - A place from where the air discharged from the outdoor unit or the operation noise will not annoy your neighbours.

Electrical work

- For power supply, be sure to use a separate power circuit dedicated to the air conditioner.


System relocation

- Relocating the air conditioner requires specialized knowledge and skills. Please consult the dealer if relocation is necessary for moving or remodeling

2.2 Names of Parts


Names of parts

Indoor Unit



Opening the front grille


How to open the grille: (page 22)



CAUTION

Before opening the front grille, be sure to stop the operation and turn the breaker OFF. Do not touch the metal parts on the inside of the indoor unit, as it may result in injury.

■ Outdoor Unit



■ Indoor Unit

1. Photocatalytic deodorizing filter and Air purifying filter:

- These filters are attached to the inside of the air filters.

2. Air outlet

3. Display

4. Front grille

5. Louvres (vertical blades): (page 12.)

- The louvres are inside of the air outlet.

6. Air inlet

7. Air filter

8. Flap (horizontal blade): (page 12.)

9. Operation lamp (green)

10. TIMER lamp (yellow): (page 18.)

11. HOME LEAVE lamp (red): (page 16.)

12. Indoor Unit ON/OFF switch:

- Push this switch once to start operation. Push once again to stop it.

- The operation mode refers to the following table.

	Mode	Temperature setting	Air flow rate
FVKS	COOL	22°C	AUTO
FVXS	AUTO	25°C	AUTO

- This switch is useful when the remote controller is missing.

13. Signal receiver:

- Signals are received from the remote controller .
- When the unit receives a signal, you will hear a short beep.
 - Operation startbeep-beep
 - Settings changedbeep
 - Operation stopbeeeeeep

14. Air outlet selection switch

15. Room temperature sensor:

- It senses the air temperature around the unit.

■ Outdoor Unit

16. Air inlet: (Back and side)

17. Refrigerant piping and inter-unit cable

18. Drain hose


19. Earth terminal:

- It is inside of this cover.

20. Air outlet

Appearance of the outdoor unit may differ from some models.

■ Remote Controller




- 1. Signal transmitter:**
 - It sends signals to the indoor unit.
- 2. Display:**
 - It displays the current settings.
(In this illustration, each section is shown with all its displays ON for the purpose of explanation.)
- 3. HOME LEAVE button:**
for HOME LEAVE operation (page 16.)
- 4. POWERFUL button:**
for POWERFUL operation (page 14.)
- 5. TEMPERATURE adjustment buttons:**
 - It changes the temperature setting.
- 6. ON/OFF button:**
 - Press this button once to start operation.
Press once again to stop it.
- 7. MODE selector button:**
 - It selects the operation mode.
(AUTO/DRY/COOL/HEAT/FAN) (page 10.)
- 8. SILENT button:** for OUTDOOR UNIT SILENT operation (page 15.)
- 9. FAN setting button:**
 - It selects the air flow rate setting.
- 10. SWING button:** (page 12.)
- 11. ON TIMER button:** (page 19.)
- 12. TIMER Setting button:**
 - It changes the time setting.
- 13. OFF TIMER button:** (page 18.)
- 14. TIMER CANCEL button:**
 - It cancels the timer setting.
- 15. CLOCK button:** (page 9.)

2.3 Preparation before Operation

Preparation Before Operation

■ To set the batteries

1. Press  with a finger and slide the front cover to take it off.
2. Set two dry batteries (AAA).
3. Set the front cover as before.



ATTENTION


■ About batteries

- When replacing the batteries, use batteries of the same type, and replace the two old batteries together.
- When the system is not used for a long time, take the batteries out.
- We recommend replacing once a year, although if the remote controller display begins to fade or if reception deteriorates, please replace with new alkali batteries. Using manganese batteries reduces the lifespan.
- The attached batteries are provided for the initial use of the system.
The usable period of the batteries may be short depending on the manufactured date of the air conditioner.

Preparation Before Operation


■ To operate the remote controller

- To use the remote controller, aim the transmitter at the indoor unit. If there is anything to block signals between the unit and the remote controller, such as a curtain, the unit will not operate.
- Do not drop the remote controller. Do not get it wet.
- The maximum distance for communication is about 7 m.



■ To fix the remote controller holder on the wall

1. Choose a place from where the signals reach the unit.
2. Fix the holder to a wall, a pillar, etc. with the screws supplied with the holder.
3. Place the remote controller in the remote controller holder.



- To remove, pull it upwards.

ATTENTION

■ About remote controller

- Never expose the remote controller to direct sunlight.
- Dust on the signal transmitter or receiver will reduce the sensitivity. Wipe off dust with soft cloth.
- Signal communication may be disabled if an electronic-starter-type fluorescent lamp (such as inverter-type lamps) is in the room. Consult the shop if that is the case.
- If the remote controller signals happen to operate another appliance, move that appliance to somewhere else, or consult the shop.

■ To set the clock

1. Press “CLOCK button”.

0:00 is displayed.

⌚ blinks.

2. Press “TIMER setting button” to set the clock to the present time.


Holding down “▲” or “▼” button rapidly increases or decreases the time display.

3. Press “CLOCK button”.

⌚ blinks.

■ Turn the breaker ON

- Turning ON the breaker opens the flap, then closes it again. (This is a normal procedure.)



NOTE

■ Tips for saving energy

- Be careful not to cool (heat) the room too much. Keeping the temperature setting at a moderate level helps save energy.
- Cover windows with a blind or a curtain. Blocking sunlight and air from outdoors increases the cooling (heating) effect.
- Clogged air filters cause inefficient operation and waste energy. Clean them once in about every two weeks.

Recommended temperature setting

For cooling: 26°C – 28°C
For heating: 20°C – 24°C

■ Please note

- The air conditioner always consumes 15-35 watts of electricity even while it is not operating.
- If you are not going to use the air conditioner for a long period, for example in spring or autumn, turn the breaker OFF.
- Use the air conditioner in the following conditions.

Mode	Operating conditions	If operation is continued out of this range
COOL	Outdoor temperature: (3/4MK(X)) -10 to 46 °C (RK(X)) -10 to 46 °C Indoor temperature: 18 to 32 °C Indoor humidity: 80% max.	<ul style="list-style-type: none"> • A safety device may work to stop the operation. (In multi system, it may work to stop the operation of the outdoor unit only.) • Condensation may occur on the indoor unit and drip.
HEAT	Outdoor temperature: (3/4MX) -15 to 16 °C (RX) -15 to 21 °C Indoor temperature: 10 to 30 °C	<ul style="list-style-type: none"> • A safety device may work to stop the operation.
DRY	Outdoor temperature: (3/4MK(X)) -10 to 46 °C (RK(X)) -10 to 46 °C Indoor temperature: 18 to 32 °C Indoor humidity: 80% max.	<ul style="list-style-type: none"> • A safety device may work to stop the operation. • Condensation may occur on the indoor unit and drip.

- Operation outside this humidity or temperature range may cause a safety device to disable the system.

2.4 AUTO·DRY·COOL·HEAT·FAN Operation

AUTO · DRY · COOL · HEAT · FAN Operation

The air conditioner operates with the operation mode of your choice.

From the next time on, the air conditioner will operate with the same operation mode.

■ To start operation

1. Press “MODE selector button” and select a operation mode.

- Each pressing of the button advances the mode setting in sequence.



: AUTO

: DRY

: COOL


: HEAT

: FAN



2. Press “ON/OFF button” .

- The OPERATION lamp lights up.



■ To stop operation

3. Press “ON/OFF button” again.

- Then OPERATION lamp goes off.


■ To change the temperature setting

4. Press “TEMPERATURE adjustment button”

DRY or FAN mode	AUTO or COOL or HEAT mode
The temperature setting is not variable.	Press “▲” to raise the temperature and press “▼” to lower the temperature.
	Set to the temperature you like.

■ To change the air flow rate setting

5. Press “FAN setting button”.

DRY mode	AUTO or COOL or HEAT or FAN mode
The air flow rate setting is not variable.	Five levels of air flow rate setting from “  ” to “  ” plus “  ” “  ” are available. 

- Indoor unit quiet operation

When the air flow is set to “”, the noise from the indoor unit will become quieter. Use this when making the noise quieter.

The unit might lose power when the fan strength is set to a weak level.

■ To change the air flow direction

(page 12.)

NOTE

■ Note on HEAT operation

- Since this air conditioner heats the room by taking heat from outdoor air to indoors, the heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is insufficient, it is recommended to use another heating appliance in combination with the air conditioner.
- The heat pump system heats the room by circulating hot air around all parts of the room. After the start of heating operation, it takes some time before the room gets warmer.
- In heating operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost.
- During defrosting operation, hot air does not flow out of indoor unit.
- At the start of heater operation, so that air does not blow directly on an individual, air blows in an upward direction. After the blowing air gets warmer, the air will blow according to memorised air flow direction and rates.

■ Note on DRY operation

- The computer chip works to rid the room of humidity while maintaining the temperature as much as possible. It automatically controls temperature and fan strength, so manual adjustment of these functions is unavailable.

■ Note on AUTO operation

- In AUTO operation, the system selects a temperature setting and an appropriate operation mode (COOL or HEAT) based on the room temperature at the start of the operation.
- The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.
- If you do not like AUTO operation, you can manually select the operation mode and setting you like.

■ Note on air flow rate setting

- At smaller air flow rates, the cooling (heating) effect is also smaller.

2.5 Adjusting the Air Flow Direction

Adjusting the Air Flow Direction

You can adjust the air flow direction to increase your comfort.


■ To adjust the horizontal blade (flap)

1. Press "SWING button".

 The display will light up and the flaps will begin to swing.


2. When the flaps have reached the desired position, press "SWING button" once more.

The display will go blank.
The flaps will stop moving.



■ To adjust the vertical blades (louvres)

Hold the knob and move the louvre.
(You will find a knob on the left-side and the right-side blades.)




Notes on flap and louvers angle

- Unless [SWING] is selected, you should set the flap at a near-horizontal angle in HEAT mode and at a upward position in COOL or DRY mode to obtain the best performance.

■ ATTENTION

- When adjusting the flap by hand, turn off the unit, and use the remote controller to restart the unit.
- Be careful when adjusting the louvres. Inside the air outlet, a fan is rotating at a high speed.




■ Air flow selection

- Make air flow selection according to what suits you.

When setting the air flow selection switch to .

- Air conditioner automatically decides the appropriate blowing pattern depending on the operating mode/situation.

Operating mode	Situation	Blowing pattern
COOL mode	<ul style="list-style-type: none"> • When the room has become fully cool, or when one hour has passed since turning on the air conditioner. 	<ul style="list-style-type: none"> • So that air does not come into direct contact with people, air is blown upper air outlet, room temperature is equalised.
	<ul style="list-style-type: none"> • At start of operation or other times when the room is not fully cooled. 	 <ul style="list-style-type: none"> • Air is blown from the upper and lower air outlets for high speed cooling during COOL mode, and for filling the room with warm air during HEAT mode.
HEAT mode	<ul style="list-style-type: none"> • At times other than below. (Normal time.) 	
	<ul style="list-style-type: none"> • At start or when air temperature is low. 	

- During Dry mode, so that cold air does not come into direct contact with people, air is blown upper air outlet.

When setting the air outlet selection switch to .

- Regardless of the operating mode or situation, air blows from the upper air outlet.
- Use this switch when you do not want air coming out of the lower air outlet. (While sleeping etc..)

CAUTION

- Do not try to adjust the flap by hand.
- When adjusting by hand, the mechanism may not operate properly or condensation may drip from air outlets.

2.6 POWERFUL Operation

POWERFUL Operation


POWERFUL operation quickly maximizes the cooling (heating) effect in any operation mode. You can get the maximum capacity .

■ To start POWERFUL operation

1. Press “POWERFUL button”.
 - POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the settings which were used before POWERFUL operation.
 - When using POWERFUL operation, there are some functions which are not available.

■ To cancel POWERFUL operation

2. Press “POWERFUL button” again.



NOTE

■ Notes on POWERFUL operation

- **In COOL and HEAT mode**
To maximize the cooling (heating) effect, the capacity of outdoor unit must be increased and the air flow rate be fixed to the maximum setting. The temperature and air flow settings are not variable.
- **In DRY mode**
The temperature setting is lowered by 2.5°C and the air flow rate is slightly increased.
- **In FAN mode**
The air flow rate is fixed to the maximum setting.

2.7 Outdoor Unit Silent Operation

OUTDOOR UNIT SILENT Operation


OUTDOOR UNIT SILENT operation lowers the noise level of the outdoor unit by changing the frequency and fan speed on the outdoor unit. This function is convenient during night.

■ To start OUTDOOR UNIT SILENT operation

1. Press "SILENT button".

■ To cancel OUTDOOR UNIT SILENT operation

2. Press "SILENT button" again.



NOTE

■ Note on OUTDOOR UNIT SILENT operation

- This function is available in COOL, HEAT, and AUTO modes. (This is not available in FAN and DRY mode.)
- POWERFUL operation and OUTDOOR UNIT SILENT operation cannot be used at the same time. Priority is given to POWERFUL operation.
- If operation is stopped using the remote controller or the main unit ON/OFF switch when using OUTDOOR UNIT SILENT operation, "🔇" will remain on the remote controller display.


2.8 HOME LEAVE Operation

HOME LEAVE Operation

HOME LEAVE operation is a function which allows you to record your preferred temperature and air flow rate settings.


■ To start HOME LEAVE operation

1. Press “HOME LEAVE button” .
 - The HOME LEAVE lamp lights up.



■ To cancel HOME LEAVE operation

2. Press “HOME LEAVE button” again.
 - The HOME LEAVE lamp goes off.



Before using HOME LEAVE operation.

■ To set the temperature and air flow rate for HOME LEAVE operation

When using HOME LEAVE operation for the first time, please set the temperature and air flow rate for HOME LEAVE operation. Record your preferred temperature and air flow rate.

	Initial setting		Selectable range	
	temperature	Air flow rate	temperature	Air flow rate
Cooling	25°C	AUTO	18-32°C	5 step, AUTO and SILENT
Heating	25°C	AUTO	10-30°C	5 step, AUTO and SILENT

1. Press “HOME LEAVE button”. Make sure “” is displayed in the remote controller display.
 2. Adjust the set temperature with “▲” or “▼” as you like.
 3. Adjust the air flow rate with “FAN” setting button as you like.
- Home leave operation will run with these settings the next time you use the unit. To change the recorded information, repeat steps 1 – 3.

■ What's the HOME LEAVE operation

Is there a set temperature and air flow rate which is most comfortable, a set temperature and air flow rate which you use the most? HOME LEAVE operation is a function that allows you to record your favorite set temperature and air flow rate. You can start your favorite operation mode simply by pressing the HOME LEAVE button on the remote controller. This function is convenient in the following situations.

■ Useful in these cases.

1. Use as an energy-saving mode

Set the temperature 2-3° higher (cooling) or lower (heating) than normal. Setting the fan strength to the lowest setting allows the unit to be used in energy-saving mode. Also convenient for use while you are out or sleeping.

• Every day before you leave the house...



When you go out, push the "HOME LEAVE Operation" button, and the air conditioner will adjust capacity to reach the preset temperature for HOME LEAVE Operation.




When you return, you will be welcomed by a comfortably air conditioned room.



Push the "HOME LEAVE Operation" button again, and the air conditioner will adjust capacity to the set temperature for normal operation.


• Before bed...



Set the unit to HOME LEAVE Operation before leaving the living room when going to bed.



The unit will maintain the temperature in the room at a comfortable level while you sleep.



When you enter the living room in the morning, the temperature will be just right. Disengaging HOME LEAVE Operation will return the temperature to that set for normal operation. Even the coldest winters will pose no problem!

2. Use as a favorite mode

Once you record the temperature and air flow rate settings you most often use, you can retrieve them by pressing HOME LEAVE button. You do not have to go through troublesome remote control operations.

NOTE

- Once the temperature and air flow rate for HOME LEAVE operation are set, those settings will be used whenever HOME LEAVE operation is used in the future. To change these settings, please refer to the "Before using HOME LEAVE operation" section above.
- HOME LEAVE operation is only available in COOL and HEAT mode. Cannot be used in AUTO, DRY, and FAN mode.
- HOME LEAVE operation runs in accordance with the previous operation mode (COOL or HEAT) before using HOME LEAVE operation.
- HOME LEAVE operation and POWERFUL operation cannot be used at the same time. Last button that was pressed has priority.
- The operation mode cannot be changed while HOME LEAVE operation is being used.
- When operation is shut off during HOME LEAVE operation, using the remote controller or the indoor unit ON/OFF switch, "🏠" will remain on the remote controller display.

2.9 TIMER Operation

TIMER Operation

Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

■ To use OFF TIMER operation

- Check that the clock is correct.
If not, set the clock to the present time.
(page 9.)

1. Press “OFF TIMER button”.

0:00 is displayed.



⊕-⊖ blinks.

2. Press “TIMER Setting button” until the time setting reaches the point you like.

- Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.

3. Press “OFF TIMER button” again.

- The TIMER lamp lights up.



■ To cancel the OFF TIMER Operation

4. Press “CANCEL button”.

- The TIMER lamp goes off.

Notes

- When TIMER is set, the present time is not displayed.
- Once you set ON, OFF TIMER, the time setting is kept in the memory. (The memory is canceled when remote controller batteries are replaced.)
- When operating the unit via the ON/OFF Timer, the actual length of operation may vary from the time entered by the user. (Maximum approx. 10 minutes)

■ NIGHT SET MODE

When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.5°C up in COOL, 2.0°C down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.

■ To use ON TIMER operation

- Check that the clock is correct. If not, set the clock to the present time (page 9.).

1. Press “ON TIMER button”.

7:00 is displayed.



⊕·| blinks.

2. Press “TIMER Setting button” until the time setting reaches the point you like.

- Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.

3. Press “ON TIMER button” again.

- The TIMER lamp lights up.




■ To cancel ON TIMER operation

4. Press “CANCEL button”.

- The TIMER lamp goes off.

■ To combine ON TIMER and OFF TIMER

- A sample setting for combining the two timers is shown below.



ATTENTION

■ In the following cases, set the timer again.

- After a breaker has turned OFF.
- After a power failure.
- After replacing batteries in the remote controller.

2.10 Care and Cleaning

Care and Cleaning



CAUTION Before cleaning, be sure to stop the operation and turn the breaker OFF.

Units


Indoor unit, Outdoor unit and Remote controller

1. Wipe them with dry soft cloth.

Front grille


1. Open the front grille.

- Press the two  places on the left and right of the front grille.



2. Remove the front grille.

- Remove the chain.
- Allowing the grille to fall forward will enable you to remove it.




3. Clean the front grille

- Wipe softly with a damp cloth.
- Only neutral detergent may be used.
- In case of washing the grille with water, dry it with cloth, dry it up in the shade after washing.

4. Attach the front grille.

- Insert the front grille into the grooves of the unit (3 places).
- Attach the chain to the right, inner-side of the front grille.
- Close the grille slowly.



Place front grille in grooves.




CAUTION

- Hold the front grille firmly so that it does not fall.
- Do not touch the metal parts on the inside of the indoor unit, as it may result in injury.
- When removing or attaching the front grille, use a robust and stable stool and watch your steps carefully.
- When removing or attaching the front grille, support the grille securely with hand to prevent it from falling.
- For cleaning, do not use hot water above 40 °C, benzine, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes, nor other hand stuff.
- After cleaning, make sure that the front grille is securely fixed.


Filters

1. Open the front grille. (page 22)



2. Remove the air filter.

- Press the claws on the right and left of the air filter down slightly, then pull upward.



3. Take off the air purifying filter, Photocatalytic deodorizing filter.



- Hold the tabs of the frame, and remove the claws in 4 places.

4. Clean or replace each filter.

See below.

5. Set the air filter, air purifying filter and photocatalytic deodorizing filter as they were and close the front grille.


- Operation without air filters may result in troubles as dust will accumulate inside the indoor unit.



■ Air Filter

1. Wash the air filters with water or clean them with vacuum cleaner.

- If the dust does not come off easily, wash them with neutral detergent thinned with lukewarm water, then dry them up in the shade.
- It is recommended to clean the air filters every two weeks.




■ Air Purifying Filter (green)

(Replace approximately once every 3 months.)

1. Detach the filter element and attach a new one.

- Insert with the green side up.
- It is recommended to replace the air purifying filter every three months.



■ Photocatalytic Deodorizing Filter (gray)

[Maintenance]

1. Dry the photocatalytic deodorizing filter in the sun.

- After removing the dust with a vacuum cleaner, place the filter in the sun for approximately 6 hours. By drying the photocatalytic deodorizing filter in the sun, its deodorizing and antibacterial capabilities are regenerated.
- Because the filter material is paper, it can not be cleaned with water.
- It is recommended dry the filter once every 6 months.

[Replacement]

1. Detach the filter element and attach a new one.

Check

Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.
Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.
Check that the earth wire is not disconnected or broken.
Check that the drain comes smoothly out of the drain hose during COOL or DRY operation. <ul style="list-style-type: none"> If no drain water is seen, water may be leaking from the indoor unit. Stop operation and consult the service shop if this is the case.

■ Before a long idle period

- Operate the “fan only” for several hours on a fine day to dry out the inside.**
 - Press “MODE” button and select “fan” operation.
 - Press “ON/OFF” button and start operation.
- Clean the air filters and set them again.**
- Take out batteries from the remote controller.**
- Turn OFF the breaker for the room air conditioner.**

NOTE

- Operation with dusty air filters lowers the cooling (heating) capacity and wastes energy. Air is also prevented from flowing smoothly through the unit creating a noise.
- Operation with dirty filters :
 - cannot deodorize the air.
 - cannot clean the air.
 - results in poor heating or cooling.
 - may cause odour.
- The air purifying filter and Photocatalytic deodorizing filter cannot be reused, even if washed.
- In principle, there is no need to replace the photocatalytic deodorizing filter. Remove the dust periodically with a vacuum cleaner. However, it is recommended to replace the filter in the following cases.
 - The paper material is torn or broken during cleaning.
 - The filter has become extremely dirty after long use.
- To order air purifying filter or Photocatalytic deodorizing filter, contact to the service shop where you bought the air conditioner.
- Dispose of old air filters as non-burnable waste and Photocatalytic deodorizing filters as burnable waste.

Item	Part No.
Photocatalytic deodorizing filter (with frame)	KAZ917B41
Photocatalytic deodorizing filter (without frame)	KAZ917B42
Air purifying filter (with frame)	KAF925B41
Air purifying filter (without frame)	KAF925B42

2.11 Trouble Shooting

Trouble Shooting

These cases are not troubles.

The following cases are not air conditioner troubles but have some reasons. You may just continue using it.

Case	Explanation
Operation does not start soon. <ul style="list-style-type: none"> When ON/OFF button was pressed soon after operation was stopped. When the mode was reselected. 	<ul style="list-style-type: none"> This is to protect the air conditioner. You should wait for about 3 minutes.
Hot air does not flow out soon after the start of heating operation.	<ul style="list-style-type: none"> The air conditioner is warming up. You should wait for 1 to 4 minutes. (The system is designed to start discharging air only after it has reached a certain temperature.)
The heating operation stops suddenly and a flowing sound is heard.	<ul style="list-style-type: none"> The system is taking away the frost on the outdoor unit. You should wait for about 3 to 8 minutes.
The outdoor unit emits water or steam.	<ul style="list-style-type: none"> In HEAT mode <ul style="list-style-type: none"> The frost on the outdoor unit melts into water or steam when the air conditioner is in defrost operation. In COOL or DRY mode <ul style="list-style-type: none"> Moisture in the air condenses into water on the cool surface of outdoor unit piping and drips.
Mists come out of the indoor unit.	<ul style="list-style-type: none"> This happens when the air in the room is cooled into mist by the cold air flow during cooling operation.
The indoor unit gives out odour.	<ul style="list-style-type: none"> This happens when smells of the room, furniture, or cigarettes are absorbed into the unit and discharged with the air flow. (If this happens, we recommend you to have the indoor unit washed by a technician. Consult the service shop where you bought the air conditioner.)
The outdoor fan rotates while the air conditioner is not in operation.	<ul style="list-style-type: none"> After operation is stopped: <ul style="list-style-type: none"> The outdoor fan continues rotating for another 60 seconds for system protection. While the air conditioner is not in operation: <ul style="list-style-type: none"> When the outdoor temperature is very high, the outdoor fan starts rotating for system protection.
The operation stopped suddenly. (OPERATION lamp is on)	<ul style="list-style-type: none"> For system protection, the air conditioner may stop operating on a sudden large voltage fluctuation. It automatically resumes operation in about 3 minutes.

Check again.

Please check again before calling a repair person.

Case	Check
The air conditioner does not operate. (OPERATION lamp is off)	<ul style="list-style-type: none"> • Hasn't a breaker turned OFF or a fuse blown? • Isn't it a power failure? • Are batteries set in the remote controller? • Is the timer setting correct?
Cooling (Heating) effect is poor.	<ul style="list-style-type: none"> • Are the air filters clean? • Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? • Is the temperature setting appropriate? • Are the windows and doors closed? • Are the air flow rate and the air direction set appropriately?
Operation stops suddenly. (OPERATION lamp flashes.)	<ul style="list-style-type: none"> • Are the air filters clean? • Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? <p>Clean the air filters or take all obstacles away and turn the breaker OFF. Then turn it ON again and try operating the air conditioner with the remote controller. If the lamp still flashes, call the service shop where you bought the air conditioner.</p>
An abnormal functioning happens during operation.	<ul style="list-style-type: none"> • The air conditioner may malfunction with lightning or radio waves. Turn the breaker OFF, turn it ON again and try operating the air conditioner with the remote controller.

Call the service shop immediately.

 **WARNING**

- When an abnormality (such as a burning smell) occurs, stop operation and turn the breaker OFF.
Continued operation in an abnormal condition may result in troubles, electric shocks or fire.
Consult the service shop where you bought the air conditioner.
- Do not attempt to repair or modify the air conditioner by yourself.
Incorrect work may result in electric shocks or fire.
Consult the service shop where you bought the air conditioner.

If one of the following symptoms takes place, call the service shop immediately.

<ul style="list-style-type: none"> ■ The power cord is abnormally hot or damaged. ■ An abnormal sound is heard during operation. ■ The safety breaker, a fuse, or the earth leakage breaker cuts off the operation frequently. ■ A switch or a button often fails to work properly. ■ There is a burning smell. ■ Water leaks from the indoor unit. 	 <div data-bbox="1093 651 1342 902" style="border: 1px solid black; padding: 10px; width: fit-content; margin: auto;"> Turn the breaker OFF and call the service shop. </div>
---	--

<ul style="list-style-type: none"> ■ After a power failure The air conditioner automatically resumes operation in about 3 minutes. You should just wait for a while. 	<ul style="list-style-type: none"> ■ Lightning If lightening may strike the neighbouring area, stop operation and turn the breaker OFF for system protection.
---	--

Disposal requirements

Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national regulations.

We recommend periodical maintenance

In certain operating conditions, the inside of the air conditioner may get foul after several seasons of use, resulting in poor performance. It is recommended to have periodical maintenance by a specialist aside from regular cleaning by the user. For specialist maintenance, contact the service shop where you bought the air conditioner.

The maintenance cost must be born by the user.

Part 6

Service Diagnosis


1. Caution for Diagnosis	70
2. Problem Symptoms and Measures	71
3. Service Check Function	72
3.1 ARC433 Series.....	72
4. Troubleshooting	73
4.1 Error Codes and Description	73
4.2 Indoor Unit PCB Abnormality	74
4.3 Freeze-up Protection Control or High Pressure Control.....	75
4.4 Fan Motor (DC Motor) or Related Abnormality.....	77
4.5 Thermistor or Related Abnormality (Indoor Unit).....	79
4.6 Shutter Drive Motor / Shutter Limit Switch Abnormality	80
4.7 Signal Transmission Error (between Indoor and Outdoor Units).....	81
4.8 OL Activation (Compressor Overload)	82
4.9 Compressor Lock	83
4.10 Input Over Current Detection	84
4.11 Four Way Valve Abnormality	85
4.12 Discharge Pipe Temperature Control.....	87
4.13 Position Sensor Abnormality	88
4.14 CT or Related Abnormality	89
4.15 Thermistor or Related Abnormality (Outdoor Unit).....	91
4.16 Electrical Box Temperature Rise	93
4.17 Radiation Fin Temperature Rise	95
4.18 Output Over Current Detection.....	97
4.19 Insufficient Gas.....	99
4.20 Over-voltage Detection.....	101
4.21 High Pressure Control in Cooling	102
5. Checks	104
5.1 How to Check.....	104

1. Caution for Diagnosis

The Operation lamp flashes when any of the following errors is detected.

1. When a protection device of the indoor or outdoor unit is activated or when the thermistor malfunctions, disabling equipment operation.
 2. When a signal transmission error occurs between the indoor and outdoor units.
- In either case, conduct the diagnostic procedure described in the following sections pages.

Location of Operation Lamp



Troubleshooting with the LED Indication

The outdoor unit has one green LED (LEDA) on the PCB. The flashing green LED indicates normal condition of microcomputer operation.

2. Problem Symptoms and Measures


Problem Symptom	Check Item	Details of Measure	Reference Page
None of the Units Operates.	Check the power supply.	Check to make sure that the rated voltage is supplied.	—
	Check the type of the indoor units.	Check to make sure that the indoor unit type is compatible with the outdoor unit.	—
	Check the outdoor air temperature.	Heating operation cannot be used when the outdoor air temperature is 30°C or higher (only for heat pump model), and cooling operation cannot be used when the outdoor air temperature is below -10 °C.	—
	Diagnosis with code indication on the remote controller	—	73
	Check the remote controller addresses.	Check to make sure that address settings for the remote controller and indoor unit are correct.	—
Operation Sometimes Stops.	Check the power supply.	A power failure of 2 to 10 cycles can stop air conditioner operation. (Operation lamp OFF)	—
	Check the outdoor air temperature.	Heating operation cannot be used when the outdoor air temperature is 30°C or higher (only for heat pump model), and cooling operation cannot be used when the outdoor air temperature is below -10°C.	—
	Diagnosis with code indication on the remote controller	—	73
Some indoor units do not operate.	Check the type of the indoor units.	Check to make sure that the indoor unit type is compatible with the outdoor unit.	—
	Diagnosis with code indication on the remote controller	—	73
Equipment operates but does not cool, or does not heat (only for heat pump model).	Check for thermistor detection errors.	Check to make sure that the main unit's thermistor has not dismantled from the pipe holder.	—
	Diagnosis with code indication on the remote controller	—	73
	Diagnosis by service port pressure and operating current	Check for insufficient gas.	99
Large Operating Noise and Vibrations	Check the power transistor.	—	—
	Check the installation condition.	Check to make sure that the required spaces for installation (specified in the Installation Manual, etc.) are provided.	—

3. Service Check Function

3.1 ARC433 Series

In the **ARC433A series**, the temperature display sections on the main unit indicate corresponding codes.

1. When the timer cancel button is held down for 5 seconds, a “00” indication flashes on the temperature display section.



<ARC433A5, A6>

(R2596)

2. Press the timer cancel button repeatedly until a continuous beep is produced.
 - The code indication changes in the sequence shown below, and notifies with along beep.

No.	Code	No.	Code	No.	Code
1	00	11	E7	21	UR
2	U4	12	C7	22	R5
3	F3	13	H8	23	J9
4	E6	14	J3	24	E8
5	L5	15	R3	25	P4
6	R6	16	R1	26	L3
7	E5	17	C4	27	L4
8	LC	18	C5	28	H6
9	C9	19	H9	29	H7
10	U0	20	J6	30	U2



Note:

1. A short beep and two consecutive beeps indicate non-corresponding codes.
2. To cancel the code display, hold the timer cancel button down for 5 seconds. The code display also cancels itself if the button is not pressed for 1 minute.

4. Troubleshooting

4.1 Error Codes and Description

	Code Indication	Description	Reference Page
System	<i>00</i>	Normal	—
	<i>U0</i> ★	Insufficient gas	99
	<i>U2</i>	Over-voltage detection	101
	<i>U4</i>	Signal transmission error (between indoor and outdoor units)	81
Indoor Unit	<i>R1</i>	Indoor unit PCB abnormality	74
	<i>R5</i>	Freeze-up protection control or high pressure control	75
	<i>R6</i>	Fan motor or related abnormality	77
	<i>C4</i>	Heat exchanger temperature thermistor abnormality	79
	<i>C7</i>	Shutter drive motor / shutter limit switch abnormality	80
	<i>C9</i>	Room temperature thermistor abnormality	79
Outdoor Unit	<i>E5</i> ★	OL activation (compressor overload)	82
	<i>E6</i> ★	Compressor lock	83
	<i>E8</i>	Input over current detection	84
	<i>ER</i>	Four way valve abnormality	85
	<i>F3</i>	Discharge pipe temperature control	87
	<i>F6</i>	High pressure control in cooling	102
	<i>H5</i>	Position sensor abnormality	88
	<i>H8</i>	CT or related abnormality	89
	<i>H9</i>	Outdoor air thermistor or related abnormality	91
	<i>J3</i>	Discharge pipe temperature thermistor or related abnormality	91
	<i>J5</i>	Heat exchanger temperature thermistor or related abnormality	91
	<i>L3</i>	Electrical box temperature rise	93
	<i>L4</i>	Radiation fin temperature rise	95
	<i>L5</i>	Output over current detection	97
	<i>P4</i>	Heat radiation fin thermistor or related abnormality	91

★: Displayed only when system-down occurs.

4.2 Indoor Unit PCB Abnormality

Remote
Controller
Display

A1

Method of
Malfunction
Detection

Evaluation of zero-cross detection of power supply by indoor unit.

Malfunction
Decision
Conditions


When there is no zero-cross detection in approximately 10 continuous seconds.

Supposed
Causes

- Faulty indoor unit PCB
- Faulty connector connection

Troubleshooting

 **Caution** Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R1400)

 **Note:** Connector Nos. vary depending on models.
Control connector

Model Type	Connector No.
Floor Standing Type	Control PCB : S7, S201, S203 Power Supply PCB : S8, S202, S204

4.3 Freeze-up Protection Control or High Pressure Control

Remote
Controller
Display

AS

Method of
Malfunction
Detection

- High pressure control (heat pump model only)
During heating operations, the temperature detected by the indoor heat exchanger thermistor is used for the high pressure control (stop, outdoor fan stop, etc.)
- The freeze-up protection control (operation halt) is activated during cooling operation according to the temperature detected by the indoor unit heat exchanger thermistor.

Malfunction
Decision
Conditions

- High pressure control
During heating operations, the temperature detected by the indoor heat exchanger thermistor is above 65°C
- Freeze-up protection

When the indoor unit heat exchanger temperature is below 0°C during cooling operation.

Supposed
Causes

- Operation halt due to clogged air filter of the indoor unit.
- Operation halt due to dust accumulation on the indoor unit heat exchanger.
- Operation halt due to short-circuit.
- Detection error due to faulty indoor unit heat exchanger thermistor.
- Detection error due to faulty indoor unit PCB.

Troubleshooting




Check No.6
Refer to P.107



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



Note:

If the outdoor air temperature is below -10°C in the cooling mode, the system may get interrupted with error R5 displayed. The system will be reset itself, but this stop will be put in the error history memory.

4.4 Fan Motor (DC Motor) or Related Abnormality

Remote
Controller
Display

AB

Method of
Malfunction
Detection

The rotation speed detected by the hall IC during fan motor operation is used to determine abnormal fan motor operation.

Malfunction
Decision
Conditions

When the detected rotation speed is less than 50% of the H tap under maximum fan motor rotation demand.

Supposed
Causes

- Operation halt due to short circuit inside the fan motor winding.
- Operation halt due to breaking of wire inside the fan motor.
- Operation halt due to breaking of the fan motor lead wires.
- Operation halt due to faulty capacitor of the fan motor.
- Detection error due to faulty indoor unit PCB (1).

Troubleshooting




Check No.01
Refer to P.104



Check No.02
Refer to P.104



Caution Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R1214)

4.5 Thermistor or Related Abnormality (Indoor Unit)

Remote
Controller
Display

Ⓒ4, Ⓒ9

Method of
Malfunction
Detection

The temperatures detected by the thermistors are used to determine thermistor errors.

Malfunction
Decision
Conditions

When the thermistor input is more than 4.96 V or less than 0.04 V during compressor operation*.

* (reference)

When above about 212°C (less than 120 ohms) or below about -50°C (more than 1,860 kohms).



Note: The values vary slightly in some models.

Supposed
Causes

- Faulty connector connection
- Faulty thermistor
- Faulty PCB

Troubleshooting




Check No.6
Refer to P.107



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R1403)

Ⓒ4 : Heat exchanger temperature thermistor

Ⓒ9 : Room temperature thermistor

4.6 Shutter Drive Motor / Shutter Limit Switch Abnormality

Remote Controller Display



Method of Malfunction Detection

The shutter open/close performance is detected by the limit switch attached on its structure. In this way, the shutter drive motor and the shutter limit switch are checked for failure.

Malfunction Decision Conditions

When the shutter is open, the limit switch is closed, or vice versa.

Supposed Causes

- Shutter drive motor defective
- Shutter limit switch defective
- Shutter itself deformed (warped)
- Shutter's sealing material too thick
- Detection error by broken relay harness or disconnected connector
- Detection error due to defective PCB (2)
- Foreign substance in blow port


Troubleshooting



Check No.3
Refer to P.104



Caution Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R3055)

4.7 Signal Transmission Error (between Indoor and Outdoor Units)

Remote
Controller
Display

U4

Method of
Malfunction
Detection

The data received from the outdoor unit in indoor unit-outdoor unit signal transmission is checked whether it is normal.

Malfunction
Decision
Conditions

When the data sent from the outdoor unit cannot be received normally, or when the content of the data is abnormal.


Supposed
Causes

- Faulty outdoor unit PCB.
- Faulty indoor unit PCB.
- Indoor unit-outdoor unit signal transmission error due to wiring error.
- Indoor unit-outdoor unit signal transmission error due to disturbed power supply waveform.
- Indoor unit-outdoor unit signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units (wire No. 2).

Troubleshooting



Check No.10
Refer to P.110



(R2597)

4.8 OL Activation (Compressor Overload)

Remote
Controller
Display

ES

Method of
Malfunction
Detection

A compressor overload is detected through compressor OL.

Malfunction
Decision
Conditions

- If the compressor OL is activated twice, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).
- * The operating temperature condition is not specified.

Supposed
Causes

- Refrigerant shortage
- Four way valve malfunctioning
- Outdoor unit PCB defective
- Water mixed in the local piping
- Electronic expansion valve defective
- Stop valve defective


Troubleshooting


Check No.4
Refer to P.105


Check No.5
Refer to P.106


Check No.6
Refer to P.107


Check No.11
Refer to P.110



4.9 Compressor Lock

Remote
Controller
Display

EG

Method of
Malfunction
Detection

A compressor lock is detected by checking the compressor running condition through the position detection circuit.


Malfunction
Decision
Conditions

- The system judges the compressor lock, and stops due to over current.
- The system judges the compressor lock, and cannot operation with position detection within 15 seconds after start up.
- The system will be shut down if the error occurs 16 times.
- Clearing condition: Continuous run for about 5 minutes (normal)

Supposed
Causes

- Compressor locked

Troubleshooting



Note: If the model doesn't have SPM, replace the outdoor unit PCB.

(R2842)

4.10 Input Over Current Detection

Remote
Controller
Display



Method of
Malfunction
Detection

An input over-current is detected by checking the input current value being detected by CT with the compressor running.

Malfunction
Decision
Conditions

- The following CT input with the compressor running continues for 2.5 seconds.
Cooling: Above 11A, Heating: Above 13A

Supposed
Causes

- Over-current due to compressor failure
- Over-current due to defective power transistor
- Over-current due to defective outdoor unit PCB
- Error detection due to outdoor unit PCB
- Over-current due to short-circuit

Troubleshooting



Check No.7
Refer to P.108




Check No.8
Refer to P.108



Caution Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

* An input over-current may result from wrong internal wiring. If the wires have been disconnected and reconnected for part replacement, for example, and the system is interrupted by an input over-current, take the following procedure.



(R2952)



Note: If the model doesn't have SPM, replace the outdoor unit PCB.

4.11 Four Way Valve Abnormality

Remote
Controller
Display

EA

**Method of
Malfunction
Detection**

The indoor air temperature thermistor, the indoor unit heat exchanger thermistor, the outdoor temperature thermistor and the outdoor unit heat exchanger thermistor are checked to see if they function within their normal ranges in the operating mode.

**Malfunction
Decision
Conditions**

A following condition continues over 10 minute after operating 5 minutes.

- Cooling / dry operation
(room temp. – indoor heat exchanger temp.) < –10°C
- Heating
(indoor unit heat exchanger temp. – room temp.) < –10°C

**Supposed
Causes**

- Connector in poor contact
- Thermistor defective
- Outdoor unit PCB defective
- Four way valve coil or harness defective
- Four way valve defective
- Foreign substance mixed in refrigerant
- Insufficient gas

Troubleshooting



Check No.5
Refer to P.106




Check No.6
Refer to P.107



Check No.11
Refer to P.110



Caution Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R3040)

4.12 Discharge Pipe Temperature Control

Remote Controller Display



Method of Malfunction Detection

The discharge pipe temperature control (stop, frequency drooping, etc.) is checked with the temperature being detected by the discharge pipe thermistor.

Malfunction Decision Conditions

- If a stop takes place 6 times successively due to abnormal discharge pipe temperature, the system will be shut down.
- If the temperature being detected by the discharge pipe thermistor rises above A °C, the compressor will stop. (The error is cleared when the temperature has dropped below B °C.)

Stop temperatures

	A	B
(1) above 45Hz (rising), above 40Hz (dropping)	120	80
(2) 130~45Hz (rising), 25~40Hz (dropping)	110	70
(3) below 30Hz (rising), below 25Hz (dropping)	105	65


- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Supposed Causes

- Refrigerant shortage
- Four way valve malfunctioning
- Discharge pipe thermistor defective (heat exchanger or outdoor air temperature thermistor defective)
- Outdoor unit PCB defective
- Water mixed in the local piping
- Electronic expansion valve defective
- Stop valve defective

Troubleshooting

- Check No.4**
Refer to P.105
- Check No.6**
Refer to P.107
- Check No.11**
Refer to P.110



4.13 Position Sensor Abnormality

Remote
Controller
Display

H6

Method of
Malfunction
Detection

A compressor startup failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction
Decision
Conditions

- The compressor fails to start in about 15 seconds after the compressor run command signal is sent.
- Clearing condition: Continuous run for about 5 minutes (normal)
- The system will be shut down if the error occurs 16 times.


Supposed
Causes
Compressor relay
cable
disconnected

- Compressor relay cable disconnected
- Compressor itself defective
- Outdoor unit PCB defective
- Stop valve closed
- Input voltage out of specification

Troubleshooting



Check No.13
Refer to P.111



(R3041)

4.14 CT or Related Abnormality

Remote
Controller
Display

H8

Method of
Malfunction
Detection

A CT or related error is detected by checking the compressor running frequency and CT-detected input current.

Malfunction
Decision
Conditions

The compressor running frequency is below 62 Hz and the CT input is below 0.1 V.
(The input current is also below 0.5 A.)


- If this error repeats 4 times, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Supposed
Causes

- Power transistor defective
- Internal wiring broken or in poor contact
- Reactor defective
- Outdoor unit PCB defective

Troubleshooting


Check No.12
 Refer to P.111



 **Note:** If the model doesn't have SPM, replace the outdoor unit PCB.

4.15 Thermistor or Related Abnormality (Outdoor Unit)

Remote
Controller
Display

P4, J3, J6, H9

Method of
Malfunction
Detection

This type of error is detected by checking the thermistor input voltage to the microcomputer.
[A thermistor error is detected by checking the temperature.]

Malfunction
Decision
Conditions

The thermistor input is above 4.96 V or below 0.04 V with the power on.
Error *J3* is judged if the discharge pipe thermistor temperature is smaller than the condenser thermistor temperature.

Supposed
Causes

- Connector in poor contact
- Thermistor defective
- Outdoor unit PCB defective
- Indoor unit PCB defective
- Condenser thermistor defective in the case of *J3* error (outdoor unit heat exchanger thermistor in the cooling mode, or indoor unit heat exchanger thermistor in the heating mode)

Troubleshooting




Check No.6
Refer to P.107



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R3043)

- P4 : Radiation fin thermistor
- J3 : Discharge pipe temperature thermistor
- J5 : Outdoor unit heat exchanger temperature thermistor
- H9 : Outdoor air temperature thermistor

4.16 Electrical Box Temperature Rise

**Remote
Controller
Display**

L3

**Method of
Malfunction
Detection**

An electrical box temperature rise is detected by checking the radiation fin thermistor with the compressor off.

**Malfunction
Decision
Conditions**

With the compressor off, the radiation fin temperature is above 122°C. (Reset is made when the temperature drops below 113°C.)

**Supposed
Causes**


- Fin temperature rise due to defective outdoor unit fan
- Fin temperature rise due to short-circuit
- Fin thermistor defective
- Connector in poor contact
- Outdoor unit PCB defective

Troubleshooting

 **Check No.6**
Refer to P.107

 **Check No.7**
Refer to P.108

 **Check No.9**
Refer to P.109



(R2953)

4.17 Radiation Fin Temperature Rise

Remote
Controller
Display

L4

Method of
Malfunction
Detection

A radiation fin temperature rise is detected by checking the radiation fin thermistor with the compressor on.

Malfunction
Decision
Conditions

If the radiation fin temperature with the compressor on is above 81°C,

- If a radiation fin temperature rise takes place 4 times successively, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Supposed
Causes

- Fin temperature rise due to defective outdoor unit fan
- Fin temperature rise due to short-circuit
- Fin thermistor defective
- Connector in poor contact
- Outdoor unit PCB defective

Troubleshooting

 **Check No.6**
Refer to P.107


 **Check No.7**
Refer to P.108

 **Check No.9**
Refer to P.109



Caution Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

Turn off the power and turn it on again to get the system started.



(R2851)

4.18 Output Over Current Detection

Remote
Controller
Display

L5

Method of
Malfunction
Detection

An output over-current is detected by checking the current that flows in the inverter DC section.

Malfunction
Decision
Conditions

- A position signal error occurs while the compressor is running.
- A speed error occurs while the compressor is running.
- An output over-current input is fed from the output over-current detection circuit to the microcomputer.
- The system will be shut down if the error occurs 16 times.
- Clearing condition: Continuous run for about 5 minutes (normal)

Supposed
Causes

- Over-current due to defective power transistor
- Over-current due to wrong internal wiring
- Over-current due to abnormal supply voltage
- Over-current due to defective PCB
- Error detection due to defective PCB
- Over-current due to closed stop valve
- Over-current due to compressor failure
- Over-current due to poor installation condition

Troubleshooting



Check No.7
Refer to P.108



Check No.8
Refer to P.108




Check No.13
Refer to P.111



Caution Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

* An output over-current may result from wrong internal wiring. If the wires have been disconnected and reconnected for part replacement, for example, and the system is interrupted by an output over-current, take the following procedure.



(R2852)



Note: If the model doesn't have SPM, replace the outdoor unit PCB.

4.19 Insufficient Gas

Remote
Controller
Display

U0

Method of
Malfunction
Detection

Gas shortage detection I : A gas shortage is detected by checking the CT-detected input current value and the compressor running frequency.

Gas shortage detection II : A gas shortage is detected by checking the difference between indoor unit heat exchanger temperature and room temperature as well as the difference between outdoor unit heat exchanger temperature and room temperature.

Malfunction
Decision
Conditions

Gas shortage detection I :

Input current < A (A/Hz) x Compressor running frequency x Voltage + B

However, when the status of running frequency > C (Hz) is kept on for a certain time.

Note : The values are different from model to model.

	A	B	C
FVK(X)S series.	1120 / 256	-80	65

Gas shortage detection II :

If a gas shortage error takes place 4 times successively, the system will be shut down. The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Supposed
Causes

- Refrigerant shortage (refrigerant leakage)
- Poor compression performance of compressor
- Discharge pipe thermistor disconnected, or indoor unit or outdoor unit heat exchanger thermistor disconnected, room or outdoor air temperature thermistor disconnected
- Stop valve closed
- Electronic expansion valve defective

Troubleshooting



Check No.4
Refer to P.105




Check No.6
Refer to P.107



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



4.20 Over-voltage Detection

Remote
Controller
Display

U2

Method of
Malfunction
Detection

An abnormal voltage rise is detected by checking the specified over-voltage detection circuit.


Malfunction
Decision
Conditions

- An over-voltage signal is fed from the over-voltage detection circuit to the microcomputer (The voltage is over 400V).
- The system will be shut down if the error occurs 5 times.
- Clearing condition: Continuous run for about 60 minutes (normal)

Supposed
Causes

- Supply voltage not as specified
- Over-voltage detection circuit defective
- PAM control part(s) defective

Troubleshooting



(R2957)



Note: If the model doesn't have SPM, replace the outdoor unit PCB.

4.21 High Pressure Control in Cooling

Remote
Controller
Display

FB

Method of
Malfunction
Detection

High-pressure control (stop, frequency drop, etc.) is activated in the cooling mode if the temperature being sensed by the heat exchanger thermistor exceeds the limit.

Malfunction
Decision
Conditions

Activated when the temperature being sensed by the heat exchanger thermistor rises above 60°C. (Deactivated when the said temperature drops below 50°C.)

Supposed
Causes

- The installation space is not large enough.
- Faulty outdoor unit fan
- Faulty electronic expansion valve
- Faulty defrost thermistor
- Faulty outdoor unit PCB
- Faulty stop valve
- Dirty heat exchanger

Troubleshooting



Check No.4
Refer to P.105



Check No.6
Refer to P.107



Check No.7
Refer to P.108




Check No.9
Refer to P.109



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R2855)

5. Checks


5.1 How to Check

5.1.1 Fan Motor Connector Output Check


Check No.01

1. Check connector connection.
2. Check motor power supply voltage output (pins 4-7 and 4-8).
3. Check motor control voltage (pins 4-3).
4. Check rotation command voltage output (pins 4-2).
5. Check rotation pulse input (pins 4-1).

Upper fan connector



Lower fan connector




(R1224)

Check No.02

1. Check connector connection.
2. Check motor control voltage output (pins 2-1).

S202




(R1073)

5.1.2 Limit Switch Continuity Check

Check No.3

Remove the front grille. The limit switch is located at the left side of the drain pan assembly. Check the continuity of the switch connection.



Shutter status	Open	Closed
Continuity	Continuity	No continuity

(Q0363)


- * The shutter can be opened and closed with hand. Keep the shutter open and closed all the way for each continuity check steps.

5.1.3 Electronic Expansion Valve Check

Check No.4

Conduct the followings to check the electronic expansion valve (EV).

1. Check to see if the EV connector is correctly inserted in the PCB. Compare the EV unit and the connector number.
2. Turn the power off and back on again, and check to see if all the EVs generate latching sound.
3. If any of the EVs does not generate latching noise in the above step 2, disconnect that connector and check the conductivity using a tester.
Check the conductivity between pins 1, 3 and 6, and between pins 2, 4 and 5. If there is no conductivity between the pins, the EV coil is faulty.



(R1082)



4. If no EV generates latching sound in the above step 2, the outdoor unit PCB is faulty.
5. If the conductivity is confirmed in the above step 2, mount a good coil (which generated latching sound) in the EV unit that did not generate latching sound, and check to see if that EV generates latching sound.
 - *If latching sound is generated, the outdoor unit PCB is faulty.
 - *If latching sound is not generated, the EV unit is faulty.



Note: Please note that the latching sound varies depending on the valve type.

5.1.4 Four Way Valve Performance Check

Check No.5



(R3047)


5.1.5 Thermistor Resistance Check

Check No.6


Remove the connectors of the thermistors on the PCB, and measure the resistance of each thermistor using tester.

The relationship between normal temperature and resistance is shown in the graph and the table below.

Temperature (°C)	Thermistor R25°C=20kΩ B=3950
-20	211.0 (kΩ)
-15	150
-10	116.5
-5	88
0	67.2
5	51.9
10	40
15	31.8
20	25
25	20
30	16
35	13
40	10.6
45	8.7
50	7.2




(R25 = 20k Ω 、 B = 3950)



(R1437)


5.1.6 Installation Condition Check

Check No.7




5.1.7 Discharge Pressure Check

Check No.8



5.1.8 Outdoor Unit Fan System Check (With AC Motor)

Check No.9



(R2670)

5.1.9 Power Supply Waveforms Check



Check No.10

Measure the power supply waveform between pins 1 and 3 on the terminal board, and check the waveform disturbance.

- Check to see if the power supply waveform is a sine wave (Fig.1).
- Check to see if there is waveform disturbance near the zero cross (sections circled in Fig.2)

[Fig.1]

[Fig.2]




(R1736)

(R1444)

5.1.10 Inverter Units Refrigerant System Check

Check No.11



(R1445)

5.1.11 Capacitor Voltage Check

Check No.12

< Measuring method >

Before measuring, operate the unit for several minutes, then shut down the operation by force using the circuit breaker.

- If the unit is shut down using the remote controller instead of the circuit breaker, the capacitor discharges the electric load, thus disallowing accurate measurement.



Note: The charge section is applied with high voltage. Therefore, exercise caution during measurement to prevent electric shock.

< Measuring positions >

Take measurements at the power transistor (+) and (-) terminals in the same way as described in section 1.

Set the multi-tester to DC and VOLTAGE RANGE before measurement.

- * Since capacitor (+) and (-) are connected to power transistor (+) and (-), capacitor voltage can be measured at the power transistor (+) and (-) terminals.

5.1.12 Power Transistor Check

Check No.13



Note: Check to make sure that the voltage between the terminal of Power transistor (+) and (-) is approx. 0 volt before checking power transistor.

< Measuring method >


Disconnect the compressor harness connector from the outdoor unit PCB. To disengage the connector, press the protrusion on the connector.

Then, follow the procedure below to measure resistance between power transistor (+) and (-) and the U, V and W terminals of the compressor connector with a multi-tester. Evaluate the measurement results for a pass/fail judgment.

<Power transistor check>

Negative (-) terminal of tester (positive terminal (+) for digital tester)	Power transistor (+)	UVW	Power transistor (-)	UVW
Positive (+) terminal of tester (negative terminal (-) for digital tester)	UVW	Power transistor (+)	UVW	Power transistor (-)
Normal resistance	Several kΩ to several MΩ (*)			
Unacceptable resistance	Short (0 Ω) or open			

<Measuring positions>



5.1.13 Hall IC Check


Check No.16

1. Check the connector connection.
2. With the power ON, operation OFF, and the connector connected, check the following.
 - *Output voltage of about 5 V between pins 1 and 3.
 - *Generation of 3 pulses between pins 2 and 3 when the fan motor is operating.

Failure of (1) → faulty PCB → Replace the PCB.

Failure of (2) → faulty hall IC → Replace the fan motor.

Both (1) and (2) result → Replace the PCB.



(R1968)

Part 7

Removal Procedure

1. Indoor Unit.....	114
1.1 Removal of the Air Filter / Front Panel	114
1.2 Removal of the Horizontal Blade.....	117
1.3 Removal of the Electrical Box	118
1.4 Removal of the PCB.....	121
1.5 Removal of the Heat Exchanger	123
1.6 Removal of the Fan Rotor / Fan Motor.....	125
2. Outdoor Unit.....	127
2.1 Removal of External Casing.....	127
2.2 Removal of Bellmouth and Left Side Plate.....	129
2.3 Removal of PCB and Electrical Box	130
2.4 Removal of Propeller Fan and Fan Motor	136
2.5 Removal of Compressor Noise Absorption Pad.....	138
2.6 Removal of Partition Plate and Reactor	140
2.7 Removal of Four Way Valve and Motor Valve	143
2.8 Removal of Compressor.....	146

1. Indoor Unit



1.1 Removal of the Air Filter / Front Panel




Procedure



Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Appearance	Procedure	Points
1	<p>Appearance</p> <ul style="list-style-type: none"> Enlarged illustration shows operation panel section. 	<p>Top discharge port</p> <p>Front panel (Suction port)</p> <p>Bottom discharge port</p>	<p>Operation panel</p> <p>Signal receiving section</p> <p>(R2604)</p>
2	<p>Remove the front panel from the unit. Push on the left and right upper parts of the panel marked with "PUSH" to open the front panel.</p>		<p>Motion of push lock</p> <p>When push the knob, the lock plate draws in.</p> <p>When push it again, the plate comes out. (R2605)</p> <p>Push lock</p> <p>AIR OUTLET SELECTION</p> <p>(R2606)</p>

Step	Procedure	Points
3	Press down the two hooks located at left and right side upper parts of the air filter, then bend slightly the air filter to remove it.	 <p data-bbox="1378 947 1442 965">(R2607)</p>
4	Unhook the chain.	 <p data-bbox="975 1491 1034 1509">(R2608)</p>





Step	Procedure	Points
5	<p>Disengage the three hooks on the bottom of the front panel.</p> 	
6	<p>Remove the four screws to take out the front grille.</p> 	 <p>■ Mounting screw M4 × 16</p>

1.2 Removal of the Horizontal Blade

Procedure






Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work





Step	Procedure	Points
1	Open the horizontal blade.  <p style="text-align: right;">(R2612)</p>	
2	Disengage the supporting bracket at the center position.  <p style="text-align: right;">(R2613)</p>	
3	Bend the horizontal blade slightly to disengage the shafts at left and right side of the blade.  <p style="text-align: right;">(R2614)</p>  <p style="text-align: right;">(R2615)</p>	<ul style="list-style-type: none"> ■ For installation, engage the supporting bracket at center of the blade after insert the shafts at both ends to the pivot holes.

1.3 Removal of the Electrical Box



Procedure

 **Warning** Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work

Step	Procedure	Points
1	Set the horizontal blade in horizontal position to take out the front grille forward.	
	 <p style="text-align: right;">(R2616)</p>	
2	Remove the setting screw to remove the wire clamp.	
	 <p style="text-align: right;">(R2617)</p>	
3	Disconnect the four connectors of the lead wire.	
	 <p style="text-align: center;">Lead wire for swing motor</p> <p style="text-align: right;">(R2618)</p>	

Step	Procedure	Procedure	Points
4	Remove the room temperature thermistor.		
5	Remove the heat exchanger thermistor.		 <ul style="list-style-type: none"> ■ Be sure not to drop the thermistor retaining spring
6	Dismount the two screws to remove the drip proof plate.		<ul style="list-style-type: none"> ■ Mounting screw M4 × 8

Step	Procedure	Points
7	To remove the electrical box, dismantle the two fixing screws and pull out the box forward.	<ul style="list-style-type: none"> ■ Mounting screw M4 × 16
8	Illustration shows parts in the electrical box.	






1.4 Removal of the PCB

Procedure



Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work






Step	Procedure	Points
<p>1</p> <p>Dismount the fixing screw to remove PCBs from the electrical box.</p>		<p>■ Display PCB</p>
<p>2</p> <p>Illustration shows the control PCB (indoor unit).</p>		<p>(R2627)</p>

Step	Procedure	Points
3	<p>Illustration shows the power supply PCB (indoor unit).</p> 	<ul style="list-style-type: none"> ■ SW2 SW2-1 : unused SW2-2 : unused SW2-3 : unused SW2-4 : OFF - initial set ON - limit upward air flow
4	<p>Illustration shows the service PCB.</p> 	<p><Discharge change-over switch></p>  <ul style="list-style-type: none"> ■ Select  to discharge air only from top discharge port. ■ Select  to discharge air with automatic pattern decided in accordance with operation mode and operation conditions. ■ It is recommendable to select . ■  has been selected before factory shipment.




1.5 Removal of the Heat Exchanger

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work

Step	Procedure	Points
<ul style="list-style-type: none"> ■ Conduct pump-down operation and check that gas has been purged completely before starting service work. 	 <p style="text-align: right;">(R2631)</p>	<ul style="list-style-type: none"> ■ Mounting screw M4 × 16
<p>1 Dismount the two screws to remove the top discharge grille.</p>	 <p style="text-align: right;">(R2632)</p>	<p>Warning! If refrigerant gas leaks during service work, ventilate work area. (Toxic gas may be generated when refrigerant gas contacts with flame.)</p>
<p>2 Remove the heat exchanger.</p>	 <p style="text-align: right;">(R2632)</p>	<ul style="list-style-type: none"> ■ 14/17 double ended wrench
<p>3 Disconnect the flared joint of liquid pipe using two wrenches.</p>	 <p style="text-align: right;">(R2633)</p>	<ul style="list-style-type: none"> ■ 17/23 double ended wrench
<p>4 Disconnect the flared joint of gas pipe using two wrenches.</p>	 <p style="text-align: right;">(R2633)</p>	<p>Caution! Do not contaminate any gas (including air) other than the specified refrigerant (R410A) (Contaminating of air or other gas causes abnormal temperature rise in refrigerating cycle, and this results in pipe breakage or personal injuries.)</p> <ul style="list-style-type: none"> ■ After pipes are disconnected, close all pipe openings with caps to prevent dust and moisture from entering pipes.

Step	Procedure	Points
5	<p>Dismount the fixing screw to remove the pipe retaining plate of the heat exchanger. Push the pipe retaining plate backward to disengage hook, then open the retaining plate using straight edge of screw-driver to remove the plate.</p>	<p>■ Mounting screw M4 × 16</p>
6	<p>Remove the two screws located at left side of the heat exchanger.</p>	<p>■ Mounting screw M4 × 16</p>
7	<p>Pull forward left side of the heat exchanger ①, slide to right to disengage hook ② and remove the heat exchanger.</p>	<p>⚠ Caution! When removing or re-installing heat exchanger, be sure to wear protective gloves or wrap heat exchanger with cloths. (Fins can cut fingers.)</p>










1.6 Removal of the Fan Rotor / Fan Motor

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work

Step	Procedure	Points
1	For removal of the drain pan, disconnect the drain hose, then dismantle the two screws located at left and right sides.	<ul style="list-style-type: none"> ■ Be careful not to wet the floor with drain water.
2	Remove the drain pan.	<ul style="list-style-type: none"> ■ Disengage harness for drain pan from right side hook.
3	To remove the swing motor on discharge port of the drain pan, dismantle the two fixing screws.	<ul style="list-style-type: none"> ■ This swing motor is for down flow shutter.



Step	Procedure	Procedure	Points
4	Dismount the six screws (three for the upper side motor and three for the bottom one) to remove the fan motors.	 <p style="text-align: right;">(R2640)</p>	<ul style="list-style-type: none"> ■ Short lead wire: for the upper fan motor Long lead wire: for the bottom fan motor ■ Mounting screw M4 × 16
5	Remove the motors and cross flow fans.	 <p style="text-align: right;">(R2641)</p>	<ul style="list-style-type: none"> ■ Loosen the fixing screw to separate the fan and motor.
6	To remove the casing, dismount the four screws at front side and the other four screws at rear side.	 <p style="text-align: right;">(R2642)</p>	<ul style="list-style-type: none"> ■ Casing mounting screw Front: M4 × 16 Rear: M4 × 14 <p>Condition : Casing</p> <ul style="list-style-type: none"> Protruded : Not to be removed Semi-sink : To be removed Sink : Not to be removed

2. Outdoor Unit





2.1 Removal of External Casing

Procedure



Warning Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
<p>1</p> <p>The stop valve cover can be removed when the fixed screw is removed.</p>		<p>(R1450)</p> <ul style="list-style-type: none"> ■ As three hooks are provided, slide the cover downward to remove. ■ The forced cooling operation in the pumping down mode can be carried out by pushing the operation switch on the main unit for five seconds. (The existing models can do it through the switch on the PC board just as well.) ■ The layout of the connection ports for the flares has been changed to horizontal position from vertical position.
<p>2</p> <p>The top plate and the front plate are constructed in a monoblock. Remove the three screws on the right side and the two screws on the front plate.</p>		



Step		Procedure	Points
3	Remove the three screws on the left side.		
4	Remove the one fixed screw in the rear of the top plate. Once lift the top plate and then remove it forward.		<ul style="list-style-type: none"> ■ The left side plate and the bellmouth can be removed all at once. ■ When restoring the top plate, move it horizontally and get it down for the easy work.
5	The front plate and the left side plate can be removed when the one fixed screw is removed.		<ul style="list-style-type: none"> ■ Sectional view at the front. 

2.2 Removal of Bellmouth and Left Side Plate

Procedure



Warning Be sure to turn off all power supplies at least 10 min. before disassembling work.



Step	Procedure	Points
1	<p>The bellmouth is attached to the front plate with two screws and four hooks.</p>  <p style="text-align: right;">(R1456)</p>	<ul style="list-style-type: none"> ■ Remove the bellmouth from the front plate after removing the two screws which are set below.
2	<p>Remove the two screws and undo the four hooks to release the bellmouth.</p>  <p style="text-align: right;">(R1457)</p>	<ul style="list-style-type: none"> ■ Slide the bellmouth in the arrow direction to disengage the hook B.

2.3 Removal of PCB and Electrical Box




Procedure







Warning Be sure to turn off all power supplies at least 10 min. before disassembling work.



Step	Procedure	Points
<p>1. Remove the shelter.</p> <p>1 Undo the five hooks and remove the shelter.</p>	 <p>(R1458)</p>	<ul style="list-style-type: none"> ■ The shelter has five hooks. ■ Be sure to avoid forgetting to restore the shelter and to avoid losing or damaging it.
<p>2. Remove the PCB.</p> <p>1 Disconnect the ground wire.</p>	 <p>Ground wire plug</p> <p>(R1459)</p> <p>(R1460)</p>	




Step	Procedure	Points
2	Remove the four screws fixing the PCB.	
3	Disconnect the six wire harness.	
4	Disconnect the two connectors of the reactor.	<ul style="list-style-type: none"> ■ There is another reactor located on bottom frame. ■ Fasten clamp materials as before when re-assembling.



Step	Procedure	Points
<p>5 Undo the eight hooks and the PCB can be disengaged.</p>	 <p>(R1464)</p>	<p>■ The PCB has eight hooks.</p>
<p>6 Disconnect the three wires from the PCB.</p>	 <p>(R1465)</p>	

Step	Procedure	Points
7	<p>The PCB can completely be released.</p>  <p>(R1466)</p>	
3.	<p>Remove the electrical box.</p>	
1	<p>Remove the two screws fixing the electrical box.</p>  <p>(R3053)</p>	

Step		Procedure	Points
2	Lift and remove the electrical box.	 <p>(R1468)</p>	
4.	Remove the molded interconnect device (MID) .	 <p>(R1469)</p>	
1	Remove the one screw fixing the MID.		





Step	Procedure	Points
2	<p data-bbox="204 215 451 275">Slide the MID upward and release.</p>  <p data-bbox="1093 645 1153 667">(R1470)</p>  <p data-bbox="986 1126 1046 1149">(R1471)</p>  <p data-bbox="986 1552 1046 1574">(R1472)</p>	


2.4 Removal of Propeller Fan and Fan Motor

Procedure



Warning Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
<ul style="list-style-type: none"> ■ Disconnect the fan motor connector S70. 	 <p style="text-align: right;">(R1473)</p>	<ul style="list-style-type: none"> ■ Remove the external plates and the drip proof cover protecting the electric parts.
<p>1 Release the lead-wires of the fan motor from the groove of the switch box.</p> <p>2 The propeller fan can be removed when the washer faced nut (M8) is removed.</p>	 <p style="text-align: right;">(R1474)</p>	 <p style="text-align: right;">(R1475)</p> <ul style="list-style-type: none"> ■ Be sure to avoid forgetting to restore the shelter and to avoid losing or damaging it.
<p>3 Remove two screws for removing the fan motor. The lead wires are disengaged by raising the hooks which fix the lead wires.</p>	 <p style="text-align: right;">(R1476)</p>	<ul style="list-style-type: none"> ■ When restoring, match the ▼ mark of the propeller fan with the D-cut of the motor shaft. ■ The fan should be restored so that the mark ● will be at upper part of the fan motor.





Step	Procedure	Points
4	<p data-bbox="204 215 464 241">Remove the fan motor.</p>  <p data-bbox="986 752 1050 779">(R1477)</p>	




2.5 Removal of Compressor Noise Absorption Pad

Procedure



Warning Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
<p>1. Remove the right side plate.</p> <p>1 Remove the three screws for removing the right side plate.</p> <p>2 Lift the right side plate to disengage the hooks.</p>	 <p>(R1478)</p>  <p>(R1479)</p>	<p>■ Insert the three hooks for the restoration.</p>  <p>(R1480)</p>
<p>2. Remove the noise absorber.</p> <p>1 Untie the string fixing the noise absorption pad for the body to the compressor.</p>	 <p>(R1481)</p>	<p>■ Since the slit prepared for the piping connection on the noise absorption pad is torn easily, remove the pad carefully.</p> <p>■ When restoring, the noise absorption pad should pass the internal side of the piping.</p>



Step	Procedure	Points
2	<p>Pull out the noise absorption pad for the body.</p> 	
3	<p>Pull out the top pad of the noise absorption (a).</p> 	<p>(R1482)</p> <ul style="list-style-type: none"> ■ Since the slit prepared for the piping on the noise absorption pad is torn easily, remove the pad carefully.
4	<p>Pull out the noise absorption pad (b).</p> 	<ul style="list-style-type: none"> ■ When restoring, the noise absorption pad should pass the internal side of the piping.




2.6 Removal of Partition Plate and Reactor


Procedure



Warning Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
1. Remove the partition plate.		
1 Remove the two screws fixing the partition plate.	 <p>(R1485)</p>	
2 Pull the partition plate upward to remove.	 <p>(R1486)</p>	

Step	Procedure	Points
3	<p>When restoring the partition plate, fit the hook into the bottom frame.</p>  <p style="text-align: right;">(R1487)</p>	
2. Remove the reactor.		
1	<p>The reactor can be released by removing the fixed screw.</p>  <p style="text-align: right;">(R1488)</p>	
3. Remove the reactor assembly.		
1	<p>Remove the one screw fixing the reactor assembly to the bottom frame.</p>  <p style="text-align: right;">(R1489)</p>	

Step	Procedure	Points
2	<p>Slide the reactor assembly this side and release.</p>  <p style="text-align: right;">(R1490)</p>	




2.7 Removal of Four Way Valve and Motor Valve



Procedure



Warning Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
1. Remove the parts around the four way valve.	<p>(R1491)</p>	
1 Remove the terminal cover and the lead wires of the compressor so as not to be burnt out by a gas brazing machine. 2 Remove the thermistor for the heat exchanger.	<p>(R1492)</p>	<ul style="list-style-type: none"> ■ The thermistor for the heat exchanger is fixed by a clamp material at one portion. Be sure to fix the thermistor back on the original position when restoring. <p>Warning! Ventilate when the refrigerant leaks during the work. (If the refrigerant is exposed to the fire, it will cause toxic gas.)</p>
3 Remove the four way valve's coil.	<p>(R1493)</p>	<ul style="list-style-type: none"> ■ Pay attention so as not to loose the retainer for the thermistor.

Step	Procedure	Points
4	<p>Remove the motor valve coil.</p>  <p style="text-align: right;">(R1494)</p>	
<p>■ Confirm that the refrigerant is completely empty in the refrigerant circuit before starting work.</p>		
<p>5 Provide a protective sheet or a steel plate so that the brazing flame can't influence the circumstance around the four way valve.</p> <p>6 Heat up the four portions of brazing parts on the four way valve. Remove the four way valve (a), (b), (c), (d).</p>	 <p style="text-align: right;">(R1495)</p>  <p style="text-align: right;">(R1496)</p>	<p>⚠ Caution Be careful about four-way valve, pipes and so on, which were heated up by a gas brazing machine, so as not to get burnt on your hands.</p> <p>Cautions at the restoration.</p> <ol style="list-style-type: none"> 1. Restore the piping by non-oxidation brazing. Braze it quickly unless nitrogen gas can be used. 2. It is required to prevent the carbonization of the oil inside the four way valve and the deterioration of the gaskets affected by heat. For the sake of this, wrap the four way valve with wet cloth and make up water so that the cloth will not be dried and avoid excessive heating. (It keeps below 120°C). <p>■ Be careful so as not to break pipes by pressing the pipes excessively by pliers when withdrawing the piping.</p>



Step	Procedure	Points
7	<p>Heat up the brazing parts and withdraw the pipes connected to the four way valve by pliers and so on.</p>  <p>(R1497)</p>	<p>In case that the removal seems to be hard;</p> <ol style="list-style-type: none"> 1. Remove the piping connection part (brazing part) which is easy to remove and restore. 2. Cut the pipes on the main unit by a miniature copper tube cutter in order to make it easy to remove. <p>NOTE: Don't use a metal saw for cutting pipes by all means because the chips come into the circuit.</p>
8	<p>Heat up the two portions of brazing parts on the motor valve and remove.</p>  <p>(R1498)</p>	<p>Cautions at the restoration. Wrap the motor valve with wet cloth and make up water so that the cloth will not be dried and avoid excessive heating.</p> <p> Caution Be careful about four way valve, pipes and so on, which were heated up by a gas brazing machine, so as not to get burnt on your hands.</p>


2.8 Removal of Compressor



Procedure



Warning Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
<p>1. Remove the parts around the compressor.</p>	 <p>Terminal cover</p> <p>(R1499)</p>  <p>(R1500)</p>	<ul style="list-style-type: none"> ■ Be careful so as not to burn the compressor terminals or the name plate.

Step	Procedure	Points
2 3	<p data-bbox="201 219 459 309">The mounting nut for the compressor is only one piece.</p> <p data-bbox="201 320 459 387">Remove the nut by an open-end wrench.</p>  <p data-bbox="628 958 740 981">Mounting nut</p> <p data-bbox="995 958 1059 981">(R1501)</p>	<ul style="list-style-type: none"><li data-bbox="1094 219 1453 309">■ Remove the four way valve and the motor valve also so as not to be burnt out.

Step	Procedure	Points
<ul style="list-style-type: none"> ■ Confirm that the refrigerant is completely empty in the refrigerant circuit before starting work. 		
<ul style="list-style-type: none"> ■ Be sure to apply nitrogen's replacement when heating up the brazing part. 		
<ol style="list-style-type: none"> 1 Remove the brazing part on the discharge side of the compressor. 2 Heat up the brazing part on the suction side of the compressor and then remove it. 3 Lift the compressor and remove it. 	<div style="text-align: center;">  <p>Protective sheet or steel plate. (R1738)</p> </div> <div style="text-align: center; margin-top: 20px;">  <p>Protective sheet or steel plate. (R1739)</p> </div>	<div style="margin-bottom: 20px;"> <p>Warning! Since it may happen that refrigeration oil in the compressor will catch fire, prepare wet cloth so as to extinguish the fire quickly.</p> </div> <div style="margin-bottom: 20px;"> <p>Warning! Ventilate when the refrigerant leaks during the work. (If the refrigerant is exposed to the fire, it will cause toxic gas).</p> </div> <div style="margin-bottom: 20px;"> <p>Caution Be careful about pipes and so on, which were heated up by a gas brazing machine, so as not to get burnt on your hands.</p> </div> <div> <ul style="list-style-type: none"> ■ Pay attention so that the fins of the heat exchanger will not be burnt. </div>

Part 8


Appendix

1. Piping Diagrams.....	150
1.1 Indoor Units.....	150
1.2 Outdoor Units.....	151
2. Wiring Diagrams.....	153
2.1 Indoor Units.....	153
2.2 Outdoor Units.....	154

1. Piping Diagrams

1.1 Indoor Units


FVKS25BVMB, FVKS35BVMB, FVXS25BVMB, FVXS35BVMB




4D034714A

1.2 Outdoor Units


RKS25BVMB



RKS35BVMB




RXS25BVMC



3D039301

RXS35BVMC




3D039302

2. Wiring Diagrams

2.1 Indoor Units


FVKS25BVMB, FVKS35BVMB, FVXS25BVMB, FVXS35BVMB




3D034713A

2.2 Outdoor Units

RKS25BVMB, RKS35BVMB –Cooling Only–



RXS25BVMB, RXS35BVMB –Heat Pump–



Index

Numerics

00	73
3 Minutes Stand-by	32

A

A1	74
A5	75
A6	77
Air Filter	114
Air Flow Direction	55
Air Flow Selection	17
Air Purifying Filter	24
ARC433A series	72
AUTO·DRY·COOL·HEAT·FAN Operation	53
Automatic Operation	20
Auto-restart Function	25
Auto-swing	16

B

Bellmouth	129
-----------------	-----

C

C4	79
C7	80
C9	79
Capacitor Voltage Check	111
Care and Cleaning	63
Compressor	146
Compressor Lock	83
Compressor Noise Absorption Pad	138
Compressor Overload	82
Compressor Protection Function	32
Control PCB	9
control PCB	121
CT or Related Abnormality	89

D

Defrost Control	37
Discharge Pipe	39
Discharge Pipe Control	33
Discharge Pipe Temperature	40
Discharge Pipe Temperature Control	87
Discharge pipe temperature thermistor	92
Discharge Pipe Thermistor	27, 28, 39
Discharge Pressure Check	108
Display PCB	9, 121

E

E5	82
E6	83
E8	84
EA	85
Electrical Box	118, 130
electrical box	133
Electrical Box Temperature Rise	93

Electronic Expansion Valve Check	105
Electronic Expansion Valve Control	38
Error Codes and Description	73
External Casing	127

F

F3	87
F6	102
Fan Control	35
Fan Motor	125, 136
Fan Motor (DC Motor)	77
Fan Motor Connector Output Check	104
Fan Rotor	125
Fan Speed Control for Indoor Units	18
Flap Control	16
Forced Operation Model	42
Four Way Valve	143
Four Way Valve Abnormality	85
Four Way Valve Operation Compensation	32
Four Way Valve Performance Check	106
Four Way Valve Switching	32
Freeze-up Protection Control	34, 75
Frequency Control	30
Frequency Principle	14
Front Panel	114
FU	8
Functions	2

H

H6	88
H8	89
H9	91
Hall IC Check	112
Heat Exchanger	123
Heat exchanger temperature thermistor	79
heat exchanger thermistor	119
Heating Peak-cut Control	34
High Pressure Control	75
High Pressure Control in Cooling	102
HOME LEAVE Operation	59
Home Leave Operation	22
Horizontal Blade	117
Hot Start Function	24

I

Indoor Heat Exchanger Thermistor	27, 28
Indoor Unit PCB Abnormality	74
Input Current Control	33
Input Over Current Detection	84
Installation Condition Check	108
Insufficient Gas	99
Insufficient Gas Control	41
Inverter Powerful Operation	23
Inverter Units Refrigerant System Check	110

J		
J3	91
J6	91
L		
L3	93
L4	95
L5	97
LED11	8
LED12	8
LED14	8
Left Side Plate	129
Limit Switch Continuity Check	104
Louvres	16
M		
Mode Hierarchy	29
Moisture Protection Function 2	36
Moisture Protection Function 1	35
Mold Proof Air Filter	24
molded interconnect device (MID)	134
Motor Valve	143
N		
Names of Parts	47
Night Set Mode	21
O		
OL Activation	82
ON/OFF Button on Indoor Unit	24
Operation Lamp	70
Outdoor air temperature thermistor	92
Outdoor Heat Exchanger Thermistor	27, 28
Outdoor Unit Fan System Check (With AC Motor)	109
Outdoor unit heat exchanger temperature thermistor	92
Outdoor Unit Silent Operation	58
Output Over Current Detection	97
Over Current	41
Over Load	41
Over-voltage Detection	101
P		
P4	91
Partition Plate	140
PCB	121, 130
PCB (1)	11
PCB (2)	11
Photocatalytic Deodorizing Filter	24
PI Control	31
Piping Diagrams	150
Position Sensor Abnormality	88
Power Supply PCB	8
power supply PCB	122
Power Supply Waveforms Check	110
Power Transistor Check	111
POWERFUL Operation	57
Powerful Operation Mode	42
Preheating Operation	32
Preparation before Operation	50
Printed Circuit Board Connector Wiring Diagram	8
Problem Symptoms and Measures	71
Programme Dry Function	19
Propeller Fan	136
R		
Radiation Fin Temperature Rise	95
Radiation fin thermistor	92
Reactor	140
Room temperature thermistor	79
S		
S10	10
S11	10
S201	8
S202	8
S203	8
S204	8
S23	8
S24	8
S25	8
S26	8
S30	10
S301	8
S302	8
S31	8
S32	8
S6	8
S7	8
S70	10, 136
S8	8
S80	10
S90	10
Self-Diagnosis Digital Display	25
Sensor Malfunction Detection	41
Service Check	72
service PCB	122
shelter	130
Shutter Drive Motor	80
Shutter Limit Switch	80
Signal Receiver PCB	9
Signal Receiving Sign	24
Signal Transmission Error (between Indoor and Outdoor Units)	81
Specifications		
Cooling Only	4
Heat Pump	5
stop valve cover	127
SW2	122
T		
Thermistor or Related Abnormality (Indoor Unit) ...	79	
Thermistor or Related Abnormality (Outdoor Unit)	91
Thermistor Resistance Check	107
TIMER Operation	61
Trouble Shooting	66
Troubleshooting	73
U		
U0	99

U2	101
U4	81
V	
V1	8
Voltage Detection Function	42
W	
Wiring Diagrams	153

Drawings & Flow Charts

A			
ARC433A series	72	Inverter Powerful Operation	23
Automatic Air Flow Control for Cooling	18	Inverter Units Refrigerant System Check	110
Automatic Air Flow Control for Heating	18	L	
Automatic Operation	20	Limit Switch Continuity Check	104
Auto-swing	16	Location of Operation Lamp	70
C		M	
Compressor Lock	83	Main Structural Parts	
Compressor Protection Function	32	Cooling Only Model	26
Control PCB	9	Heat Pump Model	26
CT or Related Abnormality	89	Mode Hierarchy	29
D		Moisture Protection Function 1	35
Defrost Control	37	N	
Detail of PCB (1)	11	Night Set Mode	21
Detail of PCB (2)	11	O	
Discharge Pipe Control	33	OL Activation (Compressor Overload)	82
Discharge Pipe Temperature Control	87	ON/OFF Button on Indoor Unit	24
Discharge Pressure Check	108	Outdoor Unit Fan System Check	
Display PCB	9	(With AC Motor)	109
E		Outline of PCB	10
Electrical Box Temperature Rise	93	Output Over Current Detection	97
Electronic Expansion Valve Check	105	Over-voltage Detection	101
Electronic Expansion Valve Control	38	P	
F		Piping Diagrams	
Fan Motor (DC Motor) or Related Abnormality	77	Indoor Units	150
Fan Motor Connector Output Check	104	Outdoor Units	151
Four Way Valve Abnormality	85	Position Sensor Abnormality	88
Four Way Valve Performance Check	106	Power Supply PCB	8
Freeze-up Protection Control	34	Power Supply Waveforms Check	110
Freeze-up Protection Control or High Pressure		Power Transistor Check	111
Control	75	Programme Dry Function	19
Frequency Control	30	R	
Frequency Principle	14	Radiation Fin Temperature Rise	95
Function of Thermistor		S	
Cooling Only Model	28	Shutter Drive Motor / Shutter Limit Switch	
Heat Pump Model	27	Abnormality	80
H		Signal Receiver PCB	9
Hall IC Check	112	Signal Transmission Error	
Heating Peak-cut Control	34	(between Indoor and Outdoor Units)	81
High Pressure Control in Cooling	102	T	
Home Leave Operation	22	Target Discharge Pipe Temperature Control	40
I		Thermistor or Related Abnormality (Indoor Unit) ..	79
Indoor Unit PCB Abnormality	74	Thermistor or Related Abnormality	
Input Current Control	33	(Outdoor Unit)	91
Input Over Current Detection	84	Thermistor Resistance Check	107
Installation Condition Check	108		
Insufficient Gas	99		
Insufficient Gas Control	41		
Inverter Features	15		

W

Wiring Diagrams

Indoor Units	153
Outdoor Units	154

DAIKIN INDUSTRIES, LTD.

Head office:

Umeda Center Bldg., 4-12, Nakazaki-Nishi 2-chome,
Kita-ku, Osaka, 530-8323 Japan

Tokyo office:

Shinjuku Sumitomo Bldg., 6-1 Nishi-Shinjuku
2-chome, Shinjuku-ku, Tokyo, 163-0235 Japan

DAIKIN EUROPE NV

Zandvoordestraat 300, B-8400 Oostende, Belgium