

ESIE15-11B

Service Manual

VRV4 indoor units



The present publication is drawn up by way of information only and does not constitute an offer binding upon Daikin Europe N.V. Daikin Europe N.V. has compiled the content of this publication to the best of its knowledge. No express or implied warranty is given for the completeness, accuracy, reliability or fitness for particular purpose of its content and the products and services presented therein. Specifications are subject to change without prior notice. Daikin Europe N.V. explicitly rejects any liability for any direct or indirect damage, in the broadest sense, arising from or related to the use and/or interpretation of this publication. All content is copyrighted by Daikin Europe N.V.



Table of contents

Part 1. Introduction	5
1. Version log	5
2. System description	6
2.1. General system layout of a VRV heat recovery system	6
3. General operation of VRV heat recovery system	9
4. How to use this book	10
4.1. Interactive information flow	

Part 2. Troubleshooting	11
1. How to retrieve error code and data?	11
1.1. Wired remote controller BRC1D	
1.1.1. Access to error code	
1.1.2. Access to inspection menu	
1.1.3. Access to Service menu	
1.2. Wired remote controller BRC1/2/3E	
1.2.1. Access to error code	
1.2.2. Access to service menu	
1.3. Wireless controller BRC4/7	
1.3.1. Access to error code	
2. Error code based troubleshooting	

Part 3. Field settings	21
1. Wireless remote controller BRC4C and BRC7C/E	21
1.1. Access field settings	21
2. Wired remote controller BRC2/3E52	22
2.1. Access field settings	
2.2. Field settings, specific for wired remote controller BRC2/3E52	25
3. Wired remote controller BRC1D51/52	27
3.1. Access field settings	
3.2. Field settings, specific for BRC1D51/52	
4. Wired remote controller BRC1E51	30
4.1. Access field settings	30
4.2. Field settings, specific for BRC1E51	32
5. Wired remote controller BRC1E52	35
5.1. Access field settings	35
5.2. Field settings, specific for BRC1E52	
6. General indoor units	41
7. Presence sensor BRYQ140A7 (for 3x3 cassette) / BRYQ60A7 (for 2x2 cassette)	46
8. Selfcleaning panel BYCQ140D7G	47
9. Aircurtain CAV/CYV	48
10. VKM	48
11. FXSQ-A / FXNQ-A / FXDQ-A / FXMQ-P/MB / FXTQ-A	51
12. Factory settings	53
12.1. How to perform factory reset of settings through remocon	53
12.2. Field settings as per type indoor unit	55





Part 1. Introduction

1. Version log

Version code	Description	Date
ESIE15-11	Release	10/12/15
ESIE15-11A	Add error codes A0, A1, A7, A9-01, A9-02, UE	23/09/16
ESIE15-11B	Addition of model FXAQ-A (no changes compared to FXAQ-P except casing)	04/09/17



2. System description

This system description explains the concept of the VRV4 H/R. All settings in this book however, are applicable to indoor units that can be connected to VRV4 HP, mini-VRV4, VRV i-series, VRV4 high ambient and VRV4 water-cooled.

2.1. General system layout of a VRV heat recovery system

The VRV heat recovery system consists of 3 different types of units:

- outdoor unit(s)
- BS unit (Branch Selector unit)
- indoor units.



- One to maximum three modules of VRV4 heat recovery outdoor unit can be connected using the optional refnet "BHFQ23P...".
- Field piping must be thermally insulated copper piping, connected to a combination of "Single circuit BS" unit(s), or/and "Multi circuit BS" unit(s).
- The "Single circuit BS" unit offers 1 change-over circuit. A "Multi circuit BS" unit offers 4, 6, 8, 10, 12 or 16 outlets.
- To split the refrigerant circuit between outdoor unit(s) and the different BS units, Daikin optional accessory refnets (reference "KHRQ23M...") are used.
- Behind the BS unit, one or more indoor units can be connected. To split the refrigerant circuit to the different indoor units to the same BS unit, Daikin optional accessory refnets (reference "KHRQ22M...") are used.
- The HT (high temperature) hydrobox is connected without BS unit: only use the HP (high pressure) gas line and the liquid line.



- 1. Outdoor units exist in different capacities. Two types of casings are used:
 - "Medium" casing: REMQ5T7Y1B, REYQ8~12T7Y1B
 - "Large" casing: REYQ14~20T7Y1B
 - The unit REYQ8~20T7Y1B can be used as "single" unit or combined into a "multi" outdoor combination of maximum three units (refer to databook).
 - The unit REMQ5T7Y1B can only be used in multi 2* REMQ5T7Y1B or REMQ5T7Y1B + REYQ8T7Y1B.



"Large" casing



"Medium" casing



- 2. BS "branch selector" units exists in:
 - "Single circuit" BS units: 3 capacities available depending on total capacity indoor units:
 - BS1Q10A: indoor index below 100 (100 not included).
 - BS1Q16A: indoor index from 100 and below 160.
 - BS1Q25A: indoor index from 160 till 250 (250 included).



BS1Q10, 16, 25A

- "Multi circuit" BS units:

•

- The maximum number of circuits depend on the model:
 - BS4Q14A: maximum 4 circuits.
 - BS6Q14A: maximum 6 circuits.
 - BS8Q14A: maximum 8 circuits.
 - BS10Q14A: maximum 10 circuits.
 - BS12Q14A: maximum 12 circuits.
 - BS16Q14A: maximum 16 circuits.



BS10Q14A

- Each circuit can have:
 - Maximum five indoor units.
 - Maximum index 140.
- 3. Indoor units:

•

- The current available type VRV DX units can be used. Minimum 50% of outdoor index must be connected through BS unit(s).
- The LT (low temperature) hydro unit can be added (BS unit required).
- The HT hydro unit can be added (without BS unit).



3. General operation of VRV heat recovery system



- When indoor unit is selecting heating mode, discharge gas is supplied by the outdoor unit(s) into the dual pressure line through EVH (high pressure expansion valve) fully opened in the BS unit to the indoor unit.
- When indoor unit is selecting cooling mode, suction gas returns from indoor unit gas line through EVL (low pressure expansion valve) fully opened in the BS unit to the outdoor unit.
- Indoor unit in cooling controls the indoor expansion valve on suction superheat (SH) by comparing gas and coil sensor on indoor unit.
- Indoor unit in heating controls the indoor expansion valve on liquid sub-cool (SC) by comparing Tc (outdoor condensing temperature) derived from reading of high pressure sensor, and indoor coil temperature.
- When indoor unit requires change over between cooling and heating, the switching between suction and discharge line is
 performed only in the BS unit that received the request of indoor unit to change over. Change over sequence is explained in
 "General built up VRV4 BS unit".
- Outdoor can switch outdoor heat exchanger separately condenser/evaporator in function of unbalance between cooling and heating demand indoor side.



4. How to use this book

4.1. Interactive information flow

This Daikin product Service Manual is intended for professional use only. The actions described hereafter, are only to be performed by qualified and certified persons.

By following the diagram below, the reader can find the relevant information related to his/her task. The digital (pdf) version of this book allows direct page access through all active links. When Adobe Acrobat Reader is used, the <Alt> + <Back Arrow> keys can be used to return to the previously viewed page.





Part 2. Troubleshooting

This part contains the following chapters:

1. How to retrieve error code and data?11	
2. Error code based troubleshooting18	

1. How to retrieve error code and data?

1.1. Wired remote controller BRC1D



1.1.1. Access to error code

If operation stops due to malfunction, the remote controller's operation LED blinks, and malfunction code is displayed. (Even if stop operation is carried out, malfunction contents are displayed when the inspection mode is entered.)

The malfunction code enables you to tell what kind of malfunction caused operation to stop.

1.1.2. Access to inspection menu

In the inspection menu, you can check the error codes, indoor unit model code, outdoor unit model code and start test operation if required.

To enter Inspection menu, push the TEST button once. The symbol of an eye (inspection) will light up on the remote controller display.







VRV III

888

898

858

Heat Pump Series

VRV III Heat Recovery Series

VRV III-C Heat Pump Series

Cooling Only Series

RXYQ-P

RXQ-P

REYQ-P

RTSYQ-PA

1.1.3. Access to Service menu

When there is no error displayed but unit is behaving strangely, you can also check some more operational data in the Service mode.

How to access the Service menu:



In the Service menu you can find below information:

Mode No	Function	Contents and operation method	Remote controller display example
ΥΩ	Malfunction history	Display malfunction history.	
	display	The history No. can be changed with the 👌 but- ton.	Unit 1 Malfunction code 2-U4 Malfunction code History No: 1 - 9 1: Latest
41	Display of sensor	Display various types of data.	
	and address data	Select the data to be displayed with the button. Sensor data 0: Thermostat sensor in remote controller. 1: Suction (or level if DDC-controller connected. 00 = level 1 etc.) 2: Liquid pipe 3: Gas pipe Address data 8: Cool/heat group address 9: Demand / low noise address	Sensor data display Unit No. Sensor type 1 1 27 Temperature °C Address display Unit No. Address type 1 8 1 Address type Address type
43	Forced fan ON	Manually turn the fan ON by each unit. (When you want to search for the unit No.) By selecting the unit No. with the Determined button, you can turn the fan of each AHU on (forced ON) individually.	Unit 1 (VE009)

Switching between Mode number 40-41-43 is done by pushing the up and down button. To return to normal operation: push the test button one time.



1.2. Wired remote controller BRC1/2/3E



1.2.1. Access to error code

If operation stops due to malfunction, the remote controller's operation LED blinks, and malfunction code is displayed.

The malfunction code enables you to tell what kind of malfunction caused operation to stop.

	Operation Status	Display	
Abnormal shutdown	The system stops operating.	The operation lamp (green) starts to blink. The message "Error: Press Menu button" will appear and blink at the bottom of the screen.	Cool Set temperature 28°C Error: Press Menu Button
Warning	The system continues its operation.	The operation lamp (green) remains on. The mes- sage "Warning: Press Menu button" will appear and blink at the bottom of the screen.	Cool Set temperature 28°C Warning: Press Menu Button



1.2.2. Access to service menu

When there is no error displayed but unit is behaving strangely, you can also check some more operational data in the Service menu.

How to access the Service menu:





Below items can be consulted in the Service Menu:

Service Menu	Item 2	Remarks	
1. Model Name Display	1. Unit No.	Select the Unit No. you want to check.	
	2. Indoor unit		
	3. Outdoor unit		
2. Operating Hours Display	1. Unit No.	Select the Unit No. you want to check.	
	2. Indoor unit operating time	All of these are displayed in hours.	
	3. Indoor unit fan operation		
	4. Indoor unit energized time		
	5. Outdoor operating time		
	6. Outdoor unit fan 1 operation		
	7. Outdoor unit fan 2 operation		
	8. Outdoor comp. 1 operation		
	9. Outdoor comp. 2 operation		
3. Indoor Status Display 1/2	1. Unit No.	Select the Unit No. you want to check.	
	2. FAN	Tap, speed (rpm)	
	3. FLAP	Swing, fixed	
	4. Speed	Fan speed (rpm)	
	5. EV	Degree that electronic expansion valve is open (pls)	
	6. MP	Drain pump ON/OFF	
	7. 52H	Electric heater ON/OFF	
	8. Hu	Humidifier ON/OFF	
	9. Anti-freezing	Anti-freezing control ON/OFF	
3. Indoor Status Display 2/2	1. Unit No.	Select the Unit No. you want to check.	
		VRV	
	2. Th1	Suction air thermistor	
	3. Th2	Heat exchanger liquid pipe thermistor	
	4. Th3	Heat exchanger gas pipe thermistor	
	5. Th4	Discharge air thermistor	
	6. In5	—	
	7. In6		
4. Outdoor Status Display	1. Unit No.	Select the Unit No. you want to check.	
		Compressor power supply frequency (Hz)	
	4. EV1		
	5. 501		
	6 Th1		
	7 Th2		
	8 Th3		
5 Error Display Selection	1 Warning display ON	Displays a warning on the screen if an error occurs	
S. Error Display Sciection	2 Warning display OFF	No warning is displayed	
	3 Error display ON	Displays the error on the screen	
	4 Error display OFF	Displays neither errors nor warnings	
6 Unit No. Transfer	1 Current Unit No	A unit No. can be transferred to another	
	2. Transfer Unit No		
7. Sensor Address Display	O Unit No.: 0 - 15	Select the Unit No. you want to check.	
	O Code		
	00.	Remote controller thermistor (°C)	
	01:	Suction air thermistor ($^{\circ}$ C)	
	02:	Host evelopeer liquid nine thermister (°C)	
	02.	Heat exchanger liquid pipe thermistor (°C)	
	03:	Heat exchanger gas thermistor (°C)	
	04:	Indoor unit address No.	
	05:	Outdoor unit address No.	
	06:	BS unit address No.	
	07:	Zone control address No.	
	08:	Cooling/heating batch address No.	
	09:	Demand/low-noise address No.	
	O Data	The corresponding data will be displayed, based on the	
		Unit No. and Code selected.	



1.3. Wireless controller BRC4/7

1.3.1. Access to error code

If a unit stops due to an error, the operation indicating LED on indoor unit is blinking. The error code can be determined by following the procedure described below.

1	Press the INSPECTION/TEST button to select "inspection". The equipment enters the inspection mode. The "Unit" indication is displayed and the Unit No. display shows blinking "C" indication.	
2	Set the Unit No. Press the UP or DOWN button and change the Unit No. display until the buzzer (*1) is generated from the indoor unit.	
	*1 Number of beeps	
	3 short beeps: Conduct all of the following operations.	
	1 short beep: Conduct steps 3 and 4.	
	Continue the operation in step 4 until a buzzer remains ON. The continuous buzzer indicates that the error code is confirmed.	
	Continuous beep: No abnormality.	
3	Press the MODE selector button.	ON/OFF
	The left " \mathcal{G} " (upper digit) indication of the error code blinks.	
4	Error code upper digit diagnosis	
	Press the UP or DOWN button and change the error code upper digit until the error code match-	
	ing buzzer (*2) is generated.	
	The upper digit of the code changes as shown below when the UP and DOWN buttons are pressed.	
	⇒ "UP" button 🖛 "DOWN" button	
	*2 Number of beeps	
	Continuous beep: Both upper and lower digits matched. (Error code confirmed)	
	2 short beeps: Upper digit matched.	
	1 short beep: Lower digit matched.	
5	Press the MODE selector button.	
	The right " G " (lower digit) indication of the error code blinks.	
6	Error code lower digit diagnosis	
	Press the UP or DOWN button and change the error code lower digit until the continuous error code matching buzzer (*2) is generated.	
	The lower digit of the code changes as shown below when the UP and DOWN buttons are pressed.	
	▖▎▎▖▕▖▔▎▖▔▎▖▔▎▖▔▎▖▔▎▖▔▎▖▌▝▖▌▝▖▌▝▖▌▝▖▌▝▖▌▝▖▌▝▖▌ ▖▕▌╺▖▎▖Ĺ。▖▔▎▖▔▎▖▔▎▖▁▎▖▌▝▖▌▝▖▌▝▖▌▝▖▌▝▖▌▝▖▌▝▖▌▝▖▌▔ ▖	
	⇔ "UP" button	

No further information can be retrieved through the wireless controller BRC4/7.



Г

2. Error code based troubleshooting

	Error code				
Main	Sub	Status outdoor	Reset	Cause	Solution
A0	-	Thermo off O	Power off/on	Fault board	Check setting 22-1-3: T1-T2 NC. If correct, indoor board fault.
A1	-	Thermo off O	Power off/on	Fault Eeprom	Replace board.
A3	-	Cool thermo off	Auto recovery	Float switch open during thermo on (cooling)	Check float switch status, drain pipe no blockage, drain pipe raiser < 600 mm.
A6	01	Thermo off	BRC1	Fan motor locked	Rpm counter no signal from motor to indoor main board when output.
	10	Thermo off	BRC1	Fan motor overcurrent	Check motor power circuit. Replace fan motor / indoor board.
	11	Thermo off	BRC1	Fan motor locked	Rpm counter no signal at off condition.
A7	-	Warning	BRC1 Off/on	No detection contact swingmotor	Check swing motor run when output 230VAC. Check contact position detection open & close.
A9	01	Thermo off O	Power off/on	EV motor fault detection	Check signal board to expansion valve.
	02	Thermo off O	Power off/on	EV body leakage	Check temperature coil sensor at close EV cooling other indoor
AF		Thermo off	BRC1	Float switch open during thermo off	Check for drain water returning from other indoor, expansion valve correct closing thermo off.
AH	03	Warning	BRC1	Communication error main PCB / self cleaning PCB	Check wire harness connections.
	04	Warning	BRC1	Dust detection sensor error	Check wire harness connections.
	05	Warning	BRC1	Dust collection error	Check for clogging by dust between brush-arm and dust collector box.
	06	Warning	BRC1	Air filter rotation error	Check rotation mechanism air filter.
	07	Warning	BRC1	Damper rotation error	Check rotation mechanism damper.
	08	Warning	BRC1	Filter cleaning time error	Filter auto cleaning program could not be performed 24 hr operation.
	09	Warning	BRC1	Auto self cleaning disabled	Check field settings to enable auto filter cleaning.
AJ	01	Thermo off	Auto recovery	Capacity adaptor missing	Add corresponding capacity adaptor onto spare part PCB
	02	Thermo off	Power reset	Incorrect expansion valve motor	Use correct expansion valve motor (between gear type and direct drive).
C1	01	Thermo off	Auto recovery	Communication error main PCB / inverter PCB fan motor	Check for communication between main PCB and inverter PCB fan motor.
	02	Thermo off	Auto recovery	Communication error main PCB / auxiliary PCB	Check for communication between main PCB and inverter PCB fan motor.



	Error code				
Main	Sub	Status outdoor	Reset	Cause	Solution
C4	02	Thermo off	Auto recovery	Coil thermistor short circuit	Check coil thermistor resistance.
	03	Thermo off	Auto recovery	Coil thermistor open circuit	Check wire harness connections coil thermistor.
C5	02	Thermo off	Auto recovery	Gas thermistor short circuit	Check gas thermistor resistance.
	03	Thermo off	Auto recovery	Gas thermistor open circuit	Check wire harness connections gas thermistor.
C6	01	Thermo off	Auto recovery	Faulty combination main PCB - inverter PCB fan motor	Change inverter PCB fan motor correct type.
C9	02	Thermo off	Auto recovery	Air thermistor short circuit	Check air thermistor resistance.
	03	Thermo off	Auto recovery	Air thermistor open circuit	Check wire harness connections air thermistor.
CE	01	Thermo off	Auto recovery	No signal from optional presence sensor	Check wire harness connections
	02	Thermo off	Auto recovery	No signal from optional floor temperature sensor	Check wire harness connections
	03	Thermo off	Auto recovery	Faulty signal from optional floor temperature sensor	Check pins connector no short circuit
	04	Thermo off	Auto recovery	High temperature detection or electric noise floor temperature sensor	Check resistance floor temperature sensor
CJ	02	Thermo off	Auto recovery	Air thermistor BRC short circuit	Check air thermistor BRC resistance.
	03	Thermo off	Auto recovery	Gas thermistor open circuit	Check wire soldering air thermistor BRC
U4	01	Thermo off	Auto recovery	Communication error indoor - BS unit	Check communication between BS unit and indoor unit(s)
U9		Thermo off	Auto recovery	Communication error other indoor unit - BS unit	Check other indoor units with error other than U9
UA	13	Thermo off	Power reset	Indoor unit refrigerant type not compatible to outdoor unit	Change system lay out - remove this indoor unit from system
	15	Thermo off	Power reset	Outdoor unit is not compatible to self cleaning panel (up to VRVII)	Mount standard decoration panel
UE	-	Warning	Auto recovery	Communication error to central control device	Check communication indoor to central control Check existing group number set indoor Check registered group number central control.





Part 3. Field settings

This part contains the following chapters:

1. Wireless remote controller BRC4C and BRC7C/E21	7. Presence sensor BRYQ140A7 (for 3x3 cassette) / BRYQ60A7 (for
2. Wired remote controller BRC2/3E5222	2x2 cassette)
3. Wired remote controller BRC1D51/5227	8. Selfcleaning panel BYCQ140D7G 47
4. Wired remote controller BRC1E51	9. Aircurtain CAV/CYV
5. Wired remote controller BRC1E52	10. VKM
6. General indoor units41	11. FXSQ-A / FXNQ-A / FXDQ-A / FXMQ-P/MB / FXTQ-A
	12. Factory settings 53

1. Wireless remote controller BRC4C and BRC7C/E

1.1. Access field settings



- 1. When in the normal mode, press the " 👸 " button for 4 seconds or more, and operation then enters the "field setting mode."
- 2. Select the desired "mode No." with the " \bigcirc " button.
- 3. Pressing the " \bigoplus_{uv} " button, select the first code No.
- 4. Pressing the " \sum_{DOWN} " button, select the second code No.
- 5. Press the timer "
- 6. Press the " button to return to the normal mode.

(Example)

When setting the filter sign time to "Filter contamination heavy/light" in all group unit setting, set the Mode No. to "10", the first code No. to "0" and second code No. to "02".



2. Wired remote controller BRC2/3E52

2.1. Access field settings



To enable the Menu/Enter and Cancel button (these are default disabled on these controllers) in the Basic screen, proceed as follow:

- 1. Keep the ► button pressed.
- 2. Push the 3 indicated keys simultaneously while keeping the ▶ button pressed.



To disable the Menu/Enter and Cancel button in the Basic screen, follow the same procedure.

2.

2

Ş

- 1. Enable the Menu/Enter and Cancel button. To enable, refer to page 22.
- Press and hold the Cancel button for 4 seconds or longer. The Service Settings menu is displayed.

<Basic screen>



Press and hold the Cancel button for 4 seconds or longer while the backlight is lit.



ESIE15-11B | Part 3. Field settings

3. Select Field Settings and press the Menu/Enter button.

<Service settings>





Press the Menu/Enter button.

 Highlight the "Mode No.", and select the desired "Mode No." by using the ▲▼ (Up/Down) buttons. For the most commonly-used field settings, refer to page 25.

In the case of individual setting per indoor unit

In the case	of group	setting
-------------	----------	---------





- In the case of configuring the indoor units individually during group control (When Mode No. such as 20, 21, 22, 23, 25 are selected), highlight the unit No. and select the "Indoor unit Number" to be set by using the ▲▼ (Up/Down) buttons. (In the case of configuring as a group, this operation is not needed.)
- Highlight the SECOND CODE NO. of the FIRST CODE NO. to be changed and select the desired SECOND CODE NO. by using the ▲▼ (Up/Down) buttons. Multiple identical mode number settings are available.

NOTE

- In the case of individual configuration per indoor unit, the current settings are displayed.
- SECOND CODE NO. " " means that there is no function available
- In the case of configuring as a group, all SECOND CODE NO. which may be set are displayed as " * ".

<Field settings>



Press the Menu/Enter button.





- 7. Press the Menu/Enter button. The confirmation screen is displayed.
 8. Select Yes and press the Menu/Enter button. The settings are saved and the Field settings screen returns.
 7. 8.
 8.
 Field Settings?

 Image: No
 Image: No
- 9. When multiple settings need to be changed, repeat step "3" to "8".
- 10. After all changes are completed, press the Cancel button twice.
- 11. The backlight goes out and "Checking the connection. Please stand by" is displayed during initialization. After the initialization, the Basic screen returns.
- 12. Disable the Menu/Enter and Cancel button when no other settings need to be changed. To disable, refer to page 22.



CAUTION

- When an optional accessory is installed on the indoor unit, the settings of the indoor unit may be changed. See the manual of the optional accessory.
- · For the details on the field settings of the indoor unit, see the installation manual attached to the indoor unit.
- The outdoor unit field settings can only be configured on the outdoor PCB. Refer to the installation manual attached to the outdoor unit.

6	•	ה	
	Ť		
U			

Νοτε

- Though the configuration is performed for the whole group, set the Mode No. in parenthesis when performing an individual configuration per indoor unit or when checking after the configuration is finished.
- The SECOND CODE NO. at factory shipment depends on the indoor unit model. Default values can be found in the
 respective Service Manual of the respective units.
 - For the following settings, the value is the same for all indoor units.
 - Thermostat sensor used for the "Auto" operation mode and the Setback function (room temperature on detailed display): "02".
 - Setback function: "04"
 - External input B1: "02"
 - External input B2: "02"
- Functions which are unavailable for the connected indoor unit(s) are not displayed.



2.2. Field settings, specific for wired remote controller BRC2/3E52

1b	4	error code detail	01	without details	ex. E3
			02 with details in field set & service mode		ex. E3-04
			03	with details in basic mode	ex. E3-04
			04	details in screen 'error code' and 'main screen'	ex. E3-04
	7	Display of symbol for defrost/hot start	01	on	
			02	off	
	8	automatic changeover winter-	01	not active	
		time-summertime	02	automatic	
			03	manual	
			04	according to centralized control	
	11	Clock display in remote controller	01	Clock is shown in remocon	
			02	Clock is not shown in remocon	
	13	Display method	01	text (like BRC1E52)	
			02	symbols	
	14	number of flaps that can be blocked	01	1	Only for FXFQ-A, FCQ(H)G-F:
		through setting	02	2	With this setting, you limit the choices
			03	3	In the menu.
			04	4	-02, -03, -04.
			05	none	
	15	Fan and swing setting	01	fanspeed and swing posi- tion can be set with remo- con	
			02	only fanspeed can be set with remocon	



1c	0	display of actual room temperature	01	off	
			02	on	
	1	selection air thermistor shown in room	01	air return (R1T)	For auto-function & setback
		temp display	02	thermistor of BRC1E	
	2	Selection mode display in auto mode	01	off	Whether or not 'heating/cooling' is dis- played during automatic mode (other-
			02 on		wise only 'automatic' is mentioned on remocon)
	4	backlight on	01	permanently off	
			02 on for 30 seconds when pushing any button		Backlight goes off again after 20 sec- onds
			03	always on	
	6	display of remocon	01	permanent display	the screen always shows values
			02	screen goes blank after 5 minutes	touching any button will reactivate the screen
	12	External input BC-B1 (window con-	01	don't use	
		tact) of pcb board BRP7A51	02	use	
	13 External input BC-B2 (keycard con-		01	don't use	
		tact) of pcb board BRP7A51	02	use	
1e	1	enable temperature display in °C or °F	01	not visible	from factory locked to °C
			02	visible	visible in menu, choice between °C and °F
	2	"setback" - function	01	not available	Setback is home leave function
			02	available for heating	
				available for cooling	
			04	available for heating & cooling	
	5	hour indication	01	not visible in menu	default 24h is activated
			02	visible in menu	enduser can choose 24h or 12h dis- play
	6	count down timer	01	not visible in menu	
				visible in menu	



3. Wired remote controller BRC1D51/52

3.1. Access field settings



- 1. When in the normal mode, press the " 🐺 " button for a minimum of four seconds, and the FIELD SET MODE is entered.
- 2. Select the desired MODE NO. with the " $\left[\stackrel{\circ}{\Phi} \right]$ " button.
- 3. During group control, when setting by each indoor unit (mode No. 20, 21, 22 and 23 have been selected), push the " \odot " button and select the INDOOR UNIT NO. to be set. (This operation is unnecessary when setting by group.)
- 4. Push the " $\stackrel{\bullet}{\odot}$ " upper button and select FIRST CODE NO.
- 5. Push the " $\stackrel{@}{\checkmark}$ " lower button and select the SECOND CODE NO.
- 6. Push the " ⊕∞ " button once and the present settings are SET.
- 7. Push the " is button to return to the NORMAL MODE.



3.2. Field settings, specific for BRC1D51/52

Mode	FIRST		tting			DE	NO. Note	2	
No. Note 1	CODE NO.	Description of setting			01			03	04
10(20)	0	Filter Contamination - Heavy/Light (Setting for spacing time of display time to clean air filter) (Setting for	Ultra long life filter		Approx. 10.000 hrs.		Approx. 5.000 hrs.	-	-
		when filter contamination is heavy, and spacing time of display time to clean air filter is to be halved)	Long life filter		Approx. 2.500 hrs.	ý	Approx. 1.250 hrs.		
	Sta filt	Standard filter	Light	Approx. 200 hrs.	Heav	Approx. 100 hrs.			
	1	Long-life filter type (setting of filter sign time). (Change setting when ultra-long installed)	n indication g filter is	Lo filte	ng-life er	Ult life	ra-long filter	-	-
	2	Thermostat sensor in remote controlle	r	Us	е	No	t use	-	-
	3	Spacing time of display time to clean a count (setting for when the filter sign is displayed)	ime to clean air filter ne filter sign is not to be		Display		not play	-	-
12(22)	1	ON/OFF input from outside (setting for forced ON/OFF is to be operated from	side (setting for when operated from outside). changeover (setting for sor).		Forced OFF		I/OFF eration	-	-
	2	Thermostat differential changeover (se when using remote sensor).			1°C		5°C	-	-
13(23)	0	High air outlet velocity (for high ceiling tions).	applica-	≤2,7 m		>2	,7≤3,0 m	>3,0≤3,5 m	-
	1	Selection of air flow direction (setting f blocking pad kit has been installed).	for when a	4-way flow		3-way flow		2-way flow	-
	3	Selection of air flow function (setting for using a decoration panel for outlet).	or when	Eq	Equipped		t uipped	-	-
	4	Air flow direction range setting.		Up	per	No	rmal	Lower	-
	6	Setting the external static pressure (se according to the connected duct resist	etting tance)	No	rmal	Hię pre	gh static essure	Low static pressure	-
		(for FHYK, follow the high ceiling setting	ng)	(No	ormal)	(Hi cei	igh iling)	-	
15(25)	3	Drain pump operation with humidifying].	Eq	uipped	No eq	t uipped	-	-
1b	0	Permission level setting		Le	vel 2	Le	vel 3	-	-
	1	Leave home function		No pe	t rmitted	Pe	rmitted	-	-
	2	Thermostat sensor in remote controlle operation and leave home function on	r (for limit ly)	Us	e	No	t use	-	-



1b	0	user permission level (BRC1D)	01	level 2	available: on/off, temperature selec- tion, delay, min/max operation, fanspeed, swingflap direction
			02	level 3	available: on/off, temperature selec- tion, fanspeed
	1	setback function	01	not available	For setback function: After activation
			02	available	in mode 1b-1, push both buttons
	2	use of remocon sensor for 'limited'	01	active	On the display the symbol will be visi-
		and 'setback' function	02	not active	ble.
	3	Start 'setback' - function	05	5°C	Function can only be activated when
			06	6°C	unit is off.
			07	7°C	
			08	8°C	
			09	9°C	
			10	10°C	
			11	11°C	
			12	12°C	
			13	13°C	
			14	14°C	
			15	15°C	
	4	Stop 'setback' - function	01	1K	
			02	2K	
			03	ЗК	
			04	4K	
			05	5K	
	5	Usage of 'limited' function in combina-	01	not available	'limited' function = additional mode to
		tion with centralised control	02	available	permit keeping the temperature between a minimum and maximum value.



4. Wired remote controller BRC1E51

4.1. Access field settings



- 1. Press and hold Cancel button for 4 seconds or longer.
- Service Settings menu is displayed.
 Select Field settings in the Service Settings menu, and press Menu/Enter button.
- Field settings screen is displayed.
 Highlight the mode, and select desired "Mode No." by using ▲▼ (Up/Down)
 - "Mode No." by using ▲▼ (Up/Down) button.
- 4. In the case of setting per indoor unit during group control (When Mode No. such as 20, 21, 22, 23, 25 are selected), highlight the unit No. and select "Indoor unit No." to be set by using ▲▼ (Up/Down) button. (In the case of group setting, this operation is not needed.) (In the case of individual setting per indoor unit, current settings are displayed. And, SECOND CODE NO. " " means no function.)



<Basic screen>



Press and hold Cancel button for 4 seconds or longer during backlight lit.

<Service settings menu screen>

2.





Press the Menu/Enter button.



5. Highlight SECOND CODE NO. of the FIRST CODE NO. to be changed, and select desired "SECOND CODE NO." by using $\blacktriangle \nabla$ (Up/Down) button. Multiple identical mode number settings are available. (In the case of group setting, all of SECOND CODE NO. which may be set are displayed as " * ". " * " is changed to SECOND CODE NO. to be set. And, SECOND CODE NO. " - " means no

function.)

3. 4. 5. <Field settings screen>

In the case of individual setting per indoor unit

Field Settings								
Unit No.	Unit No. Mode							
0	1	20						
0-01	1-00	2-00	3-00					
4	5——	6	7					
8	9——	10——	11					
12	13	14—	15					
t ⊡Return	Se	etting						

In the case of group setting





Press the Menu/Enter button.

- 6. Press Menu/Enter button. Setting confirmation screen is displayed.
- 7. Select Yes and press Menu/Enter button. Setting details are saved and Field settings screen returns.
- 8. In the case of multiple setting changes, repeat step "3" to "7".
- After all setting changes are completed, 9 press Cancel button twice.
- 10. Backlight goes out, and "Checking the connection Please stand by" is displayed during initialization. After the initialization, the basic screen returns.

<Setting confirmation screen>



Press the Menu/Enter button.

Setting confirmation



CAUTION

- When an optional accessory is installed on the indoor unit, settings of the indoor unit may be changed. See the manual of the optional accessory.
- For field setting details of the outdoor unit, see installation manual attached to the outdoor unit.



4.2. Field settings, specific for BRC1E51

Mode	FIRST		etting			DE	NO. Note :	2	
No. Note 1	CODE NO.	Description of setting				02		03	04
10(20)	0	Filter Contamination - Heavy/Light (Setting for spacing time of display time to clean air filter) (Setting for	Ultra long life filter		Approx. 10.000 hrs.		Approx. 5.000 hrs.	-	-
		when filter contamination is heavy, and spacing time of display time to clean air filter is to be halved)	Long life filter		Approx. 2.500 hrs.	ý	Approx. 1.250 hrs.		
			Standard filter	Light	Approx. 200 hrs.	Heav	Approx. 100 hrs.		
	1	Long-life filter type (setting of filter sign time). (Change setting when ultra-long installed)	n indication a filter is	Lo: filte	ng-life er	Ult life	ra-long filter	-	-
	2	Thermostat sensor in remote controlle	r	Us	е	No	t use	-	-
	3	Spacing time of display time to clean a count (setting for when the filter sign is displayed)	me to clean air filter ne filter sign is not to be		splay	Do not display		-	-
12(22)	1	ON/OFF input from outside (setting for forced ON/OFF is to be operated from	etting for when ed from outside).		Forced OFF		I/OFF eration	-	-
	2	Thermostat differential changeover (se when using remote sensor).	etting for	1°C		0,5°C		-	-
13(23)	0	High air outlet velocity (for high ceiling tions).	applica-	≤2	7 m	>2	,7≥3,0 m	>3,0≥3,5 m	-
	1	Selection of air flow direction (setting f blocking pad kit has been installed).	or when a	4-v	vay flow	3-v	vay flow	2-way flow	-
	3	Selection of air flow function (setting for using a decoration panel for outlet).	or when	Eq	Equipped		t uipped	-	-
	4	Air flow direction range setting.		Up	per	No	rmal	Lower	-
	6	Setting the external static pressure (se according to the connected duct resist (for FHYK, follow the high ceiling setting)	ure (setting .t resistance) ig setting)		rmal ormal)	Hię pre (Hi cei	gh static essure gh ling)	Low static pressure -	-
15(25)	3	Drain pump operation with humidifying].	Eq	uipped	No eq	t uipped	-	-
1c	1	Thermostat sensor in remote controlle operation and Home leave function on	r (for limit lly)	No	t use	Us	e	-	-
	3	Permission level setting		Le	vel 2	Le	vel 3	-	-
1e	2	Home leave function		No pe	t rmitted	Pe	rmitted	-	-

Νοτε

•

• Though setting is performed totally in the group, set Mode No. in the parenthesis when individual setting per indoor unit or checking after the setting should be performed.

SECOND CODE NO. at factory shipment is set to "01". However for the following cases it is set to "02".

- Airflow direction range setting (except round flow cassette)
- Thermostat sensor in remote controller (Sky Air only)
- Thermostat sensor in remote controller for limit operation and Home leave function only

• Any function which the indoor unit does not have is not displayed.



1b	4	error code detail	01	without details	ex. E3
	-		02	with details in field set &	ex E3-04
			02	service mode	0.1.2001
			03	with details in basic mode	ex. E3-04
			04	details in screen 'error	ex. E3-04
			-	code' and 'main screen'	
	7	Display of symbol for defrost/hot start	01	on	
			02	off	
	8	automatic changeover winter-	01	not active	
		time-summertime	02	automatic	
			03	manual	
			04	according to centralized	
				control	
	а	OFF-reminder timer	01	not visible	
			02	visible	
1c	0	display of actual room temperature	01	off	
			02	on	
	1	selection air thermistor shown in room	01	air return (R1T)	For auto-function & setback
		temp display	02	thermistor of BRC1E	
	2	Selection mode display in auto mode	01	off	Whether or not 'heating/cooling' is dis-
			02	on	played during automatic mode (other-
					vise only automatic is mentioned on remocon)
	3	Permission level setting	01	level 2 (low high: on/off:	
	0	i ermission level setting	01	operation mode)	
			02	level 3 (on/off)	
	4	backlight on	01	permanently off	
			02	on for 30 seconds when	
				pushing any button	
			03	always on	
	5	operation when backlight is off	01	no	when pushing a button, first backlight
					is activated, function of button is not
			02	yes	when pushing a button, backlight is activated and immediately function of
					button is activated
	6	display of remocon	01	permanent display	the screen always shows values
			02	screen goes blank after 5	touching any button will reactivate the
				minutes	screen
	А	Setback cooling differential	01	-	Home leave function requires that
			02	-2°C	room temperature doesn't rise above
			03	-3°C	nobody home. If ambient temperature
			04	-4°C	rises above 34°C, cooling will auto-
			05	-5°C	matically start until 29°C (default dif-
			06	-6°C	ferential of 5°C) is reached, then unit
			07	-7°C	gues back to its original state.
			08	-8°C	
			09	-9°C	
	В	Setback heating differential	01	-	Home leave function requires that
			02	+2°C	room temperature doesn't drop below
			03	+3°C	a certain temperature when there is nobody home. If ambient temperature
			04	+4°C	drops below 14°C, heating will auto-
			05	+5°C	matically start until 19°C (default dif-
			06	+6°C	Terential of 5°C) is reached, then unit
			07	+7°C	good baok to its original state.
			08	+8°C]
			09	+9°C]



ESIE15-11B | Part 3. Field settings

1e	0	"set temp mode changeover" visibility	01	visible			
		in main menu	02	hide from main menu			
	1	enable temperature display in °C or °F	01	not visible	from factory locked to °C		
			02	visible	visible in menu, choice between °C and °F		
	2	"setback" - function	01	not available	Setback is home leave function		
_		C	02	available			
	3	selection set temperature in limit oper-	01	not keep			
		ation when power on/off	02	keep			
	4	4 timer setting: when centralized control (similar to BRC1D528 setting 1b-5)		not visible	to avoid conflict between timer inside centralized remocon and BRC1E		
			02	visible			
	5	hour indication	01	not visible in menu	default 24h is activated		
			02	visible in menu	enduser can choose 24h or 12h dis- play		
-	6	count down timer	01	not visible in menu			
			02	visible in menu			
	А	Offset for master remocon sensor	01	-3°C	with this setting it's possible to modify		
			02	-2,5°C	the readout by remocon of the ambi-		
			03	-2°C	ent temperature		
			04	-1,5°C			
			05	-1°C			
			06	-0,5°C			
			07	0°C			
			08	+0,5°C			
			09	+1°C			
	В	offset for slave remocon sensor	01	-3°C	with this setting it's possible to modify		
			02	-2,5°C	the readout of ambient temperature of		
			03	-2°C	the secondary remocon		
			04	-1,5°C			
			05	-1°C			
			06	-0,5°C			
			07	O°C			
			08	+0,5°C			
			09	+1°C			



5. Wired remote controller BRC1E52

5.1. Access field settings



- Press and hold Cancel button for 4 seconds or longer.
- Service Settings menu is displayed.
 Select Field settings in the Service Settings menu, and press Menu/Enter

button.

- Field settings screen is displayed.
- Highlight the mode, and select desired "Mode No." by using ▲▼ (Up/Down) button.



<Basic screen>



Press and hold Cancel button for 4 seconds or longer during backlight lit.

In the case of setting per indoor unit during group control (When Mode No. such as 20, 21, 22, 23, 25 are selected), highlight the unit No. and select "Indoor unit No." to be set by using ▲▼ (Up/Down) button. (In the case of group setting, this operation is not needed.) (In the case of individual setting per indoor unit, current settings are displayed. And, SECOND CODE NO. " - " means no function.)

<Service settings menu screen>



2.



Press the Menu/Enter button.



5. Highlight SECOND CODE NO. of the FIRST CODE NO. to be changed, and select desired "SECOND CODE NO." by using ▲▼ (Up/Down) button. Multiple identical mode number settings are available. (In the case of group setting, all of SECOND CODE NO. which may be set are displayed as " * ". " * " is changed to

SECOND CODE NO. to be set. And, SECOND CODE NO. " - " means no function.)

<Field settings screen>

In the case of individual setting per indoor unit

3.

4.

5.

Unit No.	M	Mode					
0	2	20					
0-01	1-00	2-00	3-00				
4——	5	6	7—–				
8——	9	10	11—–				
12	13—–	14	15—–				

In the case of group setting





Press the Menu/Enter button.

- 6. Press Menu/Enter button. Setting confirmation screen is displayed.
- 7. Select Yes and press Menu/Enter button. Setting details are saved and Field settings screen returns.
- 8. In the case of multiple setting changes, repeat step "3" to "7".
- After all setting changes are completed, 9 press Cancel button twice.
- 10. Backlight goes out, and "Checking the connection Please stand by" is displayed during initialization. After the initialization, the basic screen returns.

<Setting confirmation screen>



Press the Menu/Enter button.

Setting confirmation



CAUTION

- When an optional accessory is installed on the indoor unit, settings of the indoor unit may be changed. See the manual of the optional accessory. •
 - For field setting details of the outdoor unit, see installation manual attached to the outdoor unit.

Page 36



5.2. Field settings, specific for BRC1E52

Mode	FIRST					DE	NO. Note 2	2	
No. Note 1	CODE NO.	Description of setting		01		02		03	04
10(20)	0	Filter Contamination - Heavy/Light (Setting for spacing time of display time to clean air filter) (Setting for	Ultra long life filter		Approx. 10.000 hrs.		Approx. 5.000 hrs.	-	-
		when filter contamination is heavy, and spacing time of display time to clean air filter is to be halved)	Long life filter		Approx. 2.500 hrs.	کر ا	Approx. 1.250 hrs.		
			Standard filter	Light	Approx. 200 hrs.	Heav	Approx. 100 hrs.		
	1	Long-life filter type (setting of filter sigr time). (Change setting when ultra-long installed)	ilter sign indication Itra-long filter is		Long-life filter		ra-long filter	-	-
	2	Thermostat sensor in remote controlle	r	Us	e	No	t use	-	-
	3	Spacing time of display time to clean a count (setting for when the filter sign is displayed)	ay time to clean air filter en the filter sign is not to be		play	Do dis	not play	-	-
12(22)	1	ON/OFF input from outside (setting for forced ON/OFF is to be operated from	ו outside (setting for when to be operated from outside).		Forced OFF		I/OFF eration	-	-
	2	Thermostat differential changeover (se when using remote sensor).	etting for	1°C	2	0,5°C		-	-
13(23)	0	High air outlet velocity (for high ceiling tions).	applica-	≤2,7 m		>2	,7≥3,0 m	>3,0≥3,5 m	-
	1	Selection of air flow direction (setting f blocking pad kit has been installed).	or when a	4-way flow		3-way flow		2-way flow	-
	3	Selection of air flow function (setting for using a decoration panel for outlet).	or when	Equipped		Not equipped		-	-
	4	Air flow direction range setting.		Up	per	No	rmal	Lower	-
	6	Setting the external static pressure (se according to the connected duct resist (for FHYK, follow the high ceiling setting)	etting ance) ng)	No (No	rmal ormal)	High static pressure (High		Low static pressure -	-
15(25)	3	Drain pump operation with humidifying].	Eq	uipped	No eq	t uipped	-	-
1c	1	Thermostat sensor in remote controlle mode and Setback function only)	r (for Auto	No	t use	Us	е	-	-
1e	2	Setback function		No	t use	Не	at only	Cool only	Cool and Heat
i	Not	TE Though setting is performed totally in the	group, set M	ode	No. in the p	aren	thesis wher	n individual setti	ng per indoor

- unit or checking after the setting should be performed.
- SECOND CODE NO. at factory shipment is set to "01". However for the following cases it is set to "02".
 - Airflow direction range setting (except round flow cassette)
 - Thermostat sensor in remote controller (Sky Air only)
 - Thermostat sensor in remote controller for auto mode operation and Setback function only
- Any function which the indoor unit does not have is not displayed.



1b	0	quiet mode display	01	visible in menu	Whether or not the quiet mode can be
			02	not visible in menu	selected in the menu
	4	error code detail	01	without details	ex. E3
			02	with details in field set & service mode	ex. E3-04
			03	with details in basic mode	ex. E3-04
			04	details in screen 'error code' and 'main screen'	ex. E3-04
	7	Display of symbol for defrost/hot start	01	on	Whether or not the defrost/hot start
			02	off	symbol is displayed on the remocon screen
	8	automatic changeover winter-	01	not active	
		time-summertime	02	automatic	
			03	manual	
			04	according to centralized control	
	11	Clock display	01	active	Whether or not the clock is displayed
			02	not active	on the remocon screen
	14	FXFQ-A, FCQ(H)G-F: number of flaps	01	1	With this setting, you limit the choices
		that can be blocked	02	2	in the menu.
			03	3	It is strongly advised not to use setting
			04	4	-, -,,
			05	none	



VRV4 indoor units

ESIE15-11B | Part 3. Field settings

1c	0	display of actual room temperature	01	off	
			02	on	
	1	selection air thermistor shown in room	01	air return (R1T)	For auto-function & setback
		temp display (for auto mode and set- back function only)	02	thermistor of BRC1E	
	2	Visualisation of mode display on	01	off	Whether or not 'heating/cooling' is dis-
		remocon in auto mode	02	on	vise only 'automatic' is mentioned on remocon)
	3	disable level	01	level 2 (low, high; on/off; operation mode)	
			02	level 3 (on/off)	
	4	backlight on	01	permanently off	
			02	on for 30 seconds when pushing any button	
			03	always on	
	5	operation when backlight is off	01	no	when pushing a button, first backlight is activated, function of button is not activated
			02	yes	when pushing a button, backlight is activated and immediately function of button is activated
	6	display of remocon	01	permanent display	the screen always shows values
			02	screen goes blank after 5 minutes	touching any button will reactivate the screen
	9	Sensor selection if 2 remocon	01	main controller	temperature sensor of main controller is used for ambient (in case 1c-1-2)
			02	2nd controller	temperature sensor of 2nd controller is used for ambient (in case 1c-1-2)
	10	Offset master remocon sensor	01	-3°C	to modify displayed temperature on
			02	-2,5°C	remocon 1
			03	-2°C	
			04	-1,5°C	
			05	-1°C	
			06	-0,5°C	
			07	0°C	
			08	+0,5°C	
			09	+1°C	
	11	Offset slave remocon sensor	01	-3°C	to modify displayed temperature on
			02	-2,5°C	remocon 2
			03	-2°C	
			04	-1,5°C	
			05	-1°C	
			06	-0,5°C	
			07	0°C	
			08	+0,5°C	
			09	+1°C	



1e	0	"set temp mode changeover" visibility	01	visible	
		in main menu	02	hide from main menu	
	1	enable temperature display in °C or °F	01	not visible in menu	from factory locked to °C
			02	visible in menu	visible in menu, choice between °C and °F
	2	Setback function	01	not available	
			02	available for heating	
			03	available for cooling	
			04	available for heating & cooling	
	4	timer setting: when centralized control (similar to BRC1D528 setting 1b-5)	01	not visible	to avoid conflict between timer inside centralized remocon and BRC1E
			02	visible	
	5	hour indication	01	not visible in menu	default 24h is activated
			02	visible in menu	enduser can choose 24h or 12h dis- play
	6	count down timer	01	not visible in menu	
			02	visible in menu	
	9	Display of 'change-over' and 'central-	01	not visible on remocon	whether or not the 'arrows' symbol is
		ised' symbols	02	visible in remocon	visible on the remocon
	10	Display of info on remocon when acti-	01	show key-symbol	
		locked through centralised control	02	show message	
	11	switching delay in automatic mode	01	15 min	
			02	30 min	
			03	60 min	
			04	90 min	



6. General indoor units

These settings are applicable to most of the indoor units.

10 /	0	Filter contamination (time between 2	01	light	Ultra-long life Filter: +/-10.000 hrs
20		filter cleaning display indications)			Long-life filter +/-2.500 hrs
					Standard filter +/-200 hrs
			02	heavy	Ultra-long life Filter: +/-5.000 hrs
					Long-life filter +/-1.250 hrs
					Standard filter +/-100 hrs
	1	Long life filter type	01	long life filter	Filterclass G1
			02	super long life filter (option)	Filter type F6 high efficiency 64 for FXCQ-FXUQ-FXFQ-FXZQ-FXKQ- FXSQ-FXDQ-FXFQ-FXMQ
					Filter type F7 for VAM (additional filter)
					Filter type F8 very high efficiency 90 for FXCQ-FXFQ-FXSQ-FXMQ
			04	oil guard filter	for installations in greasy environment
	2	Indoor thermostat sensor selection (no effect when used in conjunction with presence sensor BRYQ)	01	Use both the unit sensor (or remote sensor if installed) AND the remote controller sensor.	Note: If setting 10-6-02 + 10-2-01 or 10-2-02 or 10-2-03 are set at the same time, then setting 10-2-01, 10-2-02 or 10-2-03 have priority.
					Note: If setting 10-6-01 + 10-2-01 or 10-2-02 or 10-2-03 are set at the same time, then setting for group connection, 10-6-01 has priority and for individual connection, 10-2-01, 10-2-02 or 10-2-03 have priority.
			02	Use return air sensor only (or remote sensor if installed).	Note: If setting 10-6-02 + 10-2-01 or 10-2-02 or 10-2-03 are set at the same time, then setting 10-2-01, 10-2-02 or 10-2-03 have priority.
					Note: If setting 10-6-01 + 10-2-01 or 10-2-02 or 10-2-03 are set at the same time, then setting for group con- nection, 10-6-01 has priority and for individual connection, 10-2-01, 10-2-02 or 10-2-03 have priority.
			03	Use remote controller sen- sor only.	Note: If setting $10-6-02 + 10-2-01$ or $10-2-02$ or $10-2-03$ are set at the same time, then setting $10-2-01$, $10-2-02$ or $10-2-03$ have priority. Note: If setting $10-6-01 + 10-2-01$ or $10-2-02$ or $10-2-03$ are set at the same time, then setting for group connection, $10-6-01$ has priority and for individual connection, $10-2-01$, $10-2-02$ or $10-203$ have priority.
	3	Filter sign display	01	Display	10-2-02 01 10-2-03 have phonty.
	0		02	Do not display	
	5	Remote controller thermistor visible by	01		
	-	central control device in group wiring P1P2	02	yes	
	6	Air thermistor selection in group wiring P1P2	01	return air thermistor (indi- vidual units)	
			02	Thermistor designated by fieldsetting 20-2	
	7	Absence delay detecting time (pres-	01	30 minutes	
		ence sensor)	02	60 minutes	
	8	Compensation air sensor heating	01	add 2°C to measurement air sensor	
			02	measurement air sensor	



VRV4 indoor units

ESIE15-11B | Part 3. Field settings

11 /	3	Fan setting of heating	01	standard	
21			02	slight increase	
			03	increase	
	6	Sensitivity presence sensor	01	high sensitive	for BRYQ140A7 / BRYQ60A
			02	low sensitive	
			03	standard	
			04	disable presence sensor	
	7	External static pressure setting:	01	airflow adjustment is OFF	For FXSQ-FXMQ
		Automatic airflow adjustment function		(manual setting 23-6)	1. Turn off the indoor unit
			02	Completion of automatic airflow adjustment	2. Set indoor unit to fan operation mode.
			03	Start of automatic airflow	3. Choose desired fanspeed (L,H,HH)
				adjustment	4. Change setting 21-7-00 to 21-7-03 and exit setting menu
					5. Activate indoor unit to start the learning function
					6. Learn
	8	Compensation by floor sensor	01	floor sensor disabled	for BRYQ140A7 / BRYQ60A
			02	air suction temperature pri- ority	
			03	standard	
			04	floor temperature priority	
	9	Compensation by floor temperature	01	-4°C	for BRYQ140A7 / BRYQ60A
			02	-2°C	
			03	no correction	
			04	+2°C	



12 / 22	0	Output signal X1-X2 of the optional KRP1B PCB kit	01	indoor unit turned ON by thermostat	
			02		
			03	operation output	
			04	malfunction output	
	1	External ON/OFF (T1/T2 input) = set-	01	forced off	
		ting when forced ON/OFF is operated	02	ON/OFF operation	
		nom outside.	03	external protection device input	
			04	forced OFF - multi tenant	
	2	Thermostat differential changeover (set when remote sensor is to be	01	1°C	FXFQ, FXZQ, FXCQ, FXKQ, FXUQ, FXHQ, VKM, "biddle"
		used)	02	0,5°C	FXSQ, FXMQ, FXAQ, FXLQ, FXNQ, FXDQ, EKEQM
	3	Fanspeed setting during thermostat	01	LL	
		OFF at heating operation	02	Set speed	
			03	OFF	Note: only use in combination with optional remote sensor or when setting 10-2-03 is used.
	4	Differential for automatic changeover.	01	0°C (hp)	ex: cooling 24°C/Heating 24°C
		Temperature difference between cool-	02	1°C	ex: cooling 24°C/Heating 23°C
		automatic mode. Differential is cooling	03	2°C	ex: cooling 24°C/Heating 22°C
		setpoint minus heating setpoint.	04	3°C (HR)	ex: cooling 24°C/Heating 21°C
			05	4°C (VKM)	ex: cooling 24°C/Heating 20°C
			06	5°C	ex: cooling 24°C/Heating 19°C
			07	6°C	ex: cooling 24°C/Heating 18°C
			08	7°C	ex: cooling 24°C/Heating 17°C
	5	Auto-restart after power failure	01	disabled	
			02	enabled	
	6	Fan setting during thermostat OFF at	01	very low speed	
		cooling operation	02	according to remocon set- ting	
			03	ventilation off	
	9	Forced cool/heat master	01	disabled (select by cool/heat selection button controller)	only for 2 pipe heatpump VRV sys- tems
			02	enabled (not possible by cool/heat selection button controller)	



13/	0	Airflow amount setting (Ceiling height)	01	normal ceiling (<2,7m)	Depends on indoor unit
20			02	slightly higher ceiling (2,7m)	
			03	high ceiling (3m)	
	1	selection of airflow direction (set when a blocking path kit has been installed, 4-way blow panel)	01	4 way directions	Note: freeze-up protection will come in when the temperature, measured by R2T is below -1°C for 10 minutes.
			02	3 way directions	Note: freeze-up protection will come
			03	2 way directions	in when the temperature, measured by R2T is below 0°C for 1 minute or below 1°C for 15 minutes.
	2	Swing pattern setting if 4 swing motors	01	all directions simultane- ously swing	
			02		
			03	opposite sides synchroni- zation swing	
	3	Output to flap motor	01	enabled	
			02	disabled	
			03		
	4	Setting of airflow direction adjustment	01	draft prevention	high position (10-40°)
		range	02	standard	standard position (10-65°)
			03	ceiling soiling prevention	low position (30-65°)
	5	fanspeed setting	01	Standard	for FXFQ-M, FXHQ-M & FXZQ-M
			02	Low	
			03	Low	
		Setting the static pressure selection	01	Standard (10/15Pa)	for FXDQ-A & FXNQ-A
			02	High static pressure (30/44Pa)	
			03	Medium static pressure	
			04	Medium static pressure	
	6	External static pressure settings	01	30 Pa	only for FXMQ 40 PVE
			02	50 Pa	for FXSQ-P/A, FXMQ-P, FXTQ-A
			03	60 Pa	ESP value based on nominal airflow
			04	70 Pa	rate = Hhspeed
			05	80 Pa	
			06	90 Pa	
			07	100 Pa	
			08	110 Pa	
			09	120 Pa	
			10	130 Pa	
			11	140 Pa	_
			12	150 Pa	_
			13	160 Pa	
			14	180 Pa	only for FXMQ 50 - 125 PVE
	L		15	200 Pa	
	7	I nermostat swing	01	equipped	
	1		02	not equipped	



VRV4 indoor units

14/	2	when to display cleaning requirement	01	Display after 1.250h	only for BYCQ
24		on the remote control according to	02	Display after 2.500h	
		number of operating hours	03	Display after 5.000h	
	3	Display filter change on the remote	01	no display	
		control according to number of operat-	02	display after 32.000h	
		ing nours	03	display after 48.000h	
			04	display after 72.000h	
	4	Panel indicator (green)	01	On while in a/c operation & filter cleaning operation	
			02	possible to turn on while in filter cleaning operation only	
			03	off while in a/c operation and filter cleaning opera- tion	
			04	On	
	8	auto cleaning program	01	choice between auto and schedule	
			02	only schedule (auto not in menu)	
	9	Dust amount setting	01	standard	
			02	dust amount big	
15 / 25	0	Drainpump operation (for units equipped with drainpump 13VDC)	01	stop for 5 minutes when thermo off	
			02	stop permanently during thermo off	
		Air cleaner	01	not equipped	
			02	equipped	
	1	Humidification during thermo off (heat-	01	Off	
		ing)	02	On	
	2	Direct duct connection (ex. Fresh air	01	none	
			02	equipped	Fan must be operated from indoor unit
	3	Drain pump operation if humidifier is used (heating)	01		
	4	Filter sign	02	equipped	
	*		02	by uner by external input	
	9	Demand control	02	not equipped	
	Ĭ		02	equipped	
	I				



7. Presence sensor BRYQ140A7 (for 3x3 cassette) / BRYQ60A7 (for 2x2 cassette)



21	3	(for BRYQ60A7) Fanspeed setting during heating	01	don't speed up (correction factor 1,00)
		operation	02	speed up by 5% (correction factor 1,05)
			03	speed up by 10% (correction factor 1,10)
	6	Sensitivity presence sensor	01	high sensitive
			02	low sensitive
			03	standard
			04	disable presence sensor
	8	Compensation by floor sensor	01	floor sensor disabled
			02	air suction temperature priority
			03	standard
			04	floor temperature priority
	9	Compensation by floor temperature	01	-4°C
			02	-2°C
			03	no correction
			04	+2°C
23	1	(for BRYQ60A7) Select airflow direction	01	4-way direction
			02	3-way direction



8. Selfcleaning panel BYCQ140D7G



14/	2	when to display cleaning requirement on the	01	Display after 1.250h
24		remote control according to number of operating	02	Display after 2.500h
			03	Display after 5.000h
	3	Display filter change on the remote control	01	no display
		according to number of operating hours	02	Display after 32.000h
			03	Display after 48.000h
			04	Display after 72.000h
	4	Panel indicator (green)	01	On while in a/c operation and filter cleaning operation
			02	possible to turn on while in filter cleaning operation only
			03	off while in a/c operation and filter cleaning operation
			04	On
	8	auto cleaning program	01	choice between auto and schedule
			02	only schedule (auto not in menu)
	9	Dust amount setting	01	standard
			02	dust amount big

DIP-switches on PCB





9. Aircurtain CAV/CYV



14/	6	Fan switching delay at hotstart in minutes	01	0 minutes (fan starts immediately)
24			02	1 minute
			03	3 minutes (default)
			04	5 minutes
	7	Fan switching delay for hotstart in °C depending	01	34°C
		on the condensing pressure	02	37°C
			03	40°C
			04	43°C (default)
	8	Fan speed during defrosting or oil return	01	Fan off
			02	Fan LL (default)
			03	Keep fanspeed

10. VKM



15/	5	independent ventilation	01	not equipped
25			02	equipped
	6	independent unit	01	no
			02	yes



VRV4 indoor units

ESIE15-11B | Part 3. Field settings

10.	VKM
-----	-----

17 /	0	Interval time for filter sign indication	01	2500 hours	
27			02	1250 hours	
			03	no counting	
	1	Nighttime free cooling operation set- ting	01	no free cooling possible	Free cooling starts when outdoor tem- perature is below ambient tempera-
			02	free cooling 2 hours after unit stop	ture and when minimum stop-time has expired. Ambient temperature is checked 1x per hour. (combination with setting 27(6 & 27/7)
			03	free cooling 4 hours after unit stop	
			04	free cooling 6 hours after unit stop	
			05	free cooling 8 hours after unit stop	
	4	fan speed initial setting	01	normal	possibility to use SS1 on pcb of VKM
			02	Ultra high	
	5	Direct duct connection with VRV indoor	01	not direct duct (airflow set- ting)	VKM works independent of indoor units
			02	with direct duct (fan off)	the fan of the VKM stops immediately when indoor unit fan stops (remocon off, defrost, oil return and hot start)
			03	-	
			04	no direct duct (airflow set- ting)	the fan of VKM goes to low speed when the fan of indoor unit stops (thermo off, defrost, oil return and hot start)
			05	-	
			06	with direct duct (fan off)	the fan of VKM goes to low speed when the indoor fan stops (thermo off, defrost, oil return and hot start)
			07		
			08	no direct duct (fan off)	
		Cold areas: Fan speed setting	01	Keep set fanspeed	
			02	Heating Th off: set fanspeed	In case independent operation, set fanspeed in thermo off, defrost & oil
				Defrost: stop	return
				Oil return: stop	
			03	-	
			04	Heating Th off: low	
				Defrost: stop	
				Oil return: stop	-
			05	-	-
			06	Defrect: step	
				Oil return: stop	
			07		
			08	Heating Th off: set	
				Defrost: stop	
				Oil return: stop	
•	6	Ventilation airflow setting when night-	01	High	
		time free cooling setting	02	Ultra high	1



18/	4	Display for ventilation mode	01	show	
28			02	hide	
	7	Fresh up air supply/exhaust setting	01	no indication supply	
			02	no indication exhaust	
			03	indication supply	
			04	indication exhaust	
	8	External input terminal function selec-	01	fresh-up	fresh up operation
		tion (between J1 & JC)	02	overall alarm	malfunction code 60 is displayed
			03		
			04		
			05		
			06	airflow increase	fan strengthen up (low to high, high to ultra-high)
	9	KRP50-2 output switching selection	01	fan on/off	
		(between 1 & 3)	02	abnormal	
19 /	0	ventilation airflow setting	01	low	
29			02	low	
			03	low	
			04	low	
			05	high	
			06	high	
	2	Ventilation mode setting	01	Automatic	
			02	Exchange	
			03	Bypass	
1A	0	fresh-up operation	01	not active	
			02	active	



11. FXSQ-A / FXNQ-A / FXDQ-A / FXMQ-P/MB / FXTQ-A

FXSQ-A



FXNQ-A



FXDQ-A



FXNQ-A, FXDQ-A: specific settings

13/	5	External static pressure	01	Default: Standard (10 Pa)
23			02	High static pressure setting (30 Pa)
			03	Medium static pressure
			04	Medium static pressure







FXTQ-A





				FXSQ-A	FXMQ-M	FXMQ-P	FXTQ-A	Comment
13/	6	External static	01	30	Std ESP	30	Tbc	ESP value based on nominal airflow
23		pressure (Pa)	02	-	High ESP	50	Tbc	rate = Hhspeed
			03	30		60	Tbc	Possible available settings depend
			04	40		70	Tbc	sponding IM)
			05	50		80	Tbc	
			06	60		90	Tbc	
			07	70		100	Tbc	
			08	80		110	Tbc	
			09	90		120	Tbc	
			10	100		130	Tbc	
			11	110		140	Tbc	
			12	120		150	Tbc	
			13	130		160	Tbc	
			14	140		180	Tbc	
			15	150		200	Tbc	
11/	7	Auto-adjust-	01	Deactivated	l, manual thro	ugh 13/23-6	1	Only applicable for FXSQ and FXMQ
21		ment of ESP	02	Auto-adjust	ment			
			03	Start auto-a	djustment			

FXSQ-A, FXMQ-P/M, FXTQ-A: specific settings



12. Factory settings

12.1. How to perform factory reset of settings through remocon

Only for BRC2/3E52, BRC1E51/52

- 1. Power off unit and wait for display to go blank
- 2. Push 3 buttons simultaneously and power on unit while holding 3 buttons until initialisation starts again



Reset of:

- timer
- clock
- language
- settings 1b, 1c, 1e
- configuration settings in user menu





EXTO-A		tbc	tbc	tbc	tbc		thc	thc		the the	tDC		FXTQ-A				tbc			tbc	tbc	tbc	tbc	FXTQ-A	tbc	FXTQ-A	tbc	tbc	tbc	tbc	tbc	tbc	tbc	tbc	tbc	, LL									
EXSO.A		tbc	tbc	tbc	tbc		thc	thc	thr thr	10C	IDC		FXSQ-A				tbc			tbc	tbc	tbc	tbc	FXSQ-A	tbc	FXSQ-A	tbc	tbc	tbc	tbc	tbc	tbc	tbc	tbc	tbc	11									
Biddle		01	01	03	02		01	01			na		Biddle	-			na			na	na	na	na	Biddle	01	02	01	01	01	02	02	01	01	01	Biddle	na	na	na	na	na	na	na	na	02	5
VKM	2	01	03	na	02	_	na	na			na		VKM				na	_		na	na	na	na	VKM	01	01	01	na	01	02	na	na	na	01	VKM	na	na	na	na	na	na	na	na	01	1
FXND	2	01	na	03	02		02	02		<u>a</u>	na		FXNQ				na			na	na	na	na	FXNQ	01	01	02	02	03	02	na	na	na	01	FXNQ	na	na	na	na	na	na	na	na	na	1
FXLO		01	na	02	01		02	02		2	na		FXLQ				na			na	na	na	na	FXLQ	01	04	02	01	01	02	02	01	01	01	FXLQ	na	na	na	na	na	na	na	na	na	
FXAQ-P/A		01	01	63	01		02	02			na		FXAQ-P/A				na			na	na	na	na	FXAQ-P/A	01	01	02	01	01	02	na	na	na	01	FXAQ-P/A	01	01	na	01	02	01	na	01	na	
FX70-A		01	01	02	01		01	01	5 5	5 8	ZN		FXZQ-A				01			03	na	03	03	FXZQ-A	01	01	01	01	01	02	02	01	01	01	FXZQ-A	01	01	01	01	01	01	na	01	na	
FXDQ-A		01	04	01	01	e	01	01	5 5	5 5	01	ſe	FXDQ-A	Je	e	e	01	e	e	04	na	01	03	FXDQ-A	01	01	02	01	01	02	02	01	01	01	FXDQ-A	01	na	na	na	02	01	na	01	na	
FXHO-A		01	01	02	01	spar	01	10			20	spai	FXHQ-A	spai	spa	spa	01	spa	spa	na	na	na	na	FXHQ-A	01	01	01	01	01	02	02	01	01	01	FXHQ-A	01	na	na	na	03	01	na	01	na	-
d-OMX-		11	la	02	11		20	12			la		-XMQ-P				la			la	11	la	la	-XMQ-P	1	12	02	12	33	12	12	1	11	11	-XMQ-P	11	la	la	la	la	11	12	g	la	-
XFO-A		5	- -	2 (1		1			_ ,	-		XFQ-A				-			4 r	а а	-	3	XFQ-A	-	1	2	1	3 (2 (2	1	1 (1 0	XFQ-A	1	1	1	a	3	1	a 9	1	a	-
XIIO-A		1	1	2 0	1	_	0						XUQ-A F				1	_		8	с 	0	0	XUQ-A F	0	1	1	1	8	2 0	0	0	1 0	1 0	XUQ-A F	1	1	0	L R	0	0		0	с 	-
NO.M F		ò	ò	0	ò		ò	ò			D		(DQ-M F)				0			ö	ů	8	8	(DQ-M F)	ò	ò	ò	ò	0	20	30	ò	.0	.0	(DQ-M F)	Ô	ò	ö	ä	ö	ò	ů	ò	ů	-
SO-P F)		02	na	02	02		01	01			na		SQ-P F)				ua			na	na	na	na	SQ-P F)	02	01	01	01	03	02	02	01	01	01	sq-P F)	na	na	na	na	ua	ua	na	na	na	-
O-A FX		01	na	02	02	_	02	02			na		Q-A FX	_			na	_		na	02	na	na	:Q-A FX	01	01	02	01	02	02	01	01	01	01	:Q-A FX	01	na	na	na	na	01	15	na	na	-
D-P FXC	2	01	01	02	01	_	10	6	5	5 2	10		Q-P FXC				01	_		03	na	03	03	Q-P FXC	01	01	01	03	01	02	02	01	01	01	2-P FXC	01	na	01	na	01	01	na	01	na	-
-M FXFC		01	01	02	02		02	02			20		-M FXFG				01			na	na	na	na	-M FXFG	01	01	02	01	03	02	02	01	01	01	-M FXFG	10	01	na	na	01	01	na	01	na	
FXKO	2	01	na	02	03		eu U	Pa			na		FXKQ				na			na	na	na	na	FXKQ	02	02	02	01	01	02	na	na	na	01	FXKQ	na	na	na	01	02	na	na	na	na	
BRC		0	-	2	3	4	5	9	-	- c	α	6		0	Ļ	2	с	4	5	9	7	80	6		0	-	2	3	4	5	9	7	8	6		0	-	2	3	4	5	9	7	80	
Indoor		20												21											22											23									

DAIKIN

12.2. Field settings as per type indoor unit

units
ndoor
VRV4 ir

Q-A											2-A										
FXT0		tbc	FXT0	tbc			-														
FXSQ-A		tbc	FXSQ-A	tbc			:														
Biddle	-	na	na	na	na	na	na	01	na	04	Biddle	na	01	na	01	na	01	01			
VKM		13	na	01	60	na	05	01	na	na	VKM	na	01	na	02	na	01	01			2
FXNQ		na	na	na	na	na	na	01	na	na	FXNQ	na	02	na	01	na	01	01			20
FXLQ		na	na	na	na	na	na	02	na	na	FXLQ	na	01	na	01	na	01	01			2
FXAQ-P/A		na	na	na	na	na	na	01	na	na	FXAQ-P/A	na	01	01	01	01	01	01			5
FXZQ-A		01	na	na	na	na	na	01	na	na	FXZQ-A	02	01	01	01	01	01	01			5
=XDQ-A		11	Ja	a	a	a	a	11	a	a	=XDQ-A	02	11	11	11	11	11	1		0	2
хно-д	spare	1	2	-	1	-		5	2	-	хно-А	0	5	5	5	5	5	5	spare	spare	
MQ-P F		0	Ö	0	0	0	č	0	0	0	MQ-P F	0	0	0	0	0	0	0			c
A FX		02	na	na	na	na	na	01	na	na	A FX	01	02	na	01	01	01	01			5
FXFQ-,		01	02	01	01	01	na	01	02	01	FXFQ-,	02	01	01	01	01	01	01			5
FXUQ-A		01	na	na	na	na	na	01	na	na	FXUQ-A	02	01	01	01	01	01	01			0
FXDQ-M		na	na	na	na	na	na	01	na	na	FXDQ-M	na	01	na	01	na	01	01			5
FXSQ-P		01	na	na	na	na	na	01	na	na	FXSQ-P	02	01	na	01	01	01	01			0
FXCQ-A		01	na	na	na	na	na	01	na	na	FXCQ-A	02	01	01	01	01	01	01			5
FXFQ-P		01	01	01	01	01	na	01	02	01	FXFQ-P	02	01	01	01	01	01	01			5
FXKQ-M		na	na	na	na	na	na	01	na	na	FXKQ-M	na	01	na	01	na	10	01			5
	0	-	2	e	4	5	9	7	8	o		0	~	2	n	4	5	9	7	œ	σ
	24											25									